

AD-A125 064


COMPUTER ALGORITHMS USED IN COMPUTING THE MK 15/16
CONSTANT 07 ATA OXYGEN..(U) NAVY EXPERIMENTAL DIVING
UNIT PANAMA CITY FL E D THALMANN JAN 83 NEDU-1-83


1/3

UNCLASSIFIED

F/G 6/19


NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS 1963-A

AD A 1 25004



NAVY EXPERIMENTAL DIVING UNIT

DTIC FILE COPY



DTIC
ELECTE
FEB 28 1983
S E D

83 02 025 025



DEPARTMENT OF THE NAVY
NAVY EXPERIMENTAL DIVING UNIT
PANAMA CITY, FLORIDA 32407

IN REPLY REFER TO:

15 March 1983

ERRATUM

NEDU Report 1-83: Computer Algorithms Used in Computing the MK 15/16
Constant 0.7 ATA Oxygen Partial Pressure Decompression Tables.

After publication and distribution, an error was found in Version 1.1 of Subroutine FRSP7 which will cause small underestimates in no-decompression time and which will (in certain instances) compute first stop depths one depth increment deeper than necessary. (The program computes 0 min stop times at these too deep first stops so the resulting decompression profiles are correct).

All holders of the above report should make the following changes and substitutions to the original:

1. Replace pages 40/41 and B4-1 thru B4-4 (Annex B4) with the attached pages. Note that the replacement pages are all coded ERR 1.0 in the lower right hand corner. Subroutine FRSP7 is now Version 1.2.
2. Make a pen and ink change to Fig. 9 (page 30). Change the no-decompression time at 110 FSW from 23 to 24 min.

All other decompression profiles and Model Parameter Printouts remain correct for Version 1.2 of Subroutine FRSP7.



DEPARTMENT OF THE NAVY
NAVY EXPERIMENTAL DIVING UNIT
PANAMA CITY, FLORIDA 32407

5

NAVY EXPERIMENTAL DIVING UNIT

REPORT NO. 1-83

COMPUTER ALGORITHMS USED IN COMPUTING THE MK 15/16
CONSTANT 0.7 ATA OXYGEN PARTIAL PRESSURE
DECOMPRESSION TABLES

CDR EDWARD D. THALMANN, MC, USN

JANUARY 1983

Approved for public release; distribution unlimited

Submitted by:

E. D. THALMANN
CDR, MC, USN
Senior Medical Officer

Reviewed by:

D. G. WHALL
LCDR, USN
Executive Officer

Approved by:

FRANK E. RISSING
CDR, USN
Commanding Officer

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM										
1. REPORT NUMBER NEDU REPORT NO. 1-83	2. GOVT ACCESSION NO. AD-A125064	3. RECIPIENT'S CATALOG NUMBER										
4. TITLE (and Subtitle) COMPUTER ALGORITHMS USED IN COMPUTING THE MK 15/16 CONSTANT 0.7 ATA OXYGEN PARTIAL PRESSURE DECOMPRESSION TABLES		5. TYPE OF REPORT & PERIOD COVERED FINAL										
		6. PERFORMING ORG. REPORT NUMBER										
7. AUTHOR(s) CDR E. D. THALMANN, MC, USN		8. CONTRACT OR GRANT NUMBER(s)										
9. PERFORMING ORGANIZATION NAME AND ADDRESS NAVY EXPERIMENTAL DIVING UNIT Panama City, FL 32407		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS										
11. CONTROLLING OFFICE NAME AND ADDRESS		12. REPORT DATE January 1983										
		13. NUMBER OF PAGES 163										
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report) UNCLASSIFIED										
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE										
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.												
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)												
18. SUPPLEMENTARY NOTES												
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) <table border="0"> <tr> <td>Algorithm</td> <td>MK 15</td> </tr> <tr> <td>Decompression</td> <td>MK 16</td> </tr> <tr> <td>Computer</td> <td>Constant Partial Pressure</td> </tr> <tr> <td>Decompression Tables</td> <td>Oxygen Decompression</td> </tr> <tr> <td>Decompression Models</td> <td></td> </tr> </table>			Algorithm	MK 15	Decompression	MK 16	Computer	Constant Partial Pressure	Decompression Tables	Oxygen Decompression	Decompression Models	
Algorithm	MK 15											
Decompression	MK 16											
Computer	Constant Partial Pressure											
Decompression Tables	Oxygen Decompression											
Decompression Models												
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) <p>The computer algorithms used in computing the MK 15/16 Constant 0.7 ATA Oxygen Partial Pressure Decompression Table are presented. These algorithms were used to compute both the nitrogen-oxygen and helium-oxygen tables. No physiological rationale or test results are presented. Two model independent input-output programs are presented which can be used with any decompression model which can be written in the prescribed 8 subroutines. One input-output program outputs each decompression schedule in a very detailed format while</p> <p>(CONTINUED)</p>												

DD FORM 1473
1 JAN 73EDITION OF 1 NOV 65 IS OBSOLETE
S/N 0102-LF-014-6601

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

20. (CONTINUED)

the other outputs schedules in U.S. Navy Decompression Table format. The 8 subroutines comprising the current MK 15/16 Decompression Model are presented in detail. Where changes in the Decompression Model were made, all versions of the appropriate subroutines are presented. All versions of the program used for computing ascent criteria are presented as well as tables of all ascent criteria actually used in the development of the current MK 15/16 Decompression Model. Annexes contain complete listings of all programs in the Fortran IV language.

Accession For	
NTIS GRA&I	<input checked="checked" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A	



UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Table of Contents

	<u>Page</u>
Abstract.....	v
Glossary.....	vi
Introduction.....	1
Program Overview.....	2

PART 1

Introduction.....	4
Profile Coordinate Input File Format.....	4
Program DMDB7.....	12
Program Initialization Procedure.....	13
Profile Initialization Procedure.....	13
Profile Generation and Update Loop.....	14
First Stop Depth Computation Procedure.....	15
Profile Generation and Update Loop (Cont.).....	16
Stop Time Computation Procedure.....	16
Profile Output Procedure.....	17
Profile Output from Program DMDB7.....	17
Program TBLP7.....	21
Program Initialization Procedure.....	25
Profile Initialization Procedure.....	25
Profile Generation and Update Loop.....	25
First Stop Depth Computation Procedure.....	26
Stop Time Computation Procedure.....	26
Profile Recording Procedure.....	26
Table Printout Procedure.....	29

PART 2

Model Overview.....	32
Subroutine BLOC7.....	33
Subroutine UPDT7.....	33
Exponential Linear Version.....	33
Initialization Procedure.....	34
Tissue Update Loop.....	34
Exponential Node Time Computation Procedure.....	35
Exponential-Linear Crossover Time Computation Procedure...	36
Newton-Raphson Iteration.....	37
Linear-Exponential Crossover Time Computation Procedure...	37
Tissue Inert Gas Update Procedure.....	38
Instantaneous Ascent Depth Computation Procedure.....	38

	<u>Page</u>
Exponential-Exponential Version.....	39
Initialization Procedure.....	39
Tissue Update Loop.....	39
Node Time Computation Procedure.....	39
Exponential Update Procedure.....	40
Instantaneous Ascent Depth Computation Procedure.....	40
Subroutine FRSP7.....	40
Initialization Procedure.....	40
Depth of First Stop Iteration Loop.....	41
Subroutine STIM7.....	42
Exponential-Linear Version.....	42
Initialization Procedure.....	42
Trial Desaturation and Saturation Stop Time Computation.....	43
Desaturation Trial Stop Time Computation.....	43
Saturation Trial Stop Time Computation.....	44
Stop Time Optimization Procedure.....	44
Exponential-Exponential Version.....	45
Initialization Procedure.....	45
Trial Desaturation and Saturation Stop Time Computation Procedure.....	45
Subroutine NLIM7.....	45
Initialization Procedure.....	46
Trial No-Decompression Time Computation Procedure.....	46
No-Decompression Time Optimization Procedure.....	46
Subroutine INIT7.....	47
Subroutine RCRD7.....	47
Recording Procedure.....	47
Printout Procedure.....	48
Subroutine RDIN7.....	48
Model Parameter Input Files.....	48
File Read In Procedure.....	56
Model Parameter Printout Procedure.....	56

PART 3

Introduction.....	58
Program MVALU.....	58
Initialization and Option Select Procedure.....	58
Variable Change Procedure.....	60
Maximum Permissible Tissue Tension Computation Procedure.....	60
File Output Procedure.....	60
Printout Procedure.....	61

	<u>Page</u>
Subroutine MCOMP.....	61
Version 1.0.....	61
Version 2.0.....	63
Program Description.....	63
Version 2.1.....	63
Ascent Criteria.....	64
Decompression Tables.....	64

FIGURES

Figure 1	Program - Model Subroutine Interactions.....	3
Figure 2	Profile Subsegment Schematic.....	5
Figure 3	Profile Coordinate Input File Format.....	7
Figure 4	Profile 1-3 Profile Outputs.....	18
Figure 5	Profile 4,5 Profile Outputs.....	19
Figure 6	Profile 6 Input File and Profile Output.....	22
Figure 7	Profile Coordinate Input File Format for Program TBLP7	24
Figure 8	Program TBLP7 Output Profile Array Structure.....	27
Figure 9	Decompression Table Output Format.....	30
Figure 10	Profile 1,2 Model Profile Parameter Printouts.....	49
Figure 11	Profile 3,4 Model Profile Parameter Printouts.....	50
Figure 12	Profile 5 Model Profile Parameter Printout.....	51
Figure 13	Profile 6 Model Profile Parameter Printout.....	52
Figure 14	Model Parameter Input File HVAL09 Subfiles 1 & 2.....	53
Figure 15	Model Parameter Input File HVAL09 3rd Subfile.....	54
Figure 16	HVAL09 Printout by Subroutine EDIN7.....	57

TABLES

Table 1	Legal Option Inputs.....	9
Table 2	MVAL0 Ascent Criteria.....	62

ANNEXES

ANNEX A

Program DMDB7 Listing	A-1
Program TBLP7 Listing	A-2

ANNEX B

Subroutine BLOC7 Listing	B-1
Subroutine UPDT7 Exponential-Linear Version (1) Listing	B-2
Subroutine UPDT7 Exponential-Exponential Version (2) Listing	B-3
Subroutine FRSP7 Listing	B-4
Subroutine STIM7 Exponential-Linear Version (1) Listing	B-5
Subroutine STIM7 Exponential-Exponential Version (2) Listing	B-6
Subroutine NLIM7 Listing	B-7
Subroutine INIT7 Listing	B-8
Subroutine RCRD7 Listing	B-9
Subroutine RDIN7 Listing	B-10

ANNEX C

Program MVALU Listing	C-1
Subroutine MCOMP Version 1.0 Listing	C-2
Subroutine MCOMP Version 2.0 Listing	C-3
Subroutine MCOMP Version 2.1 Listing	C-4
MCOMP Version 1.0 Ascent Criteria	C-5
MCOMP Version 2.0 Ascent Criteria	C-6
MCOMP Version 2.1 Ascent Criteria	C-7

ANNEX D

Subroutine FMFER Listing	D
--------------------------	---

ABSTRACT

The computer algorithms used in computing the MK 15/16 Constant 0.7 ATA Oxygen Partial Pressure Decompression Tables are presented. These algorithms were used to compute both the nitrogen-oxygen and helium-oxygen tables. No physiological rationale or test results are presented. Two model independent input-output programs are presented which can be used with any decompression model which can be written in the prescribed 8 subroutines. One input-output program outputs each decompression schedule in a very detailed format while the other outputs schedules in U.S. Navy Decompression Table format. The 8 subroutines comprising the current MK 15/16 Decompression Model are presented in detail. Where changes in the Decompression Model were made, all versions of the appropriate subroutines are presented. All versions of the program used for computing ascent criteria are presented as well as tables of all ascent criteria actually used in the development of the current MK 15/16 Decompression Model. Annexes contain complete listings of all programs in the Fortran IV language.

GLOSSARY

- Algorithm** - A sequence of logical steps used to obtain a mathematical result.
- Decompression Profile** - A table or graph showing the time/depth coordinates for an entire dive including all desired stops and all obligatory decompression stops.
- Decompression Schedule** - A listing showing required decompression stop depths and stop times for a particular Bottom Depth/Time dive.
- Decompression Table** - A structured set of decompression schedules usually organized in order of increasing Bottom Depths and Bottom Times.
- Dive Profile** - A table or graph of time/depth coordinates for an entire dive showing all desired stops without regard to decompression obligation.

INTRODUCTION

Over the period from 1977 through 1982, the U.S. Navy Experimental Diving Unit (NEDU) was tasked with developing a set of decompression procedures for use with the MK 15 and MK 16 Underwater Breathing Apparatus (UBA) using a constant oxygen partial pressure of 0.7 ATA and either helium or nitrogen as a diluent. A report regarding a portion of the development of schedules for use with nitrogen as the diluent has been published (1), and the results of schedule testing using helium as a diluent are forthcoming.

Previous efforts by the U.S. Navy in calculating decompression tables have generally started out with a decompression model of some sort but as development progressed, only schedules which produced decompression sickness were revised. Thus, the finished set of tables could not be completely calculated from the original assumptions because these revisions were not applied to all schedules. The effort resulting in the production of the MK 15/16 Constant 0.7 ATA Oxygen Partial Pressure Tables differed in that a computer algorithm was first written and tested. As testing progressed, changes were made to the algorithm and only when a safe algorithm was found were a set of tables computed. Thus, all of the schedules contained in the tables were computed exactly the same way and can all be reproduced exactly from the programs described here. It must be realized, however, that roundoff errors could result in differences in stop times of up to 1 minute when different computer systems are used to run the algorithm. However, the total decompression time for a given schedule should never differ by more than 1 minute. These slight variations are considered insignificant.

The purpose of this report is to document the computer programs used in calculating the MK 15/16 Constant 0.7 ATA Oxygen Partial Pressure Tables. No discussion of the physiological rationale behind the programs will be given at this time. Only the details necessary to understand the mathematical logic and to properly run the programs will be presented. In addition, complete listings of all programs and subroutines are presented.

All of the programs presented here are written in the Fortran IV language running under the Hewlett-Packard RTE IV-B Operating System. All subroutines which are peculiar to the RTE IV-B Operating System are identified for those wishing to bring up these programs using other operating systems. However, it must be understood that neither the authors nor NEDU have the time or facilities to assist in modification of these programs for use with other operating systems.

The RTE IV-B Operating System accepts only a single line of ASCII input for each Fortran READ Statement using the Free Field Format. The Free Field Format (FORMAT statement number specified as *) allows real or integer values, separated by commas, to be input on the same line and does not require a decimal point for whole real numbers. Once the return key is hit, all variables in the READ input list not specified on that line remain unchanged. Other operating systems may not handle Fortran READ Statements this way and program modifications may have to be made.


These programs are extremely flexible and can compute decompression schedules for a variety of dive profiles and breathing gases. However, it must be realized that only certain decompression schedules have been tested and shown to be safe. Some of the test results of these schedules have been published (1) and others will be the subject of future NEDU reports.

PROGRAM OVERVIEW

This report is divided into three parts. Part 1 describes the two model independent input-output programs DMDB7 and TBLP7 along with descriptions of associated input and output files. Part 2 describes the subroutines which comprise the MK 15/16 Decompression Model and Part 3 details the calculation of the various ascent criteria used with the Decompression Model.

The model independent input-output programs DMDB7 and TBLP7 are designed to accept time, depth and rate profile coordinates from a Profile Coordinate Input File and output a specific decompression schedule or a complete set of decompression tables in a specific format. These programs do no calculations related to the Decompression Model but pass parameters to the model and accept for output parameters such as stop depths and stop times which are computed by the model. The interactions of programs DMDB7 and TBLP7 with the decompression Model Subroutines is shown in Fig. 1. Although the MK 15/16 Decompression Model Subroutines used in the development of the computer algorithm are presented in Part 2 of this report, programs DMDB7 and TBLP7 are model independent and can be used with any decompression model so long as the conventions used to get data to and from the subroutines are adhered to. Both programs DMDB7 and TBLP7 accept the same types of inputs; they differ only in their outputs. Program DMDB7 outputs an exact decompression schedule with times computed to two decimal places and will also output Model Profile Parameters used during computation of the schedule. Program TBLP7 rounds off all decompression stops to whole minutes and outputs schedules in standard U.S. Navy Decompression Table format.

Detailed descriptions of each of the eight subroutines which comprise the MK 15/16 Decompression Model are presented in Part 2. During the development of the computer algorithm a change in the MK 15/16 Decompression Model was made. This change resulted in two versions of the Tissue Update Subroutine UPDT7 and the Stop Time Computation Subroutine STIM7. Version 1 is the most current version and assumes that tissues take up gas exponentially but form a gas phase after a certain amount of supersaturation at which point gas elimination proceeds linearly. This model will be referred to as the Exponential-Linear or E-L Model. Version 2 of these subroutines was the version used to compute the tables described in reference (1). It is the classical perfusion limited supersaturation model where no gas phase is ever assumed to form where both gas uptake and offgassing are assumed to be exponential. Version 2 will be referred to as the Exponential-Exponential or E-E Model.



* SEE PROGRAM LISTING FOR SYMBOL DEFINITIONS

FIGURE 1. INTERACTIONS BETWEEN MODEL INDEPENDENT INPUT-OUTPUT PROGRAMS AND DECOMPRESSION MODEL SUBROUTINES

PART 1
MODEL INDEPENDENT
INPUT-OUTPUT PROGRAMS

Introduction


Programs DMDB7 and TBLP7 (the I-O Programs) which are described in this section were designed to accommodate any decompression model which can be written as the 8 subroutines required by the I-O Programs. The I-O Programs accept input from a Profile Coordinate Input File which may be entered directly from a terminal. However, it is more convenient to create the Profile Coordinate Input File with a text editor and then have the program read in the file a line at a time from a mass storage device. In this way, errors in the input file are more easily corrected. The Profile Coordinate Input File describes the individual profile segments which make up the dive profile. The I-O Programs break these profile segments into two subsegments and pass the variables necessary to completely describe the subsegment to the Decompression Model in a common block. However, as seen in Fig. 1, subroutines RDIN7, STIM7, FRSP7, NLIM7 and RCRD7 also pass additional variables in their subroutine calling sequences. The Decompression Model performs whatever computation and record keeping it requires as each subsegment of the profile is processed. As long as descents are made the Decompression Model Subroutines provide little direction to program DMDB7 or TBLP7 but as soon as an ascent is desired these I-O Programs call on the Decompression Model Subroutines to provide them with the necessary stop depths and times in order to safely decompress to the next shallower depth. Once the ascent has been completed, programs DMDB7 and TBLP7 again take direction from the Profile Coordinate Input File until the next ascent is desired at which time the Decompression Model Subroutines take over. In simplistic terms the Profile Coordinate Input File directs descent while the Decompression Model Subroutines direct ascent. The only practical limit on the complexity of the dive profile are the sizes of the buffers which hold the decompression schedule as it is being calculated.

Since programs DMDB7 and TBLP7 both use the same input file structure, this will be described first.

Profile Coordinate Input File Format

Any dive profile no matter how complex can be broken down into segments. In Fig. 2 a dive profile consisting of seven segments is shown. All ascents and descents are assumed to be linear and each segment is assumed to be comprised of two subsegments; a stop for some time (which may be 0 min) at a constant depth followed by a linear ascent or descent to a new depth (the new depth and old depth may be the same resulting in no depth change). The profile in Fig. 2 only shows the depths and times of interest without regard to decompression obligation. It is up to the Model to provide information regarding any stops which must be taken during ascent. Thus, although all ascents shown in Fig. 2 show direct linear ascent to the next shallower depth the Decompression Model will compute and insert any required stops into each ascent subsegment. The specified ascent rate will be retained as the rate of ascent between decompression stops. Each profile segment is completely described by three parameters; the TIME at the current depth, the Next DEPTH, and the RATE of depth change. Programs DMDB7 and TBLP7 require the RATE to always be a non-zero number, even if no depth change will occur.

PROFILE COORDINATE INPUT LINE: TIME AT DEPTH, NEXT DEPTH, RATE



DIVE PROFILE MATRIX (Time, Depth, Rate)

	T	D	R
K-1			
K	TIME AT DEPTH		RATE
K+1	$\frac{D(K+1)-D(K)}{\text{RATE}}$	NEXT DEPTH	0.0
K+2		NEXT DEPTH	

FIGURE 2. TYPICAL DIVE PROFILE SHOWING A PROFILE SEGMENT AND DETAILS OF EACH OF THE TWO SUBSEGMENTS

Each time a profile coordinate input is expected, the Profile Matrix Pointer (K) points to the junction of the first and second subsegment. After the profile coordinates are input, the I-O Program executes two model updates, one for each subsegment. The Time at the Current Depth specifies the number of minutes to be spent at the Depth which was input in the previous Profile Coordinate Input Line [D(K-1)]. The Next Depth and Rate specify where the profile goes to next and what the desired rate of depth change is. The Depth Change and time required for the change, T(K+1), are computed by the I-O Programs. The I-O Programs enter the profile coordinates into the Dive Profile Matrix as shown in Fig. 2. Time at the Current Depth is T(K), the Next Depth is D(K+1) and the Rate is R(K). The I-O Program computes T(K+1) and enters a value of 0.0 at R(K+1). The value at the next Depth is also entered again as D(K+2). If the Model determines that stops are required D(K+1) and D(K+2) will be the depths of the first stops as computed by the Decompression Model. After all updates are completed K is incremented by 2 and will point to the K+2 position in the portion of the Dive Profile Matrix shown in Fig. 2. The final entry in any Dive Profile Matrix is made at K+1, and printout will stop at the K+1 position of the final profile segment.

The Profile Coordinate Input File contains the Time at Current Depth, Next Depth, and Rate coordinates which describe the dive profile as well as other information needed to compute the decompression schedule. An example of an input file is shown in Fig. 3. The line numbers on the left are for reference and are not part of the file. This particular file contains five separate profile descriptions. The first two lines of the file, the name of the Model Input Parameter File followed by the Units and Depth Increment are specified only once in the input file no matter how many profiles are described in the file. The Model Input Parameter Filename is passed to Subroutine RDIN7 which reads the file and passes the data to the other Decompression Model Subroutines. The first integer in the second line of the input file specifies the depth units which will be used for input. A value of "1" means all depth and rate inputs will be in feet and any other value means all depth and rate inputs will be in meters. The I-O Program passes a conversion factor to convert meters to feet to the Decompression Model Subroutines which use depth units of feet internally for the most part. The next integer is the Depth Increment and is usually one of three values; 10, 5, or 3. A value of "10" is usually used with input units in feet and signifies that all stops will be in 10 feet of seawater (FSW) increments. When meters are used for input, the Depth Increment is usually "3" or "5" signifying 3 or 5 meters of seawater (MSW) stop depth increments. Other depth increments may be used but they must be whole numbers.

Lines 3 through 12 of the input file shown in Fig. 3 represent the profile coordinate inputs for the first profile. The last line of input for the profile (which in this case is line 12) is "YES" signifying that another profile follows. If the last line of input had been "NO", as in line 56, then the program would stop. As long as the last input for each profile is "YES", additional profiles may be input. There is no limit to the number of profiles which may be described. After the last profile has been input, this last line must be "NO", as it is for the last line of the 5th profile.

NAVTS1 T=00004 IS ON CR00012 USING 00003 BLKS R=0000

0001	HVAL09	-----	MODEL INPUT PARAMETER FILE NAME
0002	1,10	-----	UNITS, DEPTH INCREMENT
0003	150/ND	-----	PROFILE IDENTIFIER
0004	.79,1.0	-----	GAS TENSION
0005	0,0,60	-----	INITIALIZATION DEPTH, NEXT DEPTH, RATE
0006	F1	-----	OPTIONS
0007	0,150,60	-----	TIME, NEXT DEPTH, RATE
0008	P1	-----	OPTIONS
0009	0,0,60	-----	TIME, NEXT DEPTH, RATE
0010	P1NDFN	-----	OPTIONS
0011	YES	-----	PRINTOUT MODEL PROFILE PARAMETERS?
0012	YES	-----	ANOTHER PROFILE TO FOLLOW?
0013	150/30	}	2ND PROFILE
0014	.79,1.0		
0015	0,0,60		
0016	F1		
0017	0,150,60		
0018	P1	}	3RD PROFILE
0019	30,0,60		
0020	P1TXFN		
0021	YES		
0022	YES		
0023	150/30	}	4TH PROFILE
0024	.79,1.0		
0025	0,0,60		
0026	F1		
0027	0,150,60		
0028	P1	}	5TH PROFILE
0029	30,20,60		
0030	P1LSTXFN		
0031	YES		
0032	YES		
0033	150/30	}	
0034	.79,1.0		
0035	0,0,60		
0036	F1		
0037	0,150,60		
0038	P1	}	
0039	30,20,60		
0040	P1LSTXFN		
0041	YES		
0042	YES		
0043	150/30	}	
0044	.79,1.0		
0045	0,0,60		
0046	F1		
0047	0,150,60		
0048	P1	}	
0049	30,20,60		
0050	P1TX		
0051	0,20,60		
0052	F1		
0053	2,0,60	}	
0054	F1FN		
0055	YES		
0056	NO		

FIGURE 3. PROFILE COORDINATE INPUT FILE FORMAT. THE LINE NUMBERS TO THE LEFT ARE FOR REFERENCE AND ARE NOT PART OF THE FILE.

The third line of input is the Profile Identifier, and the fourth line of input contains up to eight gas tension values, (only 2 are shown) each separated by a comma. The first, third, fifth and seventh values are interpreted as inert gas fractions, (First Inert Gas Fraction, Second Inert Gas Fraction, etc.) the second, fourth, sixth and eighth as oxygen partial pressures in atmospheres absolute (ATA) (First Oxygen Partial Pressure, Second Oxygen Partial Pressure, etc.). It is not necessary to input all eight values. For example, in air dives only one value need be entered, a First Inert Gas Fraction Value of 0.79. In the profile shown in Fig. 3, only two values are used; an inert gas fraction of 0.79 and an oxygen partial pressure of 1.0 ATA. Options which will be described below specify which of these gas tensions is used by the Decompression Model for a profile segment particular update.

After the gas tensions have been entered, the next lines of input occur in pairs. The first line of each pair is a line of profile coordinates for a single profile segment as shown in Fig. 2, and the next line of each pair contains up to 8 characters which specify the four options (Table 1). These options describe various conditions which will be present over the entire segment. The first option (an alphanumeric character followed by an integer) is always used to specify what gas tension should be used for an update. The next three options (pairs of alphanumeric characters) are used to modify the profile computation procedure. These pairs of input lines (Profile Coordinates, Options) are repeated until all segments of the dive profile have been entered. In the first profile of Fig. 3, three pairs of lines (line numbers 5, 6; 7, 8; 9, 10) are needed to describe the profile. The option line of the last pair of lines must contain an "FN" as one of the three options, signifying that no further profile coordinates will be entered for this particular profile (line 10, Fig. 3). The next line of input (line 11, Fig. 3) specifies whether or not a printout of the Model Profile Parameters by Subroutine RCRD7 is desired ("YES" or "NO"). Finally, the last line of input for a given profile (line 12, Fig. 2) specifies whether or not another profile will follow. If "YES" is input then a new profile may be described starting with the Profile Identifier. If "NO" is input then the program stops. Note that the formats for the numerical inputs in Fig. 3 are somewhat arbitrary since all of these are read by the RTE IV-B Operating System in free field format; that is no decimal point need be specified for real numbers as long as the inputs are separated by commas. The only constraints on input are that times and depths must be whole numbers and alphanumeric inputs must be formatted as shown without intervening commas. Rates may be less than 1.0 only for Program DMDB7 but must be entered as non-zero values even if there is no depth change. The program will assign the proper sign to the rate.

As mentioned earlier, each Time, Next Depth, Rate input line describes a profile segment as shown in Fig. 2. However, the first Profile Coordinate Line entered for any profile (e.g. the 5th input line in Fig. 3) is unique in that the first value is the Initialization Depth rather than the Time at Current Depth. The Decompression Model will be initialized at the Initialization Depth and the first depth in the dive profile matrix (D(1) Fig. 2)

TABLE 1.

LEGAL OPTION INPUTS

First Option

First Character

- | | |
|---|--|
| P | Specifies Oxygen Partial Pressure to be used for Model Update. |
| F | Specifies Inert Gas Fraction to be used for Model Update. |

Second Character

- | | |
|-------------|---|
| 1,2,3, or 4 | Specifies which Partial Pressure or Inter Gas Fraction is to be used. |
|-------------|---|

Second, Third and/or Fourth Option

- | | |
|----|---|
| ND | Compute no-decompression time and substitute its value for the Time at Depth. |
| FN | This is the last line of input for this profile. |
| DX | Do not compute decompression stops for ascents, ascend directly to the Next Depth without stopping. |
| TX | Time at Current Depth includes descent time. Subtract descent time from previous depth from Time at Current Depth input. |
| LS | Next Depth is the last depth before surfacing. Compute a stop time at Next Depth which will allow ascent directly to the surface. |

NOTE: The second character of the First Option must be a number. If it is not, an error will result. Option Inputs other than those above (or no input) will result in options ND, FN, DX and LS not being executed. The inert gas tension in use will remain as specified the last time a legal gas tension was specified.

will be set to that depth. T(1) will always be 0.0 and R(1) will be set to the specified rate. The program will compute T(2) and enter the Next Depth into D(2) and D(3) and set R(2) to 0.0. The pointer K will then be set to 3 so it is in position for the next profile segment input.

Whenever an ascent is specified a check is made to see if decompression stops are needed. If they are, the Decompression Model Subroutines will be called on to compute the values for Time at Depth and Next Depth for each subsequent profile segment until the Next Depth specified in the Profile Coordinate Line is reached at which point input from the Profile Coordinate Input File will again be accepted. However, by specifying "DX" as an option this feature will be disabled over the segment specified by the preceding Profile Coordinate Input Line and ascent will proceed directly to the specified Next Depth without any decompression stops. This option is usually used to analyze profiles generated by other decompression models.

The Dive Profile Matrix in Programs DMDB7 and TBLP7 can hold a maximum of 100 points or 50 profile segments. Each descent will specify only one profile segment but each ascent may require several profile segments depending on the number of decompression stops required. This must be kept in mind so that the Dive Profile Matrix does not overflow during a final ascent from some depth to the surface.

Legal options which may be specified in the Option Line have been given in Table 1. Options which specify gas tensions are only allowed as the First Option and are put into effect before any model updates are performed on a given profile segment. If one of the legal First Options as shown in Table 1 is not specified, the gas tension specified the last time a legal First Option was input will be used for model updates. The last three options do not have to be specified if none of these options are needed, as they are all disabled just before the Option Line is read.

As mentioned before, zero Time at Depth and zero Depth Changes are legal and some of the uses of these inputs will now be discussed. A zero Time at Depth is usually input if "ND" is specified as an option because entering "ND" will cause the no-decompression time at the previously input DEPTH to be computed and used in lieu of the time actually entered (line 9,10; Fig. 3).

Another use for a zero Time at Depth input is to change breathing gases during ascent or descent. In the 5th profile of Fig. 3, a constant oxygen partial pressure of 1.0 ATA is used to begin ascent to 20 FSW at 60 FPM after spending 30 min at 150 FSW (line 49 and 50, Fig. 3). In line 51 the Time at Depth input is "0" and the Depth input "20" but the option "F1" in line 52 causes a switch to be made from the First Oxygen Partial Pressure to the First Inert Gas Fraction before beginning the model update for that profile segment. In line 53, even though a Time at Depth of 0 min was specified, the program will call on the Decompression Model Subroutines to see if a 20 FSW stop is necessary before ascending to the next depth, and the appropriate stop time will be computed.

Similarly, a zero Depth Change can be used to specify a gas change at a particular depth while stopped at that depth. Notice the first two pairs of Profile Coordinate/Option Lines in all of the profiles in Fig. 2 (lines 5, 6; 15, 16; 25, 26; 35, 36; 45, 46). The first line of each pair causes the profile to be initialized at 0 FSW using the First Inert Gas Fraction specified in the following Option Line of each pair. After initialization the depth remains at 0 FSW, that is no depth change is made. In each entry following the above pairs of lines, a time of 0 min is specified followed by DEPTH and RATE. This will cause a 0 min stop at 0 FSW but will switch to the First Oxygen Partial Pressure (P1) before beginning descent (lines 7, 8; 17, 18; 27, 28; 37, 38; 47, 48 in Fig. 3).

The only way to terminate a profile is to specify "FN" as one of the options after the last Profile Coordinate Input Line. At this point, the decompression schedule computation is terminated after the specified depth in the last Profile Coordinate Input Line is reached.

If the "LS" option is specified, then the profile will ascend to the specified Next Depth taking any necessary decompression stops and a stop time will be computed at Next Depth such that ascent can be made directly to the surface from that depth. If the specified Next Depth is so deep that ascent to the surface is not possible a stop time of 9999 minutes will be computed. After stopping at Next Depth for the computed stop time, the program will then proceed to the surface, update the model and stop. Specifying "LS" as an option is useful in constructing decompression schedules such as are found in the U.S. Navy Surface Supplied Helium Oxygen Tables where the last stop is at 40 FSW after a switch to 100% oxygen has been made at 50 FSW. The fourth profile in Fig. 3 specifies a total bottom time of 30 min at 150 FSW before ascending to 20 FSW at 60 FPM (line 39, Fig. 3). In line 40, the "LS" option is specified. Any decompression stops between 150 FSW and 20 FSW will be computed automatically. Since the "LS" option was specified, a stop time will be computed at 20 FSW such that ascent can be made directly to 0 FSW. The appropriate stop will be taken, the model will be updated to 0 FSW and decompression schedule computation will then be terminated because the "FN" option was also specified in line 40.

The "TX" option is useful for specifying bottom times rather than actual time at depth. If this option is not specified then the program will assume that the TIME input from the Profile Coordinate Line represents the actual number of minutes to be spent at the current depth. However, if the "TX" option is specified, the program will interpret this time as Total Bottom Time (sum of descent time and actual time at depth) and subtract the descent time from the previous depth from the specified Time at Current Depth to get the actual time at depth which is then passed to the Decompression Model. All of the profiles described in Fig. 3 specify the "TX" option for descent to 150 FSW (lines 20, 30, 40, 50) so that the actual time at 150 FSW will be 27.5 min (30 min bottom time minus 2.5 min descent time). If the "TX" option had not been specified, the times in lines 19, 29, 39 and 49 would have had to be 27.5 min instead of 30 min to describe the same profile.

Program DMDB7

This program accepts input from a Profile Coordinate Input File and outputs a detailed decompression profile. All times are computed to two decimal places and the program can cause the model to output values of all model variables at each stop so a detailed picture of exactly how the decompression profile was computed is obtained.

Program DMDB7 is model independent and can be used with any decompression model which can be written as the prescribed subroutines. All profile coordinate data is passed to the subroutines in the Common Block MDATA. This Common Statement describing the Common Block MDATA must appear in all Decompression Model Subroutines and the subroutines should change the values of the MDATA variables only after ensuring no undesirable side effects will occur. Some subroutines (RDIN7, RCRD7, STIM7, FRSP7, and NLIM7) carry variables with them which do not appear in MDATA.

Program DMDB7 contains 6 procedures; Program Initialization, Profile Initialization, Profile Generation and Update Loop, First Stop Depth Computation, Stop Time Computation, and Profile Output. Program Initialization is carried out only once each time the program is run. It reads the first two lines of the Profile Coordinate Input File and has the Decompression Model Subroutines get all the parameters which will be used to compute the decompression schedules. The same Model Input Parameter File, Depth Units and Depth Increment will then be used for all profiles described by the Profile Coordinate Input File.

The Profile Initialization Procedure is executed once for each profile described in the Profile Coordinate Input File. It reads in the Profile Identifier Label and the Gas Tensions which will be used for each particular dive profile. Variables and counters specific to each profile are then initialized.

The Profile Generation and Update Loop reads in the Profile Coordinate and Option Line pairs describing each profile segment and instructs the Decompression Model to update its parameters for the two subsegments which comprise each segment. The First Stop Depth and Stop Time Procedures are called from this loop to compute decompression stops each time an ascent is specified. This loop also calls on a subroutine to record all the coordinates which will then describe the decompression profile.

The First Stop Depth Computation Procedure is used to find the depth of the first stop every time an ascent is specified. It should be noted that there will always be a stop at one stop depth increment below the surface even if the stop time is zero as it will be in no-decompression dives. If decompression stops are required during ascent, this procedure sets a flag which causes input from the Profile Coordinate Input File to be temporarily suspended and for the Profile Generation and Update Loop to cause ascent in increments of one Stop Depth Increment calling upon the Stop Time Computation Procedure to compute the time to be spent at each stop.

The Profile Output Procedure outputs the Decompression Profile on one page of the line printer and then prints out the Decompression Model Parameters on the next page if they are desired.

A complete listing of Program DMDB7 is given in Appendix A-1. All references to line numbers will refer to the line numbers in the first column of the listing. Fortran statement numbers in the program will be referred to as Statement Numbers.

Program Initialization Procedure (Lines 150 - 191)

First the date and time are read from the RTE IV-B Operating System for use in printout headers. Then the RTE IV-B Operating System establishes the device number of the terminal being used to control the program. Next (line 165), the name of the Model Parameter Input File is read from Profile Coordinate Input File device LB (which is in our case is a 9 track magnetic tape) and printed out on the terminal. Then the desired Units and Depth Increment are read in and written on the terminal. In lines 171 and 172 the logical variable METRIC is set to "true" if all inputs are to be in meters and "false" if all inputs are to be in feet. If metric input is expected the correction factor CF is set to 1/.3048 which will convert all depth inputs from meters to feet, otherwise CF is set to 1. Finally (line 186), a message is printed on the terminal asking the user if he wants to have the model parameters printed out. The response to this question is the value of the variable IPRT which is passed to Subroutine RDIN7. The other variables passed to this subroutine are the device number of the terminal being used (LU), the device number of the line printer (LP), the name of the Model Parameter Input Filename (MPIF), and the value of the logical variable METRIC. Subroutine RDIN7 also uses the value of the Depth Increment (DINC) and the correction factor (CF) but these are passed to the subroutine in the Common Block MDATA. Subroutine RDIN7 returns the names of the breathing gas(es) contained in the Model Parameter Input File in the array IGAS.

Profile Initialization Procedure (Lines 204 - 228)

The Profile Identifier is read from the Profile Coordinate Input File then the inert gas fractions and tensions are read. One to eight values may be input here but gas fractions must be the first, third, fifth, and seventh values and oxygen partial pressures in ATA the second, fourth, sixth and eighth. The logical variables which determine if a first stop is to be calculated (CFSTOP) or if stop times need to be calculated (CSTIME) are initially set to "false". The model parameter counter used by Subroutine RCRD7 (CNTR) and the profile matrices pointer (K) are both set to 1. Finally, the depth at which the Model will be initialized, the next desired depth and the rate are read into CDEPTH, DEPTH and RATE respectively. TIME is set at 0.0 signifying that after initialization at CDEPTH no time is spent there before proceeding to DEPTH. After this line of input is read control

is transferred past the subsequent profile coordinate input statement to Statement 211 (line 250). It should be noted that the Program Initialization Procedure is performed only once for a given Profile Coordinate Input File. Each additional dive profile will cause the program to reenter at Statement 200 (line 207), the start of the Profile Initialization Procedure.

Profile Generation and Update Loop
(Lines 243 - 365)

This is the meat of Program DMD7. Statement 210 reads in the time to be spent at the current depth (TIME), the next depth in the profile (DEPTH) and the rate of the depth change (RATE). Note that the coordinates for the start of the profile were input in the Profile Initialization Procedure so Statement 210 is skipped the first time the Profile Generation and Update Loop is entered. All subsequent profile coordinate inputs from the Profile Coordinate Input File are read in by Statement 210. Also, note that the current depth (CDEPTH) was initially set by the Profile Initialization Procedure and will not be updated until the end of the Profile Generation and Update Loop. Next (line 250), the rate is given the proper sign and the four options are read into array OPTN (line 255). Notice the number specified as the second character in the Gas Tension Option is read into the integer variable NGAS. The five logical variables whose value is specified by the five legal second through fourth options are initially set to "false". Next (line 265), if the first character of the first option was not a "F" or a "P" (the only two legal inputs) all option decoding will be skipped. In lines 269 and 270 the logical variable CP02 will be set to "true" if a constant oxygen partial pressure was specified and to "false" if a constant inert gas fraction was specified. The proper values are then assigned to FN₂ and PO₂ from the array GASTSN depending on the value of CP02 and NGAS (line 271, 272). The remaining three options are now decoded and the appropriate logical variables set to "true" for specified options (line 276 - 282). The DO Loop configuration allows these three options to occur in any sequence in the option line.

When the Profile Generation and Update Loop is entered for the first time from the Profile Initialization Procedure, the counter K is equal to "1" signifying the beginning of the profile. In this case the Decompression Model Subroutine INIT7 is called at line 286 and the Decompression Model is initialized at CDEPTH (which is usually 0) using the oxygen tension specified in the option line. Next at line 293 the variable CFSTOP is set to "true" if an ascent is to take place (and the automatic decompression feature has not been overridden by specifying the "DX" option). By setting CFSTOP to "true" a first stop depth will be calculated later on to see if decompression stops during the ascent will be necessary. If the "TX" option was specified, then BTMTIM was set to "true" in line 278 and the previous time increment is subtracted from TIME in line 298. The value of TIME will never be allowed to be less than 0.0 as it could be if the bottom time were inadvertently specified as a value less than the descent time. Normally the value of TIME is the actual amount of time to be spent at the current depth before proceeding to the next depth. By specifying the "TX" option, one is saying

that the value of TIME includes the descent time from the previous depth and this descent time must be subtracted from TIME so the actual time at depth can be used to update the Model. In cases where a no-decompression dive is to be done, TIME is usually entered as "0" and the "ND" option is specified causing NODLIM to be set to "true" in line 279. When NODLIM is "true", subroutine NLIM7 is called to compute the no-decompression time at the current depth and this value is assigned to the variable TIME (line 302).

In lines 307 through 321 the profile coordinate values for the current depth, time, rate, gas tension, and the appropriate gas tension label are assigned to the D, T, R, GAS and GASLBL profile coordinate arrays, the Model Parameters are updated for the first subsegment by Subroutine UPDT7 and then recorded by Subroutine RCRD7 for future output. The pointer to the current position in the profile coordinate arrays is K and it points to the position in the profile segment as shown in Fig 2. Each time the Profile Generation and Update Loop is executed, two array entries are made, one at position K and the other at position K+1. The five entries at position K are made first (lines 307 -313) then the variables RATE, DC and TC are assigned the values needed to update the Model over the first subsegment (lines 317-319). The RATE and depth change (DC) are always 0 because no depth change occurs in the first subsegment, the depth entry at position K and K-1 both being the current depth CDEPTH. Thus, when the Model Update Subroutine UPDT7 is called it updates the Model for a stop of TIME minutes at the current depth CDEPTH. After the Model is updated Subroutine RCRD7 is called to record the Model Parameters for later printout (line 321). The first argument in RCRD7 is the mode, a "0" signifies recording a "1" signifies a printout. The next argument in Subroutine RCRD7 is the counter (CNTR) to keep track of how many records have been recorded. The subroutine automatically increments CNTR by "1" each time it is called so CNTR need not be incremented in the main program. Once initialized to "1" Program DMDB7 no longer changes the value of CNTR. Finally the device number of the line printer (LP) is passed to the subroutine and is used if a printout is desired.

In line 329 value of RATE is updated for the second profile subsegment. In this subsegment, a depth change DC occurs (which may be "0") and the rate of travel between them is given by RATE. If CFSTOP is "true" (which occurs for all ascents) then the program branches to the First Stop Depth Computation Procedure.

First Stop Depth Computation Procedure (Lines 383 - 406)

Subroutine FRSP7 returns the depth of the first stop (DFS). If the depth of the first stop is shallower than the next depth no stops are needed and ascent can be made directly to the next depth. However, if the next depth is "0" a First Stop Depth of DINC will always be specified. If stops are required, the value of the next depth currently stored in DEPTH is temporarily stored in FDEPTH and DEPTH is assigned the value of DFS or DINC, whichever is greater (line 398). The logical variable CETIME is set to "true" so stop times will be computed after the first stop depth is reached.

Whether a stop is needed or not CFSTOP is set to "false" so the First Stop Procedure will not be executed again unless there is another ascent input from the Profile Coordinate Input File.

Profile Generation and Update Loop (Continued)
(Lines 334 - 364)

Having established what the next depth is to be, the depth change (DC) and the time change (TC) to the next depth are calculated (lines 334, 335). Subroutine UPDT7 updates the Model over the second subsegment and Subroutine RCRD7 records the parameters. Next the depth, time increment, rate, gas tension, and gas tension label are recorded in the K+1 position of the profile arrays (lines 341-345). Note that the rate recorded here is "0" because the first half of the next subsegment will have no depth change. Finally, the current depth (CDEPTH) is updated to DEPTH and the counter (K) incremented by "2" to get the pointer in position for the next profile subsegment. At this point (line 358), control is transferred to one of two places. If stop times are needed (CSTIME or LSTOP "true"), then control is transferred to the Stop Time Computation Procedure. This procedure computes the time which has to be spent at the current depth before being able to ascend a maximum of one depth increment shallower. All previously specified options for gas tensions remain in effect while stop times are being computed. The Stop Time Computation Procedure continues to be called to compute stop times and decrement the depth until the next depth (FDEPTH) is reached. At this point control will be transferred back to Statement 210 (line 246) and the next set of profile coordinates accepted. If no stop times are needed, then control is passed directly back to Statement 210 if DONE is "false". If it is "true" then the last set of profile coordinates as been entered and control is transferred to the Profile Output Procedure beginning at Statement 500 (line 484).

Stop Time Computation Procedure
(Lines 428 - 468)

In line 431 a check is made to see if the current depth is within one depth increment of the final depth. If it is not then the DEPTH is set equal to one depth increment (DINC) less than the current depth (CDEPTH) and the stop time at the current depth necessary to allow ascent from CDEPTH to DEPTH is calculated. Control is then transferred back to Statement 220 (line 307) at line 440. The Subroutine STIM7 has two arguments. TIME returns the stop time and the second argument is the depth to which ascent is desired after a stop of TIME minutes at the current depth. If the current depth is within one depth increment of the final depth, control is passed to Statement 410 (line 444). If CSTIME is "true" it means that the final depth (FDEPTH) has not yet been reached. This is necessitated by the fact that control is passed to the Stop Time Computation Procedure at line 358 if either CSTIME or LSTOP is true. Initially, both variables may be true since the "LS" option which sets LSTOP "true" must occur during an ascent which will always set CSTIME to "true". When control is transferred to Statement 410 for the first

time, CTIME has to be "true" because it is only set to "false" at line 466 which can be gotten to only via Statement 410. So the first time control passes to Statement 410 it will transfer control to Statement 420 (line 461) where the stop time before ascending to the final depth (FDEPTH) is computed. CTIME is set to "false" before returning to Statement 220. Once CTIME has been set to "false" at line 466, the only condition at line 358 which will cause control to be again transferred to the Stop Time Computation Procedure is if LSTOP is "true". If it is, then control is passed from Statement 400 to Statement 410 and down to line 452 because CTIME was set to "false" on the previous pass through the procedure. FDEPTH is set to "0.0" at line 452 because one wants to ascend directly to "0.0" after staying at CDEPTH for the appropriate time. The stop time is computed and CTIME is set to "true" once more so stop times at each stop depth increment during ascent from CDEPTH to the surface will be recorded. The stop times at these depths should be "0.0" and the real purpose of having each stop time computed is to cause the model parameters to be recorded at each stop depth increment as ascent to the surface occurs. LSTOP is set to "false" in line 456 so once the surface is reached, no further stop times will be computed and control will be transferred back to Statement 220 (line 307).

Once LSTOP and CTIME are both "false", the program remains in the Profile Generation and Update Loop until DONE is set to "true". As will be recalled, this occurs only after "FN" has been specified as an option. If DONE is "true", control passes to the Profile Output Procedure which begins at Statement 500 (line 484).

Profile Output Procedure (Line 481 - 537)

Once the current profile input has been finished, the zero times (ZT) of each profile subsegment are computed by serially summing time increments (T) (lines 484-486). Then the Profile Coordinate Input File is read to see if a model parameter output in addition to the profile output is desired (line 490). A header is written out on the first page of output (line 494-503) followed by the dive profile zero time (ZT), elapsed time (T), depth (D), rate (R), gas tension (GAS), and gas tension label (GASLBL) arrays (line 507, 508). Note that the last recorded entry is at the K-1 position in these arrays. If a model parameter printout is desired, a header is written on a second page (line 516-524) and Subroutine RCRD7 is called with the mode set to "1", signifying that a printout is desired (line 528). Lastly, the Profile Coordinate Input File is read again to see if another profile follows (line 533). If MORE is not "YE(S)", the program stops; if it is then control goes back to the Profile Initialization Procedure beginning at Statement 200 (line 207).

Profile Output from Program DMDB7

Figures 4 and 5 show the 5 Profile Printouts generated by the Profile Coordinate Input File in Fig. 3. It must be emphasized that the decompression profiles shown here are examples only and do not necessarily

PROFILE 1

1:14 PM TUE., 5 JAN., 1982
PROGRAM DMDB7 USING 10 FSW STOPS
HVAL09<HELIUM)

150/ND

ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0.00	0.00	0	60	79.00 %
0.00	0.00	0	0	79.00 %
0.00	0.00	0	60	1.00 ATA
2.50	2.50	150	0	1.00 ATA
14.05	11.55	150	-60	1.00 ATA
16.39	2.33	10	0	1.00 ATA
16.39	0.00	10	-60	1.00 ATA
16.55	.17	0	0	1.00 ATA

PROFILE 2

1:14 PM TUE., 5 JAN., 1982
PROGRAM DMDB7 USING 10 FSW STOPS
HVAL09<HELIUM)

150/30

ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0.00	0.00	0	60	79.00 %
0.00	0.00	0	0	79.00 %
0.00	0.00	0	60	1.00 ATA
2.50	2.50	150	0	1.00 ATA
30.00	27.50	150	-60	1.00 ATA
32.00	2.00	30	0	1.00 ATA
35.06	3.06	30	-60	1.00 ATA
35.22	.17	20	0	1.00 ATA
41.45	6.23	20	-60	1.00 ATA
41.62	.17	10	0	1.00 ATA
52.92	11.30	10	-60	1.00 ATA
53.08	.17	0	0	1.00 ATA

PROFILE 3

1:14 PM TUE., 5 JAN., 1982
PROGRAM DMDB7 USING 10 FSW STOPS
HVAL09<HELIUM)

150/30

ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0.00	0.00	0	60	79.00 %
0.00	0.00	0	0	79.00 %
0.00	0.00	0	60	1.00 ATA
2.50	2.50	150	0	1.00 ATA
30.00	27.50	150	-60	1.00 ATA
32.50	2.50	0	0	1.00 ATA

FIGURE 4. PROFILE OUTPUTS AS PRINTED BY PROGRAM DMDB7 FOR THE FIRST THREE PROFILES IN THE FILE SHOWN IN FIGURE 3.

PROFILE 4

1:14 PM TUE., 5 JAN., 1982
PROGRAM DMD87 USING 10 FSW STOPS
HVAL09(HELIUM)

150/30

ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0.00	0.00	0	60	79.00 %
0.00	0.00	0	0	79.00 %
0.00	0.00	0	60	1.00 ATA
2.50	2.50	150	0	1.00 ATA
30.00	27.50	150	-60	1.00 ATA
32.00	2.00	30	0	1.00 ATA
35.06	3.06	30	-60	1.00 ATA
35.22	.17	20	0	1.00 ATA
52.75	17.53	20	-60	1.00 ATA
52.92	.17	10	0	1.00 ATA
52.92	0.00	10	-60	1.00 ATA
53.08	.17	0	0	1.00 ATA

PROFILE 5

1:14 PM TUE., 5 JAN., 1982
PROGRAM DMD87 USING 10 FSW STOPS
HVAL09(HELIUM)

150/30

ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0.00	0.00	0	60	79.00 %
0.00	0.00	0	0	79.00 %
0.00	0.00	0	60	1.00 ATA
2.50	2.50	150	0	1.00 ATA
30.00	27.50	150	-60	1.00 ATA
32.00	2.00	30	0	1.00 ATA
35.06	3.06	30	-60	1.00 ATA
35.22	.17	20	0	1.00 ATA
35.22	0.00	20	60	79.00 %
35.22	0.00	20	0	79.00 %
37.22	2.00	20	-60	79.00 %
37.22	0.00	20	0	79.00 %
57.80	20.58	20	-60	79.00 %
57.97	.17	10	0	79.00 %
113.35	55.38	10	-60	79.00 %
113.52	.17	0	0	79.00 %

FIGURE 5. PROFILE OUTPUTS AS PRINTED BY PROGRAM DMD87 FOR THE LAST TWO PROFILES IN THE FILE SHOWN IN FIGURE 3.

represent tested profiles. The headers printed out with each profile show the date and time that Program DMDB7 was run followed by a line with the program name and depth increments and units. Note that in these particular profiles the units for all depth increments are FSW (feet of seawater). If the profiles were in metric format then MSW (meters of seawater) would have appeared after the depth increment. The next line of the header gives the name of the Model Parameter Input File (MPIF) which in this case was specified as HVAL09 in line 1 of the Profile Coordinate Input File in Fig. 3. Next to the MPIF name in parenthesis is the inert gas description from the MPIF. This description is used for labeling purposes only. In these examples the inert gas label is always HELIUM. Other examples of inert gas labels might be AIR, NITROGEN, 50/50 HE-N₂, etc. Finally, a profile identifier is printed out before the actual profile. Like the inert gas name the profile identifier is for labeling purposes only and is not used for any computations. The profile itself gives the cumulative or Zero Time of the profile and the Elapsed Time at each depth or for each depth change. The positive rates are unsigned and signify descents and the negative rates ascents. The last column shows whether an inert gas fraction (%) or oxygen constant partial pressure (ATA) was used by the model for updating the segment and what value was used.

The first profile is a simple no-decompression dive to 150 FSW. The profile was initialized on 79% inert gas (air in this case) and the rest of the dive was done using a constant 1.0 ATA PO₂ in helium. (The model used here always initializes assuming nitrogen is the inert gas, helium being assumed for the remainder of the dive). The first two entries at 0 FSW are the result of the initialization then a third 0.0 min entry at 0 FSW is made when the switch to 1.0 ATA PO₂ is made. Descent to 150 FSW takes 2.5 min and 11.53 min has been computed as the maximum time which can be spent at 150 FSW without requiring decompression stops. Ascent to the surface takes 2.5 minutes. Notice that a 0.0 min stop at 10 FSW was computed. As mentioned earlier all decompression profiles will always have at least a 10 FSW stop so the model parameters will be recorded at least once before the surface is reached.

The second profile is initialized exactly the same way as the first but 27.5 min is spent at 150 FSW. Notice in Fig. 3 line 19 that 30 min was specified as the time at 150 FSW before ascending to 0 FSW at 60 FPM. However, since the "TX" option was specified in line 20 the 2.5 min descent time was subtracted by the program from the 30 min Bottom Time resulting in 27.5 min being spent at 150 FSW. Also, in line 20 of Fig. 3, the "FN" option was specified indicating that this was the last line of this dive profile. The program computed the stop depths and times at 30, 20 and 10 FSW before going on to the next profile. The first stop is at 30 FSW and it takes 2 min to get there. A 3.06 min. stop is taken before ascending to 20 FSW which takes .17 min. The last profile entry is a .17 min ascent from 10 FSW to the surface after an 11.30 min stop.

The third profile illustrates the use of the "DX" option. Note from Fig. 3 that the profile description is identical to that of the second profile except for the inclusion of the "DX" option in line 30. This option overrides the automatic decompression feature and ascent is made directly to the surface. The usefulness of the "DX" option is not obvious from the

profile printout but is better appreciated by looking at the Model Profile Parameter Printout which will be described later in this report. It is usually used in analyzing profiles produced by other models where all stops are explicitly specified and where analysis of these profiles using the current model is desired.

The fourth profile (Fig. 5) is similar to the second profile except the "LS" option is used to take the last stop at 20 FSW. After stopping at 20 FSW a direct ascent to the surface is made. However, a 0.0 min 10 FSW stop is still computed so that the Decompression Model Parameters will be computed and recorded every stop depth increment until the surface is reached. In this case there is no advantage to taking the last stop at 20 FSW since the total decompression time is the same as in the second profile.

In the fifth profile, a switch from a 1.0 ATA constant PO_2 to a 79% inert gas fraction is made at 20 FSW. Line 49 in the input file in Fig. 3 generates the profile up to Zero Time 35.22 min. Line 51 in Fig. 3 takes a 0 min stop at 20 FSW and switches to an inert gas fraction of 79%. In the Profile Output, two more entries are made at 20 FSW. Both are for 0 min so two additional entries at a zero time of 35.22 min are made. The only thing that has happened during this 0.0 min stop is that the gas switch was made. Line 53 in Fig. 3 specified a 2 min stop before ascending to the surface at 60 FPM. The 2 min stop causes two additional entries to be made at 20 FSW, both at 37.22 min. The first is the 2 min stop and the second a 0 FSW depth change. The reason there was no depth change is that the Model determined that additional time had to be spent at 20 FSW before ascending. The Model computed a 20.58 min additional stop time at 20 FSW then a 55.38 min stop at 10 FSW before ascending to the surface. Since "FN" was specified in line 54 of Fig. 3, the profile is done. Line 56 of Fig. 3 is "NO" signifying that no further profiles follow.

All profiles in Fig. 3 specified printouts of the Model Profile Parameters. These will be discussed later when the Decompression Model is presented. Also note that the "TX" option was used in all profiles so that the descent time to 150 FSW was subtracted from the specified time at 150 FSW. This option allows one to enter times as U.S. Navy Bottom Times which are defined as descent time plus actual time at depth.

In all of the above examples only "square dive" profiles were shown, that is, descent to some depth for a specified time with ascent to the surface. Fig. 6 shows the Profile Coordinate Input File and Profile Output for a complicated multiple depth dive showing how multiple depth dives are handled.

Program TBLP7

This program is basically the same as Program DMDB7 with the exception of some constraints on the Profile Coordinate Input File, a different output format, and rounding off of all bottom and stop times to whole numbers. A complete listing of Program TBLP7 is found in Appendix A-2 and only the differences between Program TBLP7 and DMDB7 will be discussed.

PROFILE OUTPUT

1:21 PM TUE., 5 JAN., 1982
PROGRAM DMD87 USING 10 FSW STOPS
HVAL09<HELIUM)

PROFILE COORDINATE INPUT FILE

150/30

	ZERO TIME	ELAPSED TIME	DEPTH	RATE	GAS
0001	HVAL09	0.00	0	60	79.00 %
0002	1, 10	0.00	0	0	79.00 %
0003	150/30	0.00	0	60	1.00 ATA
0004	.79, 1.0	2.50	150	0	1.00 ATA
0005	0, 0, 60	30.00	150	-60	1.00 ATA
0006	F1	31.50	60	0	1.00 ATA
0007	0, 150, 60	91.50	60	60	1.00 ATA
0008	P1	92.00	90	0	1.00 ATA
0009	30, 60, 60	122.00	90	60	1.00 ATA
0010	P1TX	122.50	120	0	1.00 ATA
0011	60, 90, 60	162.50	120	-60	1.00 ATA
0012	P1	164.00	30	0	1.00 ATA
0013	30, 120, 60	184.00	30	60	1.00 ATA
0014	P1	184.33	50	0	1.00 ATA
0015	40, 30, 60	214.33	50	-60	1.00 ATA
0016	P1	214.83	20	0	1.00 ATA
0017	20, 50, 60	225.37	20	-60	1.00 ATA
0018	P1	225.53	10	0	1.00 ATA
0019	30, 0, 60	294.16	10	-60	1.00 ATA
0020	P1	294.32	0	0	1.00 ATA
0021	120, 0, 60	414.32	0	60	79.00 %
0022	F1	414.32	0	0	79.00 %
0023	0, 200, 60	414.32	0	60	1.00 ATA
0024	P1	417.66	200	0	1.00 ATA
0025	60, 50, 30	477.66	200	-30	1.00 ATA
0026	P1	481.66	80	0	1.00 ATA
0027	120, 150, 30	492.24	80	-30	1.00 ATA
0028	P1	492.57	70	0	1.00 ATA
0029	60, 30, 60	503.71	70	-30	1.00 ATA
0030	P1	504.04	60	0	1.00 ATA
0031	120, 0, 30	515.17	60	-30	1.00 ATA
0032	P1FN	515.50	50	0	1.00 ATA
0033	YES	635.50	50	30	1.00 ATA
0034	NO	638.84	150	0	1.00 ATA
		698.84	150	-60	1.00 ATA
		700.50	50	0	1.00 ATA
		708.00	50	-60	1.00 ATA
		708.17	40	0	1.00 ATA
		749.75	40	-60	1.00 ATA
		749.92	30	0	1.00 ATA
		869.92	30	-30	1.00 ATA
		870.25	20	0	1.00 ATA
		908.11	20	-30	1.00 ATA
		908.45	10	0	1.00 ATA
		1038.24	10	-30	1.00 ATA
		1038.57	0	0	1.00 ATA

FIGURE 6. MULTIPLE DEPTH DIVE PROFILE COORDINATE INPUT FILE
AND PROFILE OUTPUT. SEVENTY NINE PERCENT INERT GAS
BREATHED DURING ALL INTERVALS AT 0 FSW.
BOTH 60 FSW/MIN AND 30 FSW/MIN RATES USED.

First the input file constraints will be discussed. All Profile Coordinate Input Files compatible with Program TBLP7 will work with Program DMDB7 but the reverse is not true. As with Program DMDB7, all rates specified in the input file must be non-zero numbers but they must all be whole numbers greater than 1. However, in Program TBLP7, the very first rate on the very first profile coordinate input line of the file will be used for all subsequent profiles. Also, the first gas tensions input for the first profile will remain in effect for all subsequent profiles. Each profile description for Program TBLP7 must be as shown in Fig. 7. Tissue gas tensions are initialized at the surface and changed just before descent begins. If no gas switch is desired, then one specifies the same inert gas option for both option lines. If this convention is not followed, then the bottom times and stop times will not appear in their proper spot in the printout. Also note that the "TX" option must always be used for decompression dives and that the time specified in the seventh line of each profile must not only be a whole number but must also include descent time. Profiles used with Program TBLP7 must be "bounce dives", that is, descent is made directly to some depth, time is spent at that depth, and then decompression to the surface occurs. Program TBLP7 will accept only "bounce dive" profiles and only one descent and ascent are allowed. Once ascent is begun, it may be stopped to switch breathing gases but no descents must occur; only continued ascents to the surface with intervening stops. The "LS" option allows the last stop to be taken at any desired depth; however, it is up to the user to ensure that in fact a sufficient stop can be taken at the specified depth to allow ascent to the surface. If the last stop depth specified is too deep, a stop time of 9999 min will be returned.

Program TBLP7 expects all profiles in the input file to be described in exactly the same way. The only differences allowed between profiles are the bottom times and depths.

The way in which Program TBLP7 rounds off times depends on what the time is. First of all, all depths and times specified in the Profile Coordinate Input File must be whole numbers. When a no-decompression time is computed the program adds the descent time, truncates the result, and subtracts the descent time. Thus, all no-decompression times are rounded down to the nearest decimal number which when added to the descent time will give a whole number. When the program computes a stop time it adds 0.9 min to the value and truncates the result. However, no matter how small the stop time the minimum stop time will be 1 min. It should be noted that all roundoffs occur before any model updates are done so that the actual rounded off stop times are used to update the model during ascent. In certain cases, when a deeper stop has been rounded up, the additional decompression will allow the next shallower stop to be a minute shorter.

As Program TBLP7 computes each decompression schedule the depths and times are stored in an array. After the decompression schedule computation has been completed the schedule is not immediately printed but is recorded in an output buffer which can hold up to one page of schedules. Only when enough schedules have been recorded to fill the buffer are the schedules printed in table format, a page at a time.

TBLP7 Profile Coordinates

Profile Identifier

Gas Tensions

0, 0, Rate

Options

0, Depth 1, Rate

Options

Time, Depth 2, Rate

Options (TX)

⋮

TIME, Depth N, Rate

Options (FN)

Yes

Yes ("No" if last profile)

FIGURE 7. Profile description format for the Profile Coordinate Input File used with Program TBLP7. Each profile description must comply with this format. Depth 1 is the bottom depth and Time is the Bottom Time. Depth 2 must be less than Depth 1 and all subsequent depth entries must be equal to or less than the preceding depth entry. The TX Option must always be specified in the eighth line of each profile description.

Program TBLP7 does not contain the Subroutine RCRD7 so Model Profile Parameters are not recorded. If this information is desired, Program DMDB7 should be used.

Program Initialization Procedure (Lines 193 - 245)

This is the same as in Program DMDB7 with three additional functions being performed in line 237-244. The array DSTOPS is filled with the permissible stop depths which are a function of the maximum number of stops (NSTOP) and the stop depth increment DINC (line 225-227). The maximum number of stops is dictated by FORMAT Statements 50-64 (lines 172-186). It must be remembered that if the value of NSTOP is changed, then FORMAT Statements 43 and 50-64 may have to be modified accordingly. The maximum bottom time (BTMAX) and maximum total dive time (TDTMAX) are set to their desired values in lines 243 and 244 which will restrict the schedules which will eventually be printed depending on bottom time and total dive time values.

Profile Initialization Procedure (Lines 258 - 289)

In Program TBLP7, the inert gas tensions and rate are read in for the first profile only and these values used for all subsequent profile coordinate inputs in the Profile Coordinate Input File. The first RATE is integerized by assigning it to IRATE (line 286) so fractional rates are not allowed.

Profile Generation and Update Loop (Lines 304 - 436)

Statement 210 does not read a rate as it does in Program DMDB7 but RATE is always set to the value of IRATE, which was specified by the first profile. Lines 374-377 specify how no-decompression limits are computed. Since all bottom times must be whole minutes, the actual time at depth must be adjusted so that when it is added to the descent time later in the Profile Recording Procedure a whole number results. Subroutine NLIM7 returns the exact no-decompression bottom time which may be 0.0 min. First the no-decompression time is adjusted in line 361 so the Bottom Time will not exceed the maximum value specified in line 233. In line 377 a time at depth is computed which when added to the descent time will be a whole number. This is no problem as long as when TIME is added to the descent time (T(K-1)) on the right hand side of the equal sign the result is greater than if T(K-1) was rounded up to the next minute. If it is not then a negative value will result when T(K-1) is subtracted from the truncated value of T(K-1). To prevent this the minimum time added to T(K-1) is .99 min. This ensures that

the Total Bottom Time will never be less than the descent time. Since the value of TIME computed in line 377 is input into the profile generation procedure, if it will require decompression stops they will be computed. Thus, some dives may have no no-decompression limit, decompression stops being required even if ascent is begun immediately after descent.

The legal options for Program TBLP7 are the same as those for Program DMDB7 to retain compatibility. However, the "DX" is meaningless when used with Program TBLP7 and the "TX" option must always be used in the eighth line of each profile (Fig. 7).

Statement 219 (line 383) adds 0.001 min to TIME to prevent any roundoff error from causing the integerized time values in the output procedure to be truncated to the next lower minute. The Subroutine RCRD7 is not used and gas tensions and gas tension labels are not recorded as they are in Program DMDB7 because they are not needed on output.

First Stop Depth Computation Procedure (Lines 454 - 477)

This is identical to that used in Program DMDB7.

Stop Time Computation Procedure (Lines 499 - 545)

This is the same as that used in Program DMDB7 except that all exits back to Statement 220 are via Statement 440 (line 540) so the stop times will be rounded up to the next 0.9 min. This means that stop times are rounded down only if they exceed a whole minute by less than 6 seconds. However, non-zero stop times are never rounded down to less than 1 minute (line 540).

Profile Recording Procedure (Lines 563 - 681)

This procedure has no counterpart in Program DMDB7. After each decompression schedule is computed it is stored in array IPRO for later printout. Each time IPRO fills up a page of schedules is printed before any further schedules are computed. IPRO can hold 26 schedules but only 25 schedules are printed per page. This allows the 26th schedule to be computed and stored before the other 25 schedules are printed. After printout, the schedule in the 26th position is moved to the first position in IPRO and schedule computation and recording continues. The structure of IPRO is shown in Fig. 8.

The procedure begins by ensuring in line 568 that the first stop depth contained in D(6) is not greater than the maximum value allowed by the output format (which is currently 15 stop depth increments). If it is, recording is skipped. Next the counter K is decremented by one so it points to the last

OUTPUT ARRAY ELEMENT	PARAMETER NAME	DECOMPRESSION PROFILE ARRAY ELEMENTS
I _{PRO} (1, N)	Depth	D(5)
(2, N)	Bottom Time	ZT(5)
(3, N)	Time to First Stop (min.)	} T(6)
(4, N)	Time to First Stop (10's sec.)	
(5, N)	Time to First Stop (1's sec.)	
(6, N)	150 FSW Stop Time (min.)	T(K-29)
(7, N)	140 FSW Stop Time (min.)	T(K-27)
⋮	⋮	⋮
(20, N)	10 FSW Stop Time (min.)	T(K-1)
(21, N)	Total Ascent Time (min.)	} ZT(K)-ZT(5)
(22, N)	Total Ascent Time (10's sec.)	
(23, N)	Total Ascent Time (1's sec.)	
(24, N)	Total Number of Stops	

FIGURE 8. Output Profile Array structure for the Nth decompression schedule. Each schedule may only have 24 elements in I_{PRO} which restrict schedules to those having the first stop at 15 stop depth increments or shallower.

entry in the profile arrays. Then the Zero Time is computed by serially summing the time increments in array T (line 573-575). At line 586 the total dive time, ZT(K), is compared to the maximum value (TDTMAX) which was specified in line 244. As long as TDTMAX is not exceeded, control goes to Statement 513 (line 585) where the logical variable NORCRD is set to "false" and recording proceeds. When TDTMAX is exceeded for the first time, NORCRD will be "false" and control will drop through to line 583 where it will now be set to "true". Control then goes to Statement 515 where recording proceeds normally for this profile. However, if the Total Dive Time is still greater than the maximum value the next time through line 583 will transfer control to Statement 560 (line 668) thus skipping the recording procedure. The overall effect of this is that the first profile with a Total Dive Time which exceeds the maximum is recorded but subsequent profiles will not be until the Total Dive Time decreases to less than the maximum.

The four statements beginning at Statement 515 (line 590) check for other conditions which will determine whether or not a schedule will be recorded. The first schedule computed by the program (NPRO = 0) is always recorded. Also, if the maximum depth of the dive has changed from that of the previous profile the schedule is always recorded. In line 597 if the bottom time of a profile is less than that of a previous profile the decompression schedule is not recorded. The overall effect of lines 596 and 597 is that schedules with the same bottom depth are printed with progressively increasing bottom times. In line 598, if the schedule requires decompression stops it is always recorded. At this point, all schedules which reach line 603 are for no-decompression dives. Since the no-decompression time for a given depth may not be known in advance it is possible to have several schedules with progressively increasing bottom times which are all no-decompression dives. Since only the longest no-decompression time is of interest, these schedules are recorded without incrementing NPRO by skipping Statement 535 until the first schedule requiring decompression stops is encountered. Thus, no-decompression profiles overwrite the previously recorded one until the first decompression schedule requiring stops is encountered. All other recorded schedules increment NPRO at Statement 520 so they are recorded in the next available position in IPRO.

Lines 612 through 617 compute the Total Ascent Time (ASTIM), round it off to the nearest second, then records the whole minutes, tens of seconds and seconds units in the three separate elements in IPRO. Next, the Time to the First Stop (TFS) is rounded off and scored in the same manner as the ascent time (lines 622-628). Line 623 checks for no-decompression dives (depth of first stops, D(6) = DINC; stop time, T(7) = 0) and sets the Time to the First Stop and Total Ascent Time equal. Storing ASTIM and TFS in the manner described above makes for a nicer printout. Next, the dive depth and bottom time are recorded in lines 632-633.

Lines 638 through 661 contain the instructions for recording stop times in the proper elements of IPRO. LJ is computed in line 638 and will point to the element in IPRO which will contain the first stop depth. In line 642 the total number of stops is computed and stored in the last position in IPRO.

Fig. 8 shows the positions in IPRO for all permissible stops. As one records stops the usual case will be that after the first stop there will be only one stop every DINC depth increment (Profile 1 and 2, Fig. 4, Profile 4, Fig. 5). However, in some cases there may be more than one stop time at a given depth. In the fifth profile (Fig. 5), there are three separate stop times at 20 FSW (0 min, 2 min, and 20.58 min). Program TBLP7 will add all these together to get one 22.58 min stop and record the whole 20 FSW stop only once in IPRO. The variable ISTOP is initially set to the depth of the first stop (line 648) and is decreased one depth increment each time a stop time is recorded into IPRO (line 661). NK initially points to the position in array T just ahead of where the stop time is. The DO loop beginning at line 653 steps through all stops beginning at the depth of the first stop. The array IPRO has been filled with all zero's initially by a DATA Statement (line 151) and subsequently at line 787. The first stop time is added to the value in the first stop element in IPRO. NK is increased by 2 to point to the next stop depth. If it is still the same (line 660) control goes back to Statement 545 (line 654) where this stop time is added to the previous one. Thus, all stops at a given depth will be accumulated into a single stop time. When the next shallower stop depth is encountered, the next element of IPRO will be used to record the stop time.

After finishing the recording, the next record in the Profile Coordinate Input File is skipped. This line of input specifies whether or not the Model Profile Parameter Printout is desired and is only used in Program DMDB7. The next line of input specifies whether or not another profile will follow and the answer ("YES" or "NO") is read into the variable MORE. Next, a check is made to see if the buffer IPRO is full; if it is, a page of profiles is printed. Then if another profile follows, control is transferred back to Statement 200 (line 261) and the next profile read in. If no more profiles follow, then the contents of IPRO are printed out.

Table Printout Procedure (Lines 696 - 808)

This procedure prints out a page of decompression schedules. A typical page is shown in Fig. 9. Lines 701-705 establish the value of ICONC which will point to the correct gas tension label in array CONLBL. Note that CP02 will have whatever value it had after computing the last schedule. Lines 709 through 717 print out all the header information. In line 723 the bottom depth of the first profile on the page is recorded so that when the depth changes, a special delimiter line can be printed out between groups of schedules with the same bottom depth. The DO loop beginning at line 728 prints out the schedules, one line at a time. If the profile depth has changed then a special delimiter line is printed and ICHNG is set to the new depth (line 736-739). The number of stops stored in the last position of the current row in IPRO specifies which WRITE Statement (line 751-779) will be used to print out that particular decompression schedule. This allows all stops deeper than the first stop to be left blank and makes for a nicer looking printout.

1:33 PM TUE., 5 JAN., 1982 TBLP7 VVAL18 (FEET)

.70 ATA FIXED PO2 IN NITROGEN

DESCENT RATE 60 FPM

ASCENT RATE 60 FPM

DEPTH BTM TM TO (FSW) TIM FIRST (M) STOP			DECOMPRESSION STOPS (FSW) STOP TIMES (MIN)														TOTAL ASCNT TIME			
(M:S)			150	140	130	120	110	100	90	80	70	60	50	40	30	20	10	(M:S)		
80	39	1:10															0	1:20		
80	40	1:10															1	2:20		
80	50	1:10															15	16:20		
80	60	1:10															27	28:20		
80	70	1:00														9	28	38:20		
80	80	1:00														18	28	47:20		
80	90	1:00														25	34	60:20		
80	100	0:50													3	28	42	74:20		
80	110	0:50													8	28	50	87:20		

90	32	1:20															0	1:30		
90	40	1:20															14	15:30		
90	50	1:10														3	28	32:30		
90	60	1:10														17	28	46:30		
90	70	1:00														1	28	28	58:30	
90	80	1:00														10	29	34	74:30	

100	27	1:30															0	1:40		
100	30	1:30															6	7:40		
100	40	1:30															28	29:40		
100	50	1:20														19	28	48:40		
100	60	1:10														7	28	28	64:40	

110	24	1:40															0	1:50		
110	25	1:40															3	4:50		
110	30	1:40															17	18:50		
110	40	1:30															14	28	43:50	
110	50	1:20															7	28	28	64:50

FIGURE 9. PAGE OF DECOMPRESSION TABLES AS PRINTED BY PROGRAM TBLP7.
THESE TABLES ARE THE SAME AS THE 0.7 ATA CONSTANT PO2 TABLES FOUND
IN REFERENCE 4.

After the contents of IPRO have been printed, the schedule in the last position is moved up to the first (remember that IPRO holds one more schedule than will fit on a page), and all other positions in IPRO are filled with zeros (line 785-788). NPRO is set to "1" signifying that only a single schedule is now in IPRO and a check made to see if more profile descriptions are present in the Profile Coordinate Input File. If MORE is "YE(S)" then a form feed is executed and program control goes to Statement 200 (line 261) to begin reading in the next profile. If no more profiles follow but the printout occurred because IPRO was full, control goes back to Statement 570 (line 674) to print out the last schedule before stopping. Finally, a delimiter line is printed below the last decompression schedule printed, a form feed is executed and the program stops.

PART 2

DECOMPRESSION MODEL

SUBROUTINES

Model Overview

There are 8 subroutines which comprise the MK 15/16 Decompression Model (Fig. 1). The Model is based on a maximum of 9 tissue tensions contained in an array. The number and halftimes of the tissues are specified in an input file along with the ascent criteria. The basis of the model is Subroutine UPDT7 which updates the tissue tensions over a specific time interval and depth change (one profile subsegment). In addition to updating the tissue tension, Subroutine UPDT7 also computes the Instantaneous Ascent Depth (IAD) which is the shallowest depth which could be ascended to instantaneously without violating the ascent criteria. In the course of developing the Decompression Model, two versions of Subroutine UPDT7 were used. Version 1 assumes exponential uptake and linear offgassing. This version is the one currently being used to compute the MK 15/16 Constant 0.7 ATA Oxygen Partial Pressure Decompression Tables for either helium or nitrogen inert gas. Version 2 was actually the first one tested and assumes exponential uptake and offgassing. This Version 2 of Subroutine UPDT7 updates tissue tensions according to the classical Haldanian approach assuming no gas phase forms and testing of decompression schedules computed in this way are reported in NEDU Report 11-80 (1). Each version of Subroutine UPDT7 has a corresponding version of Subroutine STIM7 associated with it. Subroutine STIM7 computes the amount of time required at a given depth before ascent can be made to a new depth. It is important that the proper version of STIM7 be loaded with the corresponding version of UPDT7.

Subroutine FRSP7 computes the depth of the first stop and is partially model independent since no assumptions are made in the subroutine about how tissue updating is done. It uses Subroutine UPDT7 to compute the IAD and goes through an iteration to find the depth which can be ascended to at the specified rate without changing the IAD. Subroutine NLIM7 uses the gas uptake equations to get an estimate of the no-decompression time at a given depth but uses Subroutines UPDT7 and FRSP7 to optimize the no-decompression time to the nearest 0.3 seconds.

Subroutine BLOC7 initializes the variables in all the common blocks and Subroutine INIT7 initializes the Model by saturating all tissues at the specified starting depth. The final two subroutines perform input and output functions for the model. Subroutine RDIN7 reads in the Model Parameter Input File which contains the ascent criteria, Stop Depth Increment, Units of Depth input (feet or meters), tissue halftimes, number of tissues and Saturation-Desaturation Ratios. While some variation in the computed decompression schedules can be made by changing the values in the common blocks as specified by Subroutine BLOC7, the major changes in the decompression schedules are made by changing the values specified in the Model Parameter Input File, usually the ascent criteria. Subroutine RDIN7 will also print out the values in the Model Parameter Input File before the actual decompression profiles or tables are output. Subroutine RCRD7 performs two functions, in the record mode it stores tissue tension values and the corresponding zero time in an array, and in the output mode it prints these values out. These values are useful in analyzing the functioning of the Model in detail.

Subroutine BLOC 7

This subroutine initializes the data in the common blocks PARAM and BLDVL which are used by the other MK 15/16 Decompression Model Subroutines. A listing is found in Annex B-1. The Common Block PARAM contains the Model ascent criteria array M, the tissue tension array P, the tissue halftime array HLFTM, the number of tissues NTISS, the saturation-desaturation ratio array SDR and the value of IAD as computed by Subroutine UPDT7. The values assigned to this common block by the DATA Statement at line 38 are really default values since the I-O Program will usually assign values to these variables from the Model Parameter Input File. The Common Block BLDVL contains variables whose values are not usually changed by the Model Subroutines. These variables represent blood and intrapulmonary gas pressures and tensions. The values assigned to these variables in line 56 are all in feet of seawater (FSW) where 33 FSW = 1 ATA = 760 mmHg. While FSW may seem a strange unit for partial pressures, using it greatly simplifies the mathematics in many of the other subroutines. It must be noted that different decompression profiles or sets of tables may require different sets of values for variables in the Common Blocks initialized by Subroutine BLOC7. The values shown in Annex B-1 are appropriate to only certain decompression schedules. The values required in BLOC7 for the various decompression schedules tested during the MK 15/16 Decompression Model development will be described in Part 3 of this report.

Subroutine UPDT7

Subroutine UPDT7 updates model parameters over a single profile subsegment. It is the heart of the MK 15/16 Decompression Model since it describes all of the gas uptake and elimination processes. Two versions are presented. The one for the E-L Model is given in Annex B-2 and the one for the E-E Model is given in Annex B-3. No physiological rationalization will be presented for this subroutine here, only a detailed description of its operation.

Exponential-Linear Version

The listing for the E-L Version (Version 1) of Subroutine UPDT7 is found in Annex B-2. The corresponding version (Version 1) of Subroutine STIM7 is found in Annex B-5. The basis of Subroutine UPDT7 are two gas uptake and elimination equations which update up to 9 halftime tissues during linear depth changes. The E-L Model assumes that all gas stays in solution until the total tissue gas tension exceeds ambient hydrostatic pressure by an amount called the gas phase overpressure. While in solution gas uptake and elimination for linear depth changes are described by Equation 2 of Annex B-2 (line 317). This is called the exponential mode. When the total tissue gas tension exceeds the gas phase overpressure, a gas phase is assumed to form and gas elimination described by Equation 4 of Annex B-2 (line 493). This is

known as the linear mode. Most of Subroutine UPDT7 is concerned with finding the exact time at which the transition is made from Equation 2 to Equation 4. If the partial pressure of oxygen is constant finding the time of the transition from Equation 2 to Equation 4 is straightforward and is given in Statement 210 (line 363) of Annex B-2. If the fraction of inert gas is constant finding the crossover time requires an iterative solution.

In cases where the tissue offgassing is initially described by Equation 4 the transition time at which crossover to Equation 2 occurs can always be found by explicitly solving Equation 3 for T. Equation 3 of Annex B-2 (line 489) describes the condition at the crossover time T and is a quadratic equation in the case of a constant inert gas fraction and a linear equation if the partial pressure of oxygen is constant (in the latter case the rate of change of oxygen tension, R02, is Zero).

After finding the crossover time the tissue tensions are updated and then the Instantaneous Ascent Depth (IAD) is computed. The IAD is the shallowest depth which could be ascended to instantaneously without violating any of the ascent criteria contained in array M. The IAD is used by other Decompression Model Subroutines.

Initialization Procedure (Lines 140 - 167)

The variable IPRNT is set to "0" to suppress printout of iteration values. Setting it to "1" will cause all intermediate iteration values to be printed out each time the Newton-Raphson iteration is performed later on. The iteration values are always printed no matter what the value of IPRNT if more than ten iterations are performed without convergence. Note that there are four rates which are used in the subroutine. RATE is the rate of depth change passed from the main program and can be in feet or meters of seawater (FSW or MSW) per minute. This rate is converted to RAMB which is the rate of ambient pressure change and is always in FSW/min. RINRT is the rate of inert gas change and R02 is the rate of inspired oxygen partial pressure change both of which are in units of FSW/min. If the oxygen partial pressure is constant then R02 is zero and RINRT will equal RAMB. If the inert gas fraction is constant both R02 and RINRT are non-zero and may or may not be equal.

Tissue Update Loop (Lines 183 - 608)

This DO loop contains the procedures for updating the tissue gas tensions over a single profile subsegment. It is executed once for each of the NTISS tissues in the Model. In lines 189-192 the time constants for saturating and desaturating tissues are calculated as well as the initial values of PAN2 and PVSAT. Since these last two variables are changed during loop execution,

they must be updated to their initial values for each new execution. PVSAT represents the amount of inert gas in the venous blood if the blood is just saturated to ambient pressure, and PAN2 is the arterial inert gas tension. The initial tissue tension PTISS is set to the value stored in the tissue tension array P in line 196. P(I) will be updated to its new value at the end of each loop execution. Next, in line 201, the determination is made whether the tissue is initially in the linear (Equation 4) or exponential (Equation 2) mode. If PTISS exceeds PVSAT by the gas phase overpressure PBOVP, a gas phase is assumed to exist so it will be in the linear mode and control is transferred to the linear update procedure at Statement 300 (line 506). If not, no gas phase is assumed to exist so the tissue is in the exponential mode and the program drops through to the Exponential Node Time Computation Procedure.

Exponential Node Time Computation (Lines 220 - 294)

This procedure goes through several checks to see if the tissue tension will go through a maximum or minimum (node) during the subsegment time interval TC. Since either saturation or desaturation may occur in the exponential mode, logical variable DSAT is set to "true" or "false" to record the initial state of the tissue tension change in lines 230 and 231. The conditions for which no maximum or minimum will occur are checked for in lines 236, 242 and 250 and control transferred either to the exponential update procedure at Statement 400 (line 584) or to the procedure which will compute the time at which desaturation goes from the exponential to the linear mode at Statement 200 (line 337). At line 254, any remaining tissues will have a node and the time at which this node will occur is computed in line 257. Tissues which were completely saturated at the current depth will have a node at 0 min (the beginning of an ascent) and will be desaturating for the entire ascent. Since these tissues may crossover to the linear mode line 262 will transfer control to Statement 200. If the node will not occur during the subsegment time interval (TC) then the tissue will remain exponential and line 267 will transfer control to the exponential update at Statement 400. At line 273, all remaining tissues will have a node sometime during the time interval TC and PAN2 and PVSAT are updated to their values at the time of the node. The time remaining in interval TC after the node is computed for later use. Finally, at line 276, the tissue inert gas tension is updated to its value at the node which by definition will be the arterial inert gas tension. The tissue is initially assumed in line 280 to remain exponential for the remainder of the time interval but if it was initially saturating control goes to the Exponential-Linear Crossover Time Computation Procedure at line 337 because after the node it will be desaturating and desaturating tissues will eventually go to linear offgassing. Line 293 transfers control for initially desaturating tissues to the update at Statement 400 (line 584) after the variable DESAT has been set to "false" indicating that after the node the tissue will be saturating.

Exponential-Linear Crossover Time Computation Procedure
(Lines 334 - 472)

Tissues ending up at Statement 200 are all desaturating at this point and may go to the linear mode if the total tissue gas tension exceeds the ambient pressure by the gas phase overpressure (PBOVP) at sometime during the time interval (TI) remaining after the node has occurred. As T gets very large the exponential term in Equation 2 (line 317) goes to 0.0 and Equation 2 becomes the equation of the asymptote:

$$(5) \quad P(I) = (PAN2 - RINRT/K) + RINRT * T$$

The equation for the value of the tissue tension at the ambient pressure at which crossover will occur is:

$$(6) \quad P_{XOVER} = PAMB - (PV_{O2} + PV_{CO2} + PH_{2O}) + PBOVP + RAMB * T$$

Crossover will occur when $P_{XOVER} = P(I)$. If the straight line described by Equation 6 is to the left of the line described by Equation 5, then $P(I)$ will have to assume a value of P_{XOVER} sometime as it approaches the asymptote. Since $RAMB$ is always greater than or equal to $RINRT$, the line described by Equation 6 will be to the left of that described by Equation 5 if the intercept of the Equation 5 line is greater than that of the Equation 6 line. The condition for which this is true is given in line 343 of Subroutine UPDT7 and if met, control passes to statement 210 (line 363) where a crossover time is computed.

If the asymptote line described by Equation 5 is to the left of that described by Equation 6, crossover may not always occur. If the intercept of the Equation 5 line is below that of the Equation 6 line the two lines will intersect only if $RINRT$ is less than $RAMB$. This cannot occur if the oxygen partial pressure is constant so crossover will never occur (line 348) and control goes directly to the Exponential Update at Statement 400. In line 352, the time where the lines described by Equations 5 and 6 intersect is computed and if this does not occur within the remaining time in the interval TI then no crossover will occur and line 357 transfers control to the Exponential Update. If intersection does occur within time TI , crossover may occur and the time T is used as a starting guess for the iteration and control passes to the iteration at Statement 220 (line 384).

Statement 210 can be arrived at only if the conditions in line 343 have been met as discussed above. The time computed here is the exact crossover time if the oxygen partial pressure is constant and if it is the iteration is skipped, control going directly to Statement 280 (line 455). If the fraction of inert gas is constant rather than the partial pressure, then this time will be the maximum time to crossover and is used as a starting point for the iteration to follow.

Newton-Raphson Iteration
(Lines 381 - 443)

Beginning at Statement 220, constants for the equations used in the iteration are computed and the number of iterations initially set to 0. In line 393 Y, represents the difference between the right and left hand sides of Equation 1 (line 313) and will be exactly 0.0 when the time T exactly equals the crossover time. DY in line 394 is the first derivative of Y. The initial values of T as computed in line 352 or 363 and Y as computed in line 393 are used to start the iteration and the values of T, Y, DY and Y/DY for each execution of the iteration are stored in the array VALIT in case they are needed later. Line 413 specifies the convergence criteria and the loop is exited when they are met. Only ten passes are made through the iteration and if the convergence criteria have not been met by then the iteration is halted at line 417 and the values stored in VALIT are printed out. Under certain conditions the value of Y will oscillate around 0.0 and this condition is checked for in line 425 and 426. When this happens, lines 427 and 428 compute the maximum error for the time estimate and if it is less than 0.0001 min the iteration is halted. This substantially cuts down the number of iterations required in many cases. The old time estimate and value of Y are stored in T1 and Y1 and a new estimate of T is made before returning to the start of the iteration at Statement 230 (line 392).

Statement 270 (line 440) will cause the values stored in array VALIT to be printed if no convergence has occurred within ten iterations or if IPRNT was set to "1" in line 141. Control drops through to Statement 280 where the crossover time is assigned the value of T either from the Newton-Raphson Iteration or Statement 210 (line 363). If the crossover occurs outside of the remaining time interval TI, then line 456 transfers control to Statement 400 and the tissue is updated exponentially. If not, pertinent variables are updated to the crossover time in lines 463-470. The time remaining in the time interval (TLIN) is computed in line 471 and since the tissue will be in the linear mode line 472 transfers control to the Linear Update at Statement 450 (line 593).

Linear-Exponential Crossover Time Computation Procedure
(Lines 503 - 571)

In this procedure, Equation 3 (line 489) is solved for T. The equation can be put into quadratic form:

$$(7) \quad (A * T^{**2}) + (B * T) + C = 0$$

Constants A, B and C are given in lines 518-520. The variable D in line 521 is the square root term of the quadratic formula for the solution of Equation 7. If either B or D are less than 0.0 or if B equals 0.0, no

crossover will occur and line 525 transfers control to the linear update at Statement 450 (line 593). If the oxygen tension is constant then R02 is 0.0 causing A to assume a value of 0.0, the square term disappears from Equation 7 and the crossover time is simply the ratio C/B (line 530). If the inert gas fraction is constant, the quadratic formula gives the solution for the crossover time and the root will always be the smallest of the two roots which is given in line 531. If the crossover time is outside the interval TC then the tissue will stay linear for the entire interval so control goes to Statement 450 (line 593). If not, then all pertinent values are updated to the crossover time and DESAT is set to "true" (line 542-545). Next the now exponential tissue is updated to its node (if it occurs in the remaining time) before going to the exponential update (line 550-571).

Tissue Inert Gas Update Procedures (Lines 581 - 595)

Line 584 is the Exponential Update Equation 2 (line 317) and line 595 is the Linear Update Equation 4 (line 493). After P(I) is updated by the appropriate equation control goes back to the beginning of the loop at line 188 until all NTISS tissues have been updated.

Instantaneous Ascent Depth Computation Procedure (Lines 625 - 636)

After all tissues have been updated then the Instantaneous Ascent Depth (IAD) is computed. The IAD is used by other Decompression Model Subroutines and is the shallowest depth which could be instantaneously ascended to without violating the ascent criteria. In the MK 15/16 Decompression Model the ascent criteria are contained in the array M which is a table of maximum tissue tensions for each depth increment. The values in the array are initially determined by analyzing existing tables and then they are adjusted empirically based on manned diving experience. The method of developing the values in the array M will not be covered here, but will be the subject of further reports. The array M has NTISS columns, one for each tissue compartment and 30 rows, representing depths from 1 stop depth increment to 30 stop depth increments. Assume that stop depth increments of 10 FSW have been chosen. Then the first row of the array M represents the maximum tissue inert gas tension at 10 FSW which will allow ascent to 0 FSW, the second row the maximum tissue inert gas tension at 20 FSW which will allow ascent to 10 FSW and so on. The IAD is found by comparing all tissue inert gas tensions to their respective maximum values starting at the 300 FSW row. If all tissue tensions are equal to or less than the values in this row of the array then ascent can be made to 290 FSW. This comparison continues until at least one tissue tension exceeds the maximum. At this depth further ascent would violate the ascent criteria so the depth of this row of array M is the IAD. The IAD is used as a first approximation for the depth of the first stop as will be discussed. Note that the maximum tissue tensions in array M are all in units of FSW but that the stop depth increment DINC is in meters or feet depending on the units used in the Profile Coordinate Input File.

After computing the IAD the tissue tension update is complete and the subroutine returns control to the main program.

Exponential-Exponential Version

The listing for the E-E Version (Version 2) of Subroutine UPDT7 is found in Annex B-3. This version must be used with the E-E Version (Version 2) of Subroutine STIM7 listed in Annex B-6. The E-E Version of Subroutine UPDT7 is similar to the E-L Version in that all tissues are first updated to their maximum or minimum nodes and there are separate time constants for uptake and elimination. In the E-E Version gas uptake and elimination are assumed to always be exponential, and it is assumed that no gas phase ever forms.

Initialization Procedure (Lines 113 - 137)

Only PAMB, PAO2 and RINRT are calculated. The other variables initialized in the E-L version are not used.

Tissue Update Loop (Lines 152 - 257)

This loop is executed once for each of the NTISS tissues. In lines 157-159, the exponential time constant for uptake (KSAT) and elimination (KDSAT) are computed along with the arterial inert gas tension (PAN2). The initial tissue tension PTISS is initialized in line 163 to the appropriate value in array P.

Node Time Computation Procedure (Lines 178 - 228)

This procedure is similar to the Exponential Node Time Computation Procedure in the E-L version. First, in lines 187-188, the value of DSAT is set to "true" or "false" depending on whether or not the tissue is saturating or desaturating. If the depth is constant (RATE = 0) there is no node and control passes directly to the update at Statement 400 (line 240). Also, there will be no node for saturating tissues undergoing descent or desaturating tissues undergoing ascent (line 192, 202). Both of these conditions cause immediate transfer of control to the Exponential Update Procedure at statement 400 (line 240). In line 209 the time of the node occurrence is calculated using the saturation or desaturation time constant as appropriate. If this time is less than 0.0 or greater than the time interval TC control is transferred at line 214 to the Exponential Update Procedure. If the node does occur within the time interval TC the tissue inert gas tension and arterial inert gas tension are updated to the node and the time remaining after the node computed (line 220-222). The variable DESAT is complemented in line 227 and control drops through to the Exponential Update Procedure.

Exponential Update Procedure
(Lines 240 - 245)

This procedure updates the tissue for a linear ascent or descent. After the update is complete, control is transferred back to the beginning of the loop until all NTISS tissues have been done. After all tissues have been updated, control drops through to the procedure which computes the Instantaneous Ascent Depth.

Instantaneous Ascent Depth Computation Procedure
(Lines 273 - 284)

This procedure is identical to the one used in the E-L Version of UPDT7.

Subroutine FRSP7

This subroutine finds the depth of the first stop for a specified ascent rate. The depth of the first stop is passed back to the main program as an argument of the subroutine (DFS), all other data is passed in the three common blocks PARAM, BLDVL and MDATA. The subroutine uses the Instantaneous Ascent Depth (IAD) calculated by Subroutine UPDT7 as a first approximation of the first stop depth. A trial update at the specified rate is performed first to DINC deeper than the IAD then if all ascent criteria are met at DINC+IAD to IAD itself. Depending on the rate of ascent and the initial tissue tensions the tissues may saturate or desaturate during the trial ascent and may have taken up excess gas (in which case the new IAD after ascent will have increased), offgassed sufficiently to go shallower (in which case the new IAD will have decreased) or still have just enough gas on board to require a stop at IAD (in which case the IAD will not have changed). Depending on whether the IAD has increased or decreased after the trial ascent, the first stop depth estimate is increased or decreased in increments of the stop depth increment (DINC) until the IAD before and after ascent are the same and are in fact equal to the depth which has just been ascended to.

Initialization Procedure
(Lines 105 - 119)

The depth of the first stop (DFS) is initially set to the current depth and if the current depth is equal to or shallower than the IAD, CDEPTH becomes the first stop depth. This precaution is necessary for two reasons. The first is that if the DX option is used for an ascent one could end up at a depth shallower than the IAD. If the DX option were not specified for the next ascent, the subroutine would attempt to descend to the IAD causing a negative descent time to be computed. Rather than have that happen, a stop will simply be taken at CDEPTH until ascent is possible. The second situation will occur if a 0 min stop is taken at a decompression stop during ascent (as in changing breathing gases) in which case the current depth will be equal to the IAD. In this case (unless precautions are taken) a trial

descent would be performed to $DINC+IAD$ causing the tissue tensions to increase and an anomalous stop to be taken at $DINC+IAD$. In the auto-decompression mode one can never go too shallow so the depth of the first stop will never be deeper than the current depth. Line 110 ensures this is always the case.

In lines 115 to 118 the logical variable LASTIT is initialized to "false" and the current tissue tensions and IAD stored temporarily because they will be changed when Subroutine UPDT7 is called to do the trial ascent.

Depth of First Stop Iteration Loop (Lines 133 - 191)

The variable MIND is set initially to the IAD and in lines 137-143 a trial update is done from the current depth to $MIND+DINC$. This must be done because the definitions of the ascent criteria requires that they be met DINC deeper than a given depth before ascent to that depth is possible. In lines 144 and 145 the tissue tensions and IAD are restored to their original values. If after ascent to $MIND+DINC$ the IAD has increased, control is transferred by line 152 to line 161 where it will drop through to line 173. If the IAD has remained the same or decreased during the first trial ascent lines 153-155 do another trial ascent to IAD. If the new IAD equals MIND (the value of IAD before ascent) then line 161 transfers control to Statement 50 (line 188) where the value of the depth of the first stop (DFS) is set to MIND and the subroutine exited.

If IAD and MIND are not equal after the trial ascent then control goes to line 173. Since additional tissue saturation or desaturation takes place during ascent it is unlikely that MIND and IAD will be equal the first time through the loop. The usual sequence of events is that the value of MIND is systematically increased or decreased and by the second iteration the value of IAD doesn't change after the trial update and the loop is exited at line 161 with MIND containing the value of the depth of the first stop. In a very few cases, however, the IAD may increase on one pass through the loop and decrease on the next. This occurs when a tissue is still saturating during ascent. On the first trial update all tissue tensions will be less than their maximum permissible values contained in array M and the new IAD decreases by one depth increment after the trial update to the original value of IAD. The next time through the loop the trial update will be to the new value of IAD. If a tissue was saturating during ascent it may have taken up enough additional gas during the additional ascent to the new IAD to just exceed its maximum permissible value. Thus, when the next trial update is done the value of IAD will decrease by one depth increment. This oscillation will continue indefinitely because the tissue will have a tension just below its maximum permissible value at the deeper trial stop and just above it at the shallower trial stop. Since the ascent criteria state that once the maximum permissible tissue tension has been reached at a given depth that ascent to the next shallower depth increment is allowed the depth of the first stop is taken at the shallower of the two depths, and assigned to MIND.

Once the depth of the first stop has been found the IAD is restored to its original value, the value of the integer MIND is assigned to the real variable DFS and the subroutine returns control to the main program (lines 188-191).

Subroutine STIM7

This subroutine computes the time which must be spent at a given depth before ascent to a shallower depth can be accomplished without violating the ascent criteria. Subroutine STIM7 is never called before Subroutine FRSP7 has been called to first establish the depth of the first stop. Once the depth of the first stop has been established, Subroutine STIM7 is usually called to see how much time must be spent at a given stop before ascending one depth increment to the next shallower stop. However, provision is made for ascent to any depth after stopping and in situations where the next shallower stop is more than one stop depth increment shallower, a special optimization procedure is used to shorten the stop time to take advantage of any additional decompression which may occur during ascent.

Ascent may be limited by one of two phenomena. A desaturating tissue will be offgassing and its tissue tensions must decrease to the maximum permissible value as specified in array M before ascent is allowed. In these cases, the stop time is regulated by the desaturation time. In other cases, a tissue may be saturating and the stop time will be determined by the time it takes this tissue to saturate to its maximum permissible value. This is called the saturation time. Either the saturation or desaturation time is computed for each of the halftime tissue and the longest desaturation time and the shortest saturation time is saved. After the saturation or desaturation time has been computed for all NTISS tissues, the shortest of either the saturation or desaturation time becomes the stop time. The next depth to be ascended to after the stop (SDEPTH) and the stop time (TIME) are passed as subroutine variables. Two versions of Subroutine STIM7 are presented. The E-L version (Version 2) is used with the E-L version of Subroutine UPDT7 in Annex B-2 and the E-E version (Version 2) is used with the E-E version of Subroutine UPDT7 in Annex B-3.

Exponential-Linear Version

The listing of this version of Subroutine STIM7 is found in Annex B-5.

Initialization Procedure (Lines 119 - 140)

In lines 122, 127-136, the ambient pressure, arterial oxygen tension and the venous and arterial inert gas tension are computed. In line 134, the desaturation time is initialized to its smallest possible value (0.0) and in line 135 the saturation time is initialized to its largest possible value (9999 min) which is considered an infinite time. Finally, in line 139, the depth or row subscript of array M which is associated with the next shallower depth SDEPTH is computed. It is this row of maximum permissible tissue tensions which must not be exceeded before ascent to SDEPTH can be accomplished.

Trial Desaturation and Saturation Stop Time Computation Procedure
(Lines 158 - 258)

This procedure is executed once for each of the NTISS tissues in the model. In lines 165 and 166 the saturation and desaturation time constants for the tissue under consideration are computed. Then in line 170 control is passed to the Saturation Trial Stop Time Computation at Statement 100 (line 239) if the tissue is saturating. If it is not, control drops through to the Desaturation Trial Stop Time Computation.

Desaturation Trial Stop Time Computation
(Lines 177 - 229)

In lines 181 and 182, the Trial Stop Time is set to 0.0 if the tissue tension is already less than or equal to the maximum permissible tissue tension at SDEPTH. In line 187 and 188, the Trial Stop Time is set to 9999 min (infinity) if the arterial inert gas tension is greater than or equal to the maximum permissible value. It must be remembered that all tissues which are desaturating will approach the arterial inert gas tension asymptotically, so if the arterial inert gas tension is greater than or equal to the maximum permissible value in array M, ascent to SDEPTH will never be possible.

Once it has been determined that a tissue can have a non-zero finite positive stop time, it must be determined whether the tissue is decaying linearly or exponentially. If the dissolved tissue tension is less than or equal to the venous inert gas tension, then the gas phase will have disappeared and the tissue will be decaying exponentially. By setting PLIN to the dissolved tissue tension in line 195 in these cases, the stop time for the linear portion of the tissue desaturation as computed in line 203 will be 0.0. If the dissolved inert gas tension is greater than the venous inert gas tension then PLIN is set to PVN2 in line 201 because when the tissue has desaturated to this value, further desaturation will be exponential. If the maximum permissible inert gas tension is greater than the venous, the tissue will have satisfied the ascent criteria without ever entering the exponential mode so PLIN is set in line 202 to the maximum permissible value in array M, so that the stop time for the exponential portion of the desaturation as computed in line 214 will be 0.0. After computing the time required for linear desaturation in line 203, the procedure will fix the time spent in the exponential mode to 0.0 if the maximum permissible inert gas tissue tension is above the venous (line 209-210). The time for the exponential portion of the desaturation is computed in line 215 and the exponential or linear times are summed in Statement 40 (line 219) to get the total stop times for this particular desaturating tissue. In line 224, it is assured that the largest stop time which can be computed is 9999. minutes. Finally, at Statement 50, the largest desaturation time computed so far is saved as TDSAT before either proceeding on the next tissue or exiting the loop if all NTISS tissues have been done.

Saturation Trial Stop Time Computation
(Lines 235 - 258)

Saturating tissues always stay exponential and a positive finite stop time will exist if the dissolved inert gas tension is less than the maximum permissible value in array M (line 246). The saturation stop times are computed in line 250 but can never be negative (line 251). A negative stop time might occur because of roundoff error causing the log argument function to be less than 1.0 in line 250. The shortest saturation time is saved in line 256 before doing the next tissue or exiting the loop.

In line 267 the smallest of the saturation or desaturation stop times is assigned to TIME as the stop time. Line 271 will terminate the subroutine if the depth to be ascended to after the current stop is not more than one DINC shallower than the current depth. Also, the subroutine is terminated if a non-zero positive finite stop time was not found (line 275).

Stop Time Optimization Procedure
(Lines 292 - 350)

If ascent is to be greater than DINC and a non-zero positive stop time exists, then it may be possible to shorten the stop time to take advantage of the additional decompression. The two logical variables used in this procedure are initialized in lines 295 and 296 and the current tissue tension and IAD stored temporarily in lines 300-302 anticipating the trial update by Subroutine UPDT7 which will change these values. In lines 306-309, a trial update for the trial stop time previously calculated at the current depth is done and Subroutine FRSP7 called to compute the depth of the first stop (DFS). If the value of DFS as returned by Subroutine FRSP7 is greater than SDEPTH (the next shallower stop depth) the first time through the procedure, no optimization is possible. This usually means a tissue is saturating during ascent and will actually exceed the maximum permissible tissue tension at SDEPTH when it is reached. If DFS is less than or equal to SDEPTH, optimization may be possible.

In lines 313-315, the tissue tensions and IAD are restored to their original values. Line 319 will transfer control to Statement 430 (line 340) if the value of DFS is greater than SDEPTH. If it is not, FIRSTM is set to "false" signifying that the first pass through the procedure has been completed. In line 329, if the stop time is 0.0 or if IDFS has been set to "true" in line 348 on a previous pass, the optimization is over and the subroutine is terminated. In line 334, the stop time is shortened by 0.1 min (but never to a value less than 0.0) before returning to Statement 400 (line 300) for another update. Shortening of the stop time will occur until the value of DFS as computed by Subroutine FRSP7 in line 311 just exceeds SDEPTH.

When DFS exceeds SDEPTH, control is transferred at line 319 to Statement 430 (line 340) and if this happens the first time through the procedure (FIRSTM is "true"), the subroutine is terminated because optimization is not possible. If it is not the first time through then the stop time is increased in .005 min increments. IDFS is set to "true" so that as soon as the stop time has been increased sufficiently to cause DFS to equal SDEPTH, line 329 will cause the subroutine to terminate.

Exponential-Exponential Version

The E-E Version of Subroutine STIM7 should only be used with the E-E version of Subroutine UPDT7. The E-E Version of Subroutine STIM7 is basically the same as the E-L Version except that the linear portion of the gas elimination is assumed not to take place, both gas uptake and elimination being assumed exponential. A listing of this version of Subroutine STIM7 is found in Annex B-6.

Initialization Procedure (Lines 117 - 137)

The venous inert gas tension does not appear in this subroutine and is not initialized. Otherwise the procedure is the same as for the E-L Version.

Trial Desaturation and Saturation Stop Time Computation Procedure (Lines 155 - 231)

The major difference in this section from the E-L Version is the procedure for finding the trial stop time for desaturating tissues. Since all offgassing is exponential once it has been verified that conditions at the stop will allow decay to the maximum permissible level in array M in lines 179 and 185, only the exponential stop time has to be computed (line 189). The procedure for finding the stop time for saturating tissues is identical to that in the E-L Version.

From line 236 on, the E-E version of STIM7 is identical to that portion of the E-L version beginning at line 264 in Annex B-6.

Subroutine NLIM7

Annex B-7 contains the listing for this subroutine. This subroutine finds the maximum time which can be spent at the current depth which will allow direct ascent to the surface without violating the ascent criteria. The no-decompression time is passed as the variable TIME with the subroutine.

The no-decompression time is first estimated by computing the time it takes for each tissue to exponentially saturate to a level where the tissue tension just equals the maximum permissible value at 1 ATA (that is, the values in the first row of array M). The trial no-decompression time is the shortest of all the times computed for each tissue. Since this trial no-decompression time assumes instantaneous ascent, an optimization procedure is performed which will lengthen or shorten the trial no-decompression time until the tissue tensions are exactly equal to their maximum permissible values at the surface after a linear ascent at a finite rate.

Initialization Procedure (Lines 112 - 125)

The logical variable IDFS which is used later on in the Optimization Procedure is set to "false". The ambient pressure, arterial oxygen tension and arterial inert gas tensions are computed and the no-decompression time is initialized to 9999 min which is defined as being essentially infinite.

Trial No-Decompression Time Computation Procedure (Lines 141 - 166)

This procedure is a DO loop which is executed once for each of the NTISS tissues. If the tissue tension already exceeds its maximum permissible value, the trial no-decompression time is set to 0.0 min (line 147, 148). If the arterial inert gas tension is less than the surfacing maximum tension then the tissue can surface without decompression even after saturating and the no-decompression time is set to 9999 min (line 153, 154). In lines 158-163, the trial no-decompression time is computed for all other tissues and the smallest value saved as the final trial no-decompression time in line 164.

If the trial no-decompression time is 0.0 or 9999 then optimization is not possible and line 179 transfers control to Statement 40 (line 241) and the subroutine is exited.

No-Decompression Time Optimization Procedure (Lines 190 - 231)

The current tissue tensions in array P are stored in array TP (the IAD was temporarily stored in line 175) anticipating a trial update by Subroutine UPDT7 which will change the tensions in array P as well as the IAD. In lines 198-201 a trial update at the current depth is done and then Subroutine FRSP7 is called to find the depth of the first stop. Following this, the tissue tensions in array P are restored to their original values in lines 205 and 206.

If the depth of the first stop (DFS) is not 0.0 then some gas uptake is taking place during decompression and the trial no-decompression time is too long. If DFS is 0.0 then all one can say is that the trial no-decompression time is not too long but it may be too short. The remainder of the procedure beginning at line 210 will add time in 0.1 min increments to the trial no-decompression time (line 218) until DFS is no longer 0.0. At this point, one can say that at the most the no-decompression time is 0.1 min too long. Since DFS will now exceed DINC, line 210 transfers control to Statement 30 (line 225) where the trial stop time is shortened in 0.005 min increments. Since IDFS was set to "true", as soon as the trial no-decompression time has been shortened sufficiently such that DFS is again 0.0 then line 217 will transfer control to Statement 40 where the subroutine is exited. If the trial no-decompression time at any time decreases to 0.0 then line 230 will immediately transfer control to Statement 40. If a finite positive time results from the optimization procedure it will be at the most .005 min (0.3 sec) too short.

Statement 40 restores the IAD to its original value and the subroutine is exited.

Subroutine INIT7

In this subroutine the model is initialized at CDEPTH. CDEPTH is usually 0.0 but may be any value. All tissue inert gas tensions are set equal to the arterial inert gas tension at CDEPTH. A listing is found in Annex A-8.

Subroutine RCRD7

This subroutine which is listed in Annex B-9 has two modes. If MODE is "1" then line 90 transfers control to the printout procedure beginning at Statement 200 (line 136). Otherwise, control drops through to the recording procedure.

Recording Procedure (Lines 100 - 121)

The tissue tensions in array P are recorded in array TT in the row specified by CNTR. If this is the very first record, line 108 causes line 109 to be skipped so that the recorded Zero Time will retain the value of "0" set in the DATA Statement in line 76. Otherwise, line 109 sums the elapsed time since last recording Zero Time with the previous Zero Time to get its current value. Tissue gas tensions are stored in columns 1 through 9 of array TT, Zero Time in column 10 and the inert gas tension in column 11. CNTR is automatically incremented in line 119 each time the recording procedure is executed.

Printout Procedure
(Lines 135 - 139)

The tissue inert gas tensions, zero time and gas tensions are written out to the line printer. The tissue halftimes and saturation desaturation ratios are written in a label for the appropriate tissue tension column. Figures 10, 11 and 12 show examples of Model Profile Parameter Output for the profiles in Fig. 4 and 5. In these cases, 9 tissues were specified so there are 9 columns of tissue tensions. If less than 9 tissues had been specified, zeros would have appeared in columns where a tissue was not specified. Column 10 is the Zero Time and keys the 9 tissue tensions to the rows having corresponding zero times in the profiles of Fig. 4 and 5. Tissue tensions are printed in the last column but are unlabeled. Figure 13 is the Model Profile Parameter Output for the multiple depth dive profile shown in Figure 6.

The array TT can hold up to 100 profile subsegments or 50 profile segments; in this case, the same number as the dive profile arrays in Program DMDB7.

Subroutine RDIN7

This subroutine reads in the data in the Model Input Parameter File. A complete listing is found in Annex B-10. Since different computer operating systems handle disk files in different manners this subroutine must be tailored not only to the Decompression Model used but to the operating system as well. All subroutines except one which is used by this subroutine are part of the Hewlett-Packard RTE IV-B Operating System and will not be discussed. Subroutine FMPEP is a subroutine which was especially written to decode any error messages which may occur when manipulating disk files and a listing is given for completeness in Annex D. No detailed description of Subroutine FMPEP is given, the comments contained in the subroutine should be sufficient for those familiar with the RTE IV-B Operating System. Subroutine FMPEP is not necessary for proper execution of Subroutine RDIN7 and can be left out. Its only purpose is to print out any errors which occurred during disk file manipulation as soon as it occurs. Without this subroutine the program would simply stop if an error occurred and the operating system would have to be interrogated to find the reason.

Model Parameter Input Files

A typical Model Parameter Input File (MPIF) which is read by Subroutine RDIN7 is shown in Figures 14 and 15. This particular file consists of 3 sub-files each 33 lines long. There is no limit to the number of sub-files which may be contained in each MPIF, however, each sub-file must be exactly 33 lines long and conform to the format in Figures 14 and 15.

PROFILE 1

1114 PM TUE., 5 JAN., 1982
 PROGRAM DHD87 USING 10 FSU STOPS
 HVAL 09KHELIUM
 150/ND

5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR	TIME	GAS
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	1.00
40.16747	32.63971	28.72124	26.66817	25.62514	25.27556	25.09845	24.99445	24.92262	2.50	1.00
126.66023	96.59586	68.23941	48.77090	37.32841	33.22928	31.12218	29.84151	28.97762	14.05	1.00
119.99036	95.41788	69.23573	49.94891	38.14677	33.83263	31.59630	30.23172	29.30797	16.39	1.00
119.29259	95.06580	69.23573	49.94891	38.14677	33.83263	31.59630	30.23172	29.30797	16.39	1.00
		69.06129	49.86169	38.10321	33.80516	31.57593	30.21721	29.29682	16.55	1.00

PROFILE 2

1114 PM TUE., 5 JAN., 1982
 PROGRAM DHD87 USING 10 FSU STOPS
 HVAL 09KHELIUM
 150/30

5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR	TIME	GAS
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	1.00
40.16747	32.63971	28.72124	26.66817	25.62514	25.27556	25.09845	24.99445	24.92262	2.50	1.00
146.10617	131.28619	102.31900	72.85109	51.67581	43.37380	38.95785	36.22190	34.35783	30.00	1.00
138.98517	128.39618	101.89075	73.40414	52.30460	43.88229	39.36361	36.58182	34.66662	32.00	1.00
126.19281	122.00000	98.69266	71.80510	51.68267	43.62006	39.24049	36.49669	34.61244	35.06	1.00
125.49504	121.85112	98.51822	71.71788	51.64269	43.60888	39.22975	36.48908	34.60733	35.22	1.00
99.42216	108.61469	92.00000	68.45877	50.81314	42.71399	38.67796	36.10497	34.32021	41.45	1.00
98.72448	108.26581	91.82556	68.37155	49.96953	42.68719	38.66040	36.09181	34.31043	41.62	1.00
91.42215	84.61469	80.00000	62.45877	47.01314	40.71627	37.21970	35.03227	33.48180	52.92	1.00
59.72438	84.26581	79.82556	62.37155	46.96953	40.68719	37.19872	35.01502	33.46687	53.08	1.00

FIGURE 10. MODEL PROFILE PARAMETER PRINTOUTS AS PRINTED BY SUBROUTINE RCRD7 FOR THE FIRST TWO PROFILES IN FIGURE 4.

PROFILE 3

1:14 PM TUE., 5 JAN., 1962
PROGRAM DMD87 USING 10 FSU STOPS
HVAL69<HELIUM

158/30

5 MIN	10 MIN	20 MIN	40 MIN	80 MIN	120 MIN	160 MIN	200 MIN	240 MIN	
1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	GAS
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
48.16747	32.69971	28.72124	26.66817	25.62514	25.27556	25.09845	24.99445	24.92262	2.50
146.18617	131.28619	102.31900	72.85109	51.67581	43.37380	38.95785	36.22190	34.35783	30.00
136.89185	127.34953	101.36742	73.14249	52.17707	43.81301	39.33125	36.54446	34.63859	32.50
									1.00

PROFILE 4

1:14 PM TUE., 5 JAN., 1962
PROGRAM DMD87 USING 10 FSU STOPS
HVAL69<HELIUM

158/30

5 MIN	10 MIN	20 MIN	40 MIN	80 MIN	120 MIN	160 MIN	200 MIN	240 MIN	
1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	GAS
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00
48.16747	32.69971	28.72124	26.66817	25.62514	25.27556	25.09845	24.99445	24.92262	2.50
146.18617	131.28619	102.31900	72.85109	51.67581	43.37380	38.95785	36.22190	34.35783	30.00
136.89185	127.34953	101.36742	73.14249	52.17707	43.81301	39.33125	36.54446	34.63859	32.50
									1.00

FIGURE 11. MODEL PROFILE PARAMETER PRINTOUTS AS PRINTED BY SUBROUTINE RCRD7 FOR THE LAST PROFILE IN FIGURE 4 AND THE FIRST PROFILE IN FIGURE 5.

PROFILE 5

1114 PM TUE.. 5 JAN.. 1982
 PROGRAM DMDB7 USING 10 FSW STOPS
 HVAL 09<HELIUM
 158/38

5 MIN	10 MIN	20 MIN	40 MIN	80 MIN	120 MIN	160 MIN	200 MIN	240 MIN	TIME	GAS
1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR		
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
40.16747	32.69971	28.72124	26.66817	25.62514	25.27536	25.09845	24.99445	24.92262	2.50	1.00
146.10617	131.28619	102.31900	72.85109	51.67581	43.37380	38.95785	36.22190	34.35783	30.00	1.00
138.98517	128.39618	101.99075	73.40414	52.30460	43.88229	39.38361	36.58182	34.66662	32.00	1.00
126.19261	122.00000	98.69266	71.80510	51.68267	43.62006	39.24049	36.49669	34.61244	35.06	1.00
125.49504	121.65112	98.51822	71.71788	51.64269	43.60888	39.22975	36.48908	34.60733	35.22	1.00
125.49504	121.65112	98.51822	71.71788	51.64269	43.60888	39.22975	36.48908	34.60733	35.22	79.00
125.49504	121.65112	98.51822	71.71788	51.64269	43.60888	39.22975	36.48908	34.60733	35.22	79.00
123.18547	120.49634	97.94083	71.42918	51.49834	43.56377	39.23959	36.51589	34.64052	37.22	79.00
99.42216	108.61469	92.00000	68.45877	50.01314	43.20583	39.33600	36.78119	34.97111	57.80	79.00
99.23397	108.53058	91.95795	68.43774	50.00262	43.20017	39.33489	36.77913	34.97038	57.97	79.00
51.42218	84.61469	80.00000	62.45877	47.01314	41.20718	37.89685	36.02637	34.60078	113.35	79.00
51.30258	84.55484	79.37088	62.44381	47.00566	41.20219	37.89254	36.02379	34.59801	113.52	79.00

FIGURE 12. MODEL PROFILE PARAMETER PRINTOUTS AS PRINTED BY SUBROUTINE RCRD7 FOR THE LAST PROFILE IN FIGURE 5.

11:21 PM TUE... 5 JAN.. 1982
 PROGRAM DHD87 USING 10 FSU STOPS
 HVAL09<HELIUM
 150/30

5 MIN	10 MIN	20 MIN	40 MIN	80 MIN	120 MIN	160 MIN	200 MIN	240 MIN	TIME	GAS
1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR	1.00 SDR		
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	79.00
24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	24.57000	0.00	1.00
40.16747	32.69971	28.72124	26.66817	25.62514	25.27556	25.09845	24.99445	24.92262	2.50	1.00
146.10617	131.20819	102.31900	72.85109	51.67581	43.37380	38.95785	36.22190	34.35783	30.00	1.00
141.07846	129.44284	102.41406	73.63254	52.34354	43.89097	39.37463	36.57076	34.65589	31.50	1.00
58.54177	60.31859	64.44475	63.85016	54.83935	48.16586	43.75233	40.68793	38.44937	91.50	1.00
89.55327	80.77869	64.60109	63.93386	54.92030	48.24330	43.81634	40.74426	38.49866	92.00	1.00
88.04774	85.03384	80.05046	73.89288	62.60651	54.64828	49.26210	45.46010	42.64965	122.00	1.00
89.09430	85.66600	80.45432	74.14880	62.78357	54.78956	49.37910	45.56010	42.73718	122.50	1.00
118.38513	116.44788	108.98859	96.32440	79.10255	67.93300	60.37647	55.00211	51.00298	162.50	1.00
113.19228	113.91504	107.87480	95.93491	79.05960	67.98514	60.46111	55.09608	51.10100	164.00	1.00
39.96883	72.04897	86.94176	85.46538	73.82634	64.45629	57.85649	53.31503	49.83250	184.00	1.00
39.96802	71.38127	86.59288	85.29395	73.74104	64.44824	57.82837	53.29856	49.82127	184.33	1.00
40.36572	51.36816	62.36649	70.83878	67.96350	61.91082	56.69149	52.82471	49.71161	214.33	1.00
47.35847	50.75134	61.92113	70.58621	67.84138	61.83725	56.64363	52.79147	49.68782	214.83	1.00
25.20154	34.07604	50.89764	65.07446	65.08351	60.00000	55.26569	51.68913	48.76920	225.37	1.00
24.93378	33.83956	50.72320	64.98724	65.04190	59.97092	55.24389	51.67168	48.75466	225.53	1.00
8.50121	8.71777	12.66881	30.45765	47.08552	48.00000	46.26569	44.48913	42.76920	294.16	1.00
8.38649	8.65769	12.61601	30.38047	47.04191	47.97052	46.24369	44.47169	42.75467	294.32	1.00
24.57000	24.56612	24.38322	25.34548	42.74786	45.10822	44.09686	42.75407	41.32332	414.32	79.00
24.57000	24.56612	24.38322	25.34548	42.74786	45.10822	44.09686	42.75407	41.32332	414.32	1.00
54.76700	48.61243	32.68011	29.50644	44.36450	46.14714	44.08953	43.40399	41.87558	417.66	1.00
198.46490	196.83302	177.77252	138.75180	106.85051	90.76889	80.05017	72.52290	66.79506	477.66	1.00
183.93613	188.91748	175.87788	138.95615	107.91647	91.85356	81.05084	73.42885	67.61685	481.66	1.00
139.62460	166.76172	164.00000	133.41721	105.33887	91.06163	80.93652	73.61150	67.94449	492.24	1.00
138.22906	166.06396	163.65112	133.24277	105.25317	91.02788	80.92589	73.61098	67.95000	492.57	1.00
92.39229	142.76172	152.00000	127.41721	102.34039	89.62494	80.34088	73.41256	67.96739	503.71	1.00
91.10124	142.06396	151.65112	127.24277	102.25317	89.57504	80.31668	73.40579	67.96291	504.04	1.00
64.94461	118.06395	139.65112	121.24277	99.25317	87.59348	79.25217	72.81905	67.65351	515.17	1.00
48.50800	48.52715	52.05093	63.94216	69.56771	68.77080	66.76836	64.54460	62.04113	515.50	1.00
68.42191	59.23326	57.22395	65.90915	70.41809	69.34079	67.24524	64.93604	62.39282	638.84	1.00
148.48047	147.10522	137.09052	119.29374	102.07224	92.52502	85.84404	80.62497	76.89277	698.84	1.00
142.58319	144.19528	135.84680	118.93590	102.05965	92.59853	85.93512	80.72937	76.19774	700.50	1.00
111.19598	128.50568	128.00000	115.01250	100.09795	91.28273	84.95427	79.94459	75.68446	708.00	1.00
110.49821	128.15680	127.62556	114.92328	100.05434	91.25366	84.93246	79.92725	75.58910	708.17	1.00
38.87810	50.61398	84.30360	93.16429	89.17384	84.00000	79.49222	75.57504	71.96227	749.75	1.00
38.75477	50.41227	84.12917	93.07077	89.13023	83.97093	79.47041	75.55760	71.94772	749.92	1.00
28.58000	28.58535	29.59525	40.28366	57.74606	63.03789	63.77063	62.99778	61.48120	869.92	1.00
20.27242	28.39054	29.52509	40.18700	57.65890	62.97974	63.77202	62.96289	61.45213	870.25	1.00
18.55134	19.21688	21.46821	29.75267	47.76641	56.37492	58.77341	59.00000	58.14972	908.11	1.00
18.32144	19.08581	21.37654	29.65907	47.67936	56.31678	58.72980	58.96511	58.12064	908.45	1.00
8.58000	8.58131	8.64329	10.73208	21.78512	34.07123	41.74884	45.38034	46.80000	1038.24	1.00
8.27242	8.38659	8.56407	10.69043	21.65249	34.01524	41.70523	45.34545	46.77093	1038.57	1.00

FIGURE 13. MODEL PROFILE PARAMETER PRINTOUT AS PRINTED BY SUBROUTINE RCRD7 FOR THE PROFILE IN FIGURE 6.

HVAL09 T=00004 IS ON CR00060 USING 00029 BLKS R=0000

0001	120.000	98.000	80.000	68.000	56.000	48.000	47.500	47.000	46.800
0002	132.000	110.000	92.000	80.000	68.000	60.000	59.500	59.000	58.800
0003	144.000	122.000	104.000	92.000	80.000	72.000	71.500	71.000	70.800
0004	156.000	134.000	116.000	104.000	92.000	84.000	83.500	83.000	82.800
0005	168.000	146.000	128.000	116.000	104.000	96.000	95.500	95.000	94.800
0006	180.000	158.000	140.000	128.000	116.000	108.000	107.500	107.000	106.800
0007	192.000	170.000	152.000	140.000	128.000	120.000	119.500	119.000	118.800
0008	204.000	182.000	164.000	152.000	140.000	132.000	131.500	131.000	130.800
0009	216.000	194.000	176.000	164.000	152.000	144.000	143.500	143.000	142.800
0010	228.000	206.000	188.000	176.000	164.000	156.000	155.500	155.000	154.800
0011	240.000	218.000	200.000	188.000	176.000	168.000	167.500	167.000	166.800
0012	252.000	230.000	212.000	200.000	188.000	180.000	179.500	179.000	178.800
0013	264.000	242.000	224.000	212.000	200.000	192.000	191.500	191.000	190.800
0014	276.000	254.000	236.000	224.000	212.000	204.000	203.500	203.000	202.800
0015	288.000	266.000	248.000	236.000	224.000	216.000	215.500	215.000	214.800
0016	300.000	278.000	260.000	248.000	236.000	228.000	227.500	227.000	226.800
0017	312.000	290.000	272.000	260.000	248.000	240.000	239.500	239.000	238.800
0018	324.000	302.000	284.000	272.000	260.000	252.000	251.500	251.000	250.800
0019	336.000	314.000	296.000	284.000	272.000	264.000	263.500	263.000	262.800
0020	348.000	326.000	308.000	296.000	284.000	276.000	275.500	275.000	274.800
0021	360.000	338.000	320.000	308.000	296.000	288.000	287.500	287.000	286.800
0022	372.000	350.000	332.000	320.000	308.000	300.000	299.500	299.000	298.800
0023	384.000	362.000	344.000	332.000	320.000	312.000	311.500	311.000	310.800
0024	396.000	374.000	356.000	344.000	332.000	324.000	323.500	323.000	322.800
0025	408.000	386.000	368.000	356.000	344.000	336.000	335.500	335.000	334.800
0026	420.000	398.000	380.000	368.000	356.000	348.000	347.500	347.000	346.800
0027	432.000	410.000	392.000	380.000	368.000	360.000	359.500	359.000	358.800
0028	444.000	422.000	404.000	392.000	380.000	372.000	371.500	371.000	370.800
0029	456.000	434.000	416.000	404.000	392.000	384.000	383.500	383.000	382.800
0030	468.000	446.000	428.000	416.000	404.000	396.000	395.500	395.000	394.800
0031	1	10HELIUM							
0032	5.00	10.00	20.00	40.00	80.00	120.00	160.00	200.00	240.00
0033	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
0034	120.000	98.000	80.000	68.000	56.000	48.000	47.500	47.000	46.800
0035	131.811	109.911	91.811	79.811	67.811	59.811	59.311	58.811	58.611
0036	143.622	121.622	103.622	91.622	79.622	71.622	71.122	70.622	70.422
0037	155.433	133.433	115.433	103.433	91.433	83.433	82.933	82.433	82.233
0038	167.244	145.244	127.244	115.244	103.244	95.244	94.744	94.244	94.044
0039	179.055	157.055	139.055	127.055	115.055	107.055	106.555	106.055	105.855
0040	190.866	168.866	150.866	138.866	126.866	118.866	118.366	117.866	117.666
0041	202.677	180.677	162.677	150.677	138.677	130.677	130.177	129.677	129.477
0042	214.488	192.488	174.488	162.488	150.488	142.488	141.988	141.488	141.288
0043	226.299	204.299	186.299	174.299	162.299	154.299	153.799	153.299	153.099
0044	238.110	216.110	198.110	186.110	174.110	166.110	165.610	165.110	164.910
0045	249.921	227.921	209.921	197.921	185.921	177.921	177.421	176.921	176.721
0046	261.732	239.732	221.732	209.732	197.732	189.732	189.232	188.732	188.532
0047	273.543	251.543	233.543	221.543	209.543	201.543	201.043	200.543	200.343
0048	285.354	263.354	245.354	233.354	221.354	213.354	212.854	212.354	212.154
0049	297.165	275.165	257.165	245.165	233.165	225.165	224.665	224.165	223.965
0050	308.977	286.977	268.977	256.977	244.977	236.977	236.477	235.977	235.776
0051	320.788	298.788	280.788	268.788	256.788	248.788	248.288	247.788	247.588
0052	332.599	310.599	292.599	280.599	268.599	260.599	260.099	259.599	259.399
0053	344.410	322.410	304.410	292.410	280.410	272.410	271.910	271.410	271.210
0054	356.221	334.221	316.221	304.221	292.221	284.221	283.721	283.221	283.021
0055	368.032	346.032	328.032	316.032	304.032	296.032	295.532	295.032	294.832
0056	379.843	357.843	339.843	327.843	315.843	307.843	307.343	306.843	306.643
0057	391.654	369.654	351.654	339.654	327.654	319.654	319.154	318.654	318.454
0058	403.465	381.465	363.465	351.465	339.465	331.465	330.965	330.465	330.265
0059	415.276	393.276	375.276	363.276	351.276	343.276	342.776	342.276	342.076
0060	427.087	405.087	387.087	375.087	363.087	355.087	354.587	354.087	353.887
0061	438.898	416.898	398.898	386.898	374.898	366.898	366.398	365.898	365.698
0062	450.709	428.709	410.709	398.709	386.709	378.709	378.209	377.709	377.509
0063	462.520	440.520	422.520	410.520	398.520	390.520	390.020	389.520	389.320
0064	2	3HELIUM							
0065	5.00	10.00	20.00	40.00	80.00	120.00	160.00	200.00	240.00
0066	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

FIGURE 14. THE FIRST TWO SUBFILES OF MODEL PARAMETER INPUT FILE HVAL09
THE LINE NUMBERS ON THE LEFT ARE FOR REFERENCE AND ARE NOT PART
OF THE FILE

0067	120.000	98.000	80.000	68.000	56.000	48.000	47.500	47.000	46.800
0068	139.685	117.685	99.685	87.685	75.685	67.685	67.185	66.685	66.485
0069	159.370	137.370	119.370	107.370	95.370	87.370	86.870	86.370	86.170
0070	179.055	157.055	139.055	127.055	115.055	107.055	106.555	106.055	105.855
0071	198.740	176.740	158.740	146.740	134.740	126.740	126.240	125.740	125.540
0072	218.425	196.425	178.425	166.425	154.425	146.425	145.925	145.425	145.225
0073	238.110	216.110	198.110	186.110	174.110	166.110	165.610	165.110	164.910
0074	257.795	235.795	217.795	205.795	193.795	185.795	185.295	184.795	184.595
0075	277.480	255.480	237.480	225.480	213.480	205.480	204.980	204.480	204.280
0076	297.165	275.165	257.165	245.165	233.165	225.165	224.665	224.165	223.965
0077	316.850	294.850	276.850	264.850	252.850	244.850	244.350	243.850	243.650
0078	336.535	314.535	296.535	284.535	272.535	264.535	264.035	263.535	263.335
0079	356.221	334.220	316.220	304.220	292.220	284.220	283.720	283.220	283.020
0080	375.906	353.906	335.906	323.906	311.906	303.906	303.406	302.906	302.706
0081	395.591	373.591	355.591	343.591	331.591	323.591	323.091	322.591	322.391
0082	415.276	393.276	375.276	363.276	351.276	343.276	342.776	342.276	342.076
0083	434.961	412.961	394.961	382.961	370.961	362.961	362.461	361.961	361.761
0084	454.646	432.646	414.646	402.646	390.646	382.646	382.146	381.646	381.446
0085	474.331	452.331	434.331	422.331	410.331	402.331	401.831	401.331	401.131
0086	494.016	472.016	454.016	442.016	430.016	422.016	421.516	421.016	420.816
0087	513.701	491.701	473.701	461.701	449.701	441.701	441.201	440.701	440.501
0088	533.386	511.386	493.386	481.386	469.386	461.386	460.886	460.386	460.186
0089	553.071	531.071	513.071	501.071	489.071	481.071	480.571	480.071	479.871
0090	572.756	550.756	532.756	520.756	508.756	500.756	500.256	499.756	499.556
0091	592.441	570.441	552.441	540.441	528.441	520.441	519.941	519.441	519.241
0092	612.126	590.126	572.126	560.126	548.126	540.126	539.626	539.126	538.926
0093	631.811	609.811	591.811	579.811	567.811	559.811	559.311	558.811	558.611
0094	651.496	629.496	611.496	599.496	587.496	579.496	578.996	578.496	578.296
0095	671.181	649.181	631.181	619.181	607.181	599.181	598.681	598.181	597.981
0096	690.866	668.866	650.866	638.866	626.866	618.866	618.366	617.866	617.666
0097	2	HELIUM							
0098	5.00	10.00	20.00	40.00	80.00	120.00	160.00	200.00	240.00
0099	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

FIGURE 15. CONTINUATION OF THE MODEL PARAMETER INPUT FILE HVAL09 OF
FIGURE 14 SHOWING THE THIRD SUBFILE. THE LINE NUMBERS ON THE LEFT
ARE FOR REFERENCE AND ARE NOT PART OF THE FILE.

The first 30 lines of each sub-file are the maximum permissible tissue tensions in units of FSW (33 FSW = 1 ATA) in F8.3 format. Each column represents values for one halftime tissue and the tissue halftimes appear in the 32nd line in F7.2 format followed by the number of tissues in use in I9 format. If the number of tissues in use is less than 9 then only the left most tissues are used up to the maximum number by the MK 15/16 Decompression Model. Thus, if only 6 tissues are specified only the first 6 columns are meaningful. The sub-file must have numbers at all positions shown in Fig. 14. If certain tissues are not specified the values in the corresponding columns may be set to 0.0 or may contain any number since they will not be used. Subroutine RDIN7 always reads in all 9 columns of maximum permissible tissue tensions into array M, even if less than 9 tissues will be used.

The 31st line of each sub-file contains the Units Mode and Stop Depth Increment each in an I8 format followed by 12 alphanumeric characters which are the Inert Gas Label. Line 33 contains 9 Saturation-Desaturation Ratios in F7.2 format followed again by the number of tissues in I9 Format.

Subroutine RDIN7 will read the first 30 lines of each sub-file into array M then read the next 3 lines of data into the appropriate variables. The subroutine then compares the Units Mode and Depth Increment in the 31st line with the values specified by the calling program. A Units Mode of "1" means that the Stop Depth Increment is in units of feet of seawater (FSW) and a "2" means it is in units of meters of seawater (MSW) (no matter what the Stop Depth Increment the maximum tissue tensions are always in FSW). If a match with the specified Units Mode and Stop Depth Increment is not made, the next 33 lines are read. Subroutine RDIN7 continues reading in 33 line sub-files until a sub-file with the specified Depth Units and Stop Depth Increments is encountered. There is no limit to the number of sub-files which may be contained in the MPIF, however, if no match of Units Mode or Stop Depth Increment is made by the time the end of the file is encountered, an error will occur and the program will stop.

The MK 15/16 Decompression Model MPIFs each contain 3 sub-files. The first is for Stop Depth Increments of 10 fsw, the second for Stop Depth Increments of 3 MSW and the third in increments of 5 MSW. Tissue halftimes, the number of tissues, Saturation Desaturation Ratios and the Inert Gas Label are identical for all 3 sub-files. The purpose of having 3 sub-files was to conveniently print out tables in either Imperial or Metric Units once an algorithm has been developed. The Inert Gas Label is used to label tables and profiles and indicates for what inert gas or combination of inert gases the maximum tissue tension values were developed.

The MPIF could be generated by a text editor but in the case of the MK 15/16 Decompression Model a program was used to generate these files. This program will be presented later.

File Read In Procedure
(Lines 141 - 202)

In lines 145 and 146 the value of IMODE is established depending on whether or not a metric stop depth increment is desired. The Stop Depth Increment desired by the calling program is integerized as IDINC in line 147.

In line 153-155 the desired file (IFILE) is opened. If an error occurs IERR returns as a negative number then Subroutine FMPER prints the error message and the subroutine causes an immediate halt. If Subroutine FMPER is not used Subroutine RDIN7 will function as described but no error messages will be printed.

The DO loop beginning at Statement 175 (line 161) reads in the first 30 rows of the MPIF into array M. In lines 170-184 the Depth Units Mode, Stop Depth Increment, Inert Gas Label, tissue halftimes, number of tissues and the Saturation-Desaturation Ratios are read in. In lines 190 and 191 control is transferred back to Statement 175 (line 161) if a match is not made between the Specified Depth Units Mode and Stop Depth Increments and the values actually read in.

Once a match is made the input file is closed in line 195 and if no printout is desired then the subroutine is exited at line 201.

Model Parameter Printout Procedure
(Lines 214 - 238)

This procedure prints out the values of IFILE, IGAS, arrays HLFTM, SDR, and M and the values in Common Block BLDVL in the format shown in Fig. 16.

8:37 AM SUN., 10 JAN., 1982 TBLP7

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL09- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	120.000	98.000	80.000	68.000	56.000	48.000	47.500	47.000	46.800
20 FSW	132.000	110.000	92.000	80.000	68.000	60.000	59.500	59.000	58.800
30 FSW	144.000	122.000	104.000	92.000	80.000	72.000	71.500	71.000	70.800
40 FSW	156.000	134.000	116.000	104.000	92.000	84.000	83.500	83.000	82.800
50 FSW	168.000	146.000	128.000	116.000	104.000	96.000	95.500	95.000	94.800
60 FSW	180.000	158.000	140.000	128.000	116.000	108.000	107.500	107.000	106.800
70 FSW	192.000	170.000	152.000	140.000	128.000	120.000	119.500	119.000	118.800
80 FSW	204.000	182.000	164.000	152.000	140.000	132.000	131.500	131.000	130.800
90 FSW	216.000	194.000	176.000	164.000	152.000	144.000	143.500	143.000	142.800
100 FSW	228.000	206.000	188.000	176.000	164.000	156.000	155.500	155.000	154.800
110 FSW	240.000	218.000	200.000	188.000	176.000	168.000	167.500	167.000	166.800
120 FSW	252.000	230.000	212.000	200.000	188.000	180.000	179.500	179.000	178.800
130 FSW	264.000	242.000	224.000	212.000	200.000	192.000	191.500	191.000	190.800
140 FSW	276.000	254.000	236.000	224.000	212.000	204.000	203.500	203.000	202.800
150 FSW	288.000	266.000	248.000	236.000	224.000	216.000	215.500	215.000	214.800
160 FSW	300.000	278.000	260.000	248.000	236.000	228.000	227.500	227.000	226.800
170 FSW	312.000	290.000	272.000	260.000	248.000	240.000	239.500	239.000	238.800
180 FSW	324.000	302.000	284.000	272.000	260.000	252.000	251.500	251.000	250.800
190 FSW	336.000	314.000	296.000	284.000	272.000	264.000	263.500	263.000	262.800
200 FSW	348.000	326.000	308.000	296.000	284.000	276.000	275.500	275.000	274.800
210 FSW	360.000	338.000	320.000	308.000	296.000	288.000	287.500	287.000	286.800
220 FSW	372.000	350.000	332.000	320.000	308.000	300.000	299.500	299.000	298.800
230 FSW	384.000	362.000	344.000	332.000	320.000	312.000	311.500	311.000	310.800
240 FSW	396.000	374.000	356.000	344.000	332.000	324.000	323.500	323.000	322.800
250 FSW	408.000	386.000	368.000	356.000	344.000	336.000	335.500	335.000	334.800
260 FSW	420.000	398.000	380.000	368.000	356.000	348.000	347.500	347.000	346.800
270 FSW	432.000	410.000	392.000	380.000	368.000	360.000	359.500	359.000	358.800
280 FSW	444.000	422.000	404.000	392.000	380.000	372.000	371.500	371.000	370.800
290 FSW	456.000	434.000	416.000	404.000	392.000	384.000	383.500	383.000	382.800
300 FSW	468.000	446.000	428.000	416.000	404.000	396.000	395.500	395.000	394.800

BLOOD PARAMETERS

(PRESSURE IN FSW; 33 FSW=1 ATA)

PAC02	PH20	PVC02	PV02	AMBA02	PBOVP
1.50	0.00	2.30	2.00	0.00	0.000

FIGURE 16. HVAL09 ASCENT CRITERIA AS PRINTED OUT BY SUBROUTINE RDIN7.
THE VALUES IN COMMON BLOCK BLDVL ARE ALSO PRINTED OUT
BY THE SUBROUTINE.

PART 3

ASCENT CRITERIA

INTRODUCTION

The MK 15/16 Decompression Model described in Part 2 of this report is the algorithm for computing decompression tables. However, the decompression profiles may be varied by either changing the initialization values in Subroutine BLOC7 or by changing the ascent criteria in the Model Parameter Input File. As discussed during the description of Subroutine RDIN7, the Model Parameter Input File contains the ascent criteria (Maximum Permissible Tissue Tensions from the surface down to 30 stop depth increments), the units and magnitude of the Stop Depth Increment, an Inert Gas Label, up to nine tissue halftimes, the number of tissues and up to nine Saturation-Desaturation Ratios. Several different methods were used to compute the ascent criteria during the testing of the MK 15/16 Decompression Model. Program MVALU was used to generate the Model Parameter Input File containing the ascent criteria and Subroutine MCOMP is used by Program MVALU to actually compute the ascent criteria. Listings for Program MVALU and the three versions of Subroutine MCOMP used so far are given in Annex C. Version 1.0 of Subroutine MCOMP was used to generate the ascent criteria used in the current version of the Nitrogen/Oxygen and Helium/Oxygen Decompression Tables. Version 2.0 was used to generate the ascent criteria in MVAL 1, 2 and 3 and Version 2.1 to generate the ascent criteria in MVAL5. MVAL 1, 2, 3 and 5 were used to develop the first set of constant 0.7 ATA P_{O_2} in nitrogen decompression schedules as previously reported (1).

Program MVALU

This program allows creation of a new Model Parameter Input File, modification of existing files or listing of existing files. A listing of the program is found in Annex C-1. Figures 14 and 15 show the file format as it appears in mass storage. Three 33-line subfiles are expected but the program is capable of listing files containing only a single subfile as some of the early Model Parameter Input Files did. Both the input and output of files in Program MVALU is to a disk file.

Program MVALU uses Subroutine FMPEP to print out errors which may occur during file manipulation. A listing of this subroutine is given in Annex D for completeness and it will not be discussed further. Subroutine MCOMP which actually computes the ascent criteria will be discussed later. All other subroutines used by Program MVALU are Hewlett Packard RTE IV-B Operating System Subroutines and will not be discussed here. Their functions are only briefly described in the program listing.

Initialization and Option Select Procedure (Lines 145 - 175)

In lines 148-152 the device number of the terminal and line printer are established. Statement 40 (line 147) prints out a message asking for the desired option. Legal responses are "1", "2", or "6". Any other response will cause control to go back to Statement 40. Unless an error occurs, there

are only two ways to stop the program. That is by specifying option 6 at line 159 or 171. All normal exits from the program are from these two statements. Option 1 will produce only a listing of an existing file. If this option is selected control goes to Statement 50 (line 194) to get the file name and then Statement 53 (line 202) transfers control to the Printout Procedure beginning at line 465. Option 2 causes control to drop through to Statement 45 (line 168) where selection of one of three "Create" options is requested. If option "6" is selected, the program stops.

At line 168, a message is written to the terminal asking for one of 4 "Create" options. If one of the legal responses "3", "4", "5" or "6" is not selected, control goes back to Statement 45 where another option selection is requested. Option 3 will cause a new file to be created so no input file name is needed and line 172 transfers control to Statement 55 (line 211) to get an output file name. Option 4 will modify an existing file so the input and output file will be the same. Option 5 will need both an input file name and an output file name because it will use existing values in one file to create another. Both Options 4 and 5 cause control to go to Statement 50 to get the input file name. Note that Option 1 also ends up at Statement 50 from line 160.

Lines 194-198 ask for an input file name. Simply hitting a return will cause control to go back to Statement 40 if Option 1 had been initially selected and to Statement 45 if Option 4 or 5 had been selected to get a new option. Once an input file has been specified, line 202 will transfer control directly to the Printout Procedure if Option 1 had been selected. Option 4 requires no output file name since an existing file is being modified so line 206 causes the statements for getting the output file name to be skipped.

Lines 211-220 get the output file name and creates the output file for Options 3 and 5. If no file name is specified then control goes back to Statement 45 (line 168) to select a new option. If an error is encountered in line 218, IERR will be returned as a negative number and after the error message is printed by Subroutine FMPEP, control will go back to Statement 55 (line 211) to get another output file name.

If Option 3 has been selected then lines 230-269 which read in data from an input file are skipped. Option 3 will start out with the variables set to the values in the DATA Statements at lines 92 and 96.

Options 4 and 5 will need to have the input file read in first. Statement 58 (line 230) opens the input file and if an error is encountered, control will go back to Statement 50 (line 194) to get a new input file name. Lines 237-240 read in the first row of the file, which are the surfacing Maximum Permissible Tissue Tensions (Surfacing Tensions), into array STNSN. Nine values are read, even if they are not all used. Lines 245-249 position the file to the 31st record to get the Units Mode, Stop Depth Increment and Inert Gas Label. Lines 254-257 read the tissue halftimes and number of tissues from the 32nd record and lines 262-265 read the Saturation-Desaturation Ratios from the 33rd record. Line 269 closes the input file.

Statement 65 (line 273) displays the data read in from the file on the terminal and if this is not what was wanted, typing any response but "YES" at line 278 will cause control to go back to Statement 45 (line 168) to select a new option. If "YES" is entered then the program proceeds to the Variable Change Procedure.

Variable Change Procedure (Lines 295 - 335)

As currently written only the 1st, and 31st-33rd lines of the first subfile of the Model Parameter Input File are read in. All maximum permissible tissue tensions at depths below the surface are currently computed using only the first line of the first subfile as starting values.

Lines 298-327 allow changes to be made to the Inert Gas Label, Number of Tissues, Surfacing Tensions Tissue Halftime Values, Saturation-Desaturation Ratios and the Depth Multiplier (MULTP). (MULTP is used only by Version 1 of Subroutine MCOMP). Hitting a carriage return after any input is requested will retain the values originally displayed. In line 333 the user is asked if he is done. If more changes are desired or if the changes already made want to be reviewed, entering any response other than "YES" will transfer control back to Statement 70 (line 298). Once all changes are finished, entering a "YES" at line 334 will cause the program to drop through to compute the maximum permissible tissue tensions.

Maximum Permissible Tissue Tension Computation Procedure (Lines 348 - 376)

The DO Loop beginning at line 351 will compute 3 sets of ascent criteria, in 10 FSW, 3 MSW and 5 MSW increments. The Surfacing Tensions are put in the first row of the Model Parameter Input File Array (MTABLE) in lines 352 and 353 and the proper value of the Stop Depth Increment and ATMD established in lines 359-375. The tissue tensions in array MTABLE are always in units of FSW but the Stop Depth Increments may be in FSW or MSW. ATMD has a value of either 1.0 or 3.28084 and when multiplied by INCR will always give a depth increment in FSW. Subroutine MCOMP is called to actually compute the table of maximum tissue tensions.

File Output Procedure (Lines 388 - 454)

If option 4 has been selected an existing file will be replaced with a new one. In lines 392 to 396 the old file is eliminated by Subroutine PURGE and then a new file with the same name created. The input and output file

names are set equal to each other in lines 402 and 403 and the output file opened in line 402. If an error occurs control is transferred back to Statement 45 (line 168) where a new option may be specified.

Lines 412-453 write out the three subfiles contained in MTABLE to the output file in the format shown in Figures 14 and 15. Line 465 asks if a printout of the new files is wanted. If a "YES" is entered the file is rewound to the first record and control goes to Statement 175 (line 496) to print the file out. Any other response causes control to pass to Statement 165 (line 470) where the file is closed and control transferred back to the beginning of the program at Statement 40 (line 157) to select a new option.

Printout Procedure (Lines 479 - 531)

Option 1 enters this procedure at Statement 170 (line 484) while all other options enter the procedure at Statement 175 (line 496). Lines 484-488 open the Option 1 file for input and sets the input file name equal to the output file name. An error on opening the file passes control to Statement 50 (line 194) to get a new input file name. Lines 496-530 read in one subfile at a time from the specified input file and prints each one out before reading the next one. This was done this way because some of the earlier Model Parameter Input Files had only one subfile which could then be read and printed before an end of file is encountered and the program stops. Since only a very few files had only one subfile it was not deemed necessary to detect and trap the error but just let the program stop.

Table 2 shows the format for the printout of the first subfile of the Model Parameter Input File MVAL0. The format is identical to that shown in Fig. 16 which was output by MK 15/16 Decompression Model Subroutine RDIN7 with the exception that the Blood Parameters which are not part of the Model Parameter Input File are not printed by Program MVALU.

Subroutine MCOMP

There are 3 versions of this subroutine. Version 1.0 was used to compute the ascent criteria for the current version of the Nitrogen/Oxygen Decompression Tables and all versions of the Helium/Oxygen Decompression Tables. These tables will be described in forthcoming reports. Version 2.0 and 2.1 were used to compute the ascent criteria used for the Constant 0.7 ATA Oxygen Partial Pressure in Nitrogen Decompression Tables which have already been presented (1).

Version 1.0 (Annex C-2)

This version uses the first row of the Maximum Permissible Tissue Tension (Surfacing Tensions) as starting values and increments them linearly with increasing depth. The factor MULTP determines the rate of increase. The Surfacing Tensions and MULTP must be specified. ATMD will convert values of INCR given in meters to units of feet.

TABLE 2

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVALO - NITROGEN)

DEPTH	TISSUE HALF-TIMES					
	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR
10 FSW	104.000	98.000	72.000	58.000	52.000	51.000
20 FSW	125.699	107.223	88.514	71.921	64.738	63.537
30 FSW	148.899	127.312	105.404	85.920	77.465	76.049
40 FSW	172.226	147.426	122.237	99.812	90.071	88.439
50 FSW	195.442	167.413	138.935	113.568	102.544	100.696
60 FSW	218.490	187.241	155.485	127.190	114.890	112.828
70 FSW	241.357	206.906	171.891	140.687	127.119	124.845
80 FSW	264.049	226.415	188.162	154.068	139.242	136.757
90 FSW	286.574	245.778	204.308	167.343	151.267	148.572
100 FSW	308.942	265.003	220.336	180.520	163.202	160.299
110 FSW	331.163	284.100	236.257	193.606	175.055	171.945
120 FSW	353.246	303.079	252.076	206.608	186.831	183.516
130 FSW	375.200	321.944	267.801	219.532	198.536	195.016
140 FSW	397.033	340.705	283.438	232.383	210.174	206.451
150 FSW	418.752	359.367	298.993	245.165	221.750	217.825
160 FSW	440.363	377.974	314.469	257.883	233.267	229.141
170 FSW	461.872	396.418	329.871	270.539	244.729	240.402
180 FSW	483.284	414.816	345.204	283.138	256.139	251.612
190 FSW	504.605	433.135	360.470	295.683	267.499	262.773
200 FSW	525.838	451.378	375.674	308.175	278.811	273.888
210 FSW	546.987	469.549	390.817	320.618	290.079	284.959
220 FSW	568.057	487.652	403.903	333.013	301.303	295.987
230 FSW	589.051	505.689	420.934	345.363	312.487	306.975
240 FSW	609.971	523.663	435.912	357.669	323.631	317.924
250 FSW	630.820	541.576	450.839	369.934	334.737	328.837
260 FSW	651.602	559.431	465.718	382.159	345.808	339.713
270 FSW	672.319	577.230	480.550	394.345	356.843	350.555
280 FSW	692.973	594.975	495.337	406.495	367.844	361.364
290 FSW	713.567	612.668	510.081	418.608	378.813	372.141
300 FSW	734.101	630.310	524.782	430.687	389.751	382.888

Version 2.0
(Annex C-3)

This version of Subroutine MCOMP was used to compute the ascent criteria in the Model Parameter Input Files MVAL1, MVAL2, and MVAL3 of reference (1). The relationship used to compute the maximum tensions shown in line 10 of Annex C-3 was originally presented by Dwyer in reference (2). There is one slight difference, however, in that Dwyer's calculation assumed 100% Nitrogen. The maximum tensions thus computed were later multiplied by 0.79 by Workman (3) to get his table of M-values (Appendix E of reference (3)) for computing air tables. The relationship presented here does this in one step. Table 2 shows the Table of Maximum Permissible Tissue Tensions computed by this version of MCOMP using the Surfacing Tensions as presented in Appendix E of reference (3). The agreement between Table 2 and Appendix E of reference (3) is quite good, the small differences probably being due to rounding errors done during the computation of the values in Appendix E of reference (3).

Program Description

Version 2.0 of Subroutine MCOMP uses a Newton-Raphson iteration to solve the equation given in line 10 for M and by setting IPRNT equal to " 1" in line 88 all iteration variables will be printed. In this case, IPRNT was set to "0" so iteration values will not be printed unless convergence does not occur in 10 iterations. The nitrogen fraction is set to .79 in line 92. The DO Loops beginning at lines 97 and 98 will compute maximum tensions for 9 compartments at 30 depth increments. The surfacing ratio is computed in line 107. The Newton-Raphson iteration from lines 114-174 is basically the same as discussed with Subroutine UPDT7 so its function will not be covered in detail here. T represents the trial maximum tensions and the initial estimate given in line 123 is simply the depth ratio of the previous maximum tension times the new nitrogen tension. The depth ratio R is computed at Statement 230 (line 124) which is where the iteration reenters with its successive estimates of T. The Newton-Raphson null variable Y is the difference between the right and left sides of the equation given in line 10 and DY is its first derivative. After the iteration has finished, the appropriate element in MTABLE is set to the final value of T in line 174.

Version 2.1
(Annex C-4)

This version of MCOMP was used to compute the MVAL5 ascent criteria and the rationale behind the computation is given in reference (1). The computation is straight-forward, the Maximum Permissible Tissue Tension being given in Annex C-4 by line 57 for depths less than or equal to 80 FSW and by line 58 for depths greater than 80 FSW.

Ascent Criteria

Printouts of the ascent criteria for all the Model Parameter Input Files actually tested during development of the MK 15/16 Decompression Model are given in Annexes C-5, C-6 and C-7. The files used for schedule development using nitrogen as a diluent are MVAL 1, 2, and 3 (Annex C-6) and MVAL 5, 83, 92 and 94 (Annex C-7) which were all used with the E-E Version (Version 2) of Subroutines UPDT7 and STIM7, and VVAL09, 14 and 18 (Annex C-5) which were used with the E-L Version (Version 1) of these subroutines. All decompression schedules computed using the E-E Version of the Model had all values in Common Block BLDVL of Subroutine BLOC7 set to 0.0. The tables computed using the E-L Version used the values in Subroutine BLOC7 as presented in Annex B-1. MVAL 1, 2 and 3 were computed by Program MVALU using Version 2.0 of Subroutine MCOMP. MVAL5 was computed using Version 2.1 of Subroutine MCOMP. MVAL 83, 92, and 97 were constructed by modifying individual values in MVAL5 and cannot be directly computed from any set of initial assumptions.

All HVAL files (Annex C-5) and VVAL 09, 14 and 18 were created using Version 1.0 of Subroutine MCOMP. It should be noted that some of these files have the same Maximum Permissible Tissue Tensions and differ only in the number of tissues used and/or the Saturation-Desaturation Ratios.

Decompression Tables

To date, a complete set of Decompression Tables using MVAL5 have been published in reference (1). A complete set of tables using VVAL18 have been published in Chapter 16 of reference (4) which supercedes those computed using MVAL5 in reference (1). Reports describing tables computed with other sets of ascent criteria are forthcoming.

While one can compute any variety of tables using the computer programs described in this report, it must be again emphasized that the only conditions under which the MK 15/16 Decompression Model has been tested to date is using a constant PO_2 of 0.7 ATA in either a Nitrogen or Helium diluent. The E-L Model at present will not handle large changes in inspired oxygen tension which makes it unsuitable for computing air tables at present although this shortcoming is being worked out.

References

1. Thalmann, E.D. Testing of Decompression Algorithms for Use in The U.S. Navy Underwater Decompression Computer: Phase I. U.S. Navy Experimental Diving Unit Report 11-80.
2. Dwyer, J.V. Calculation of Repetitive Diving Decompression Tables. U.S. Navy Experimental Diving Unit Research Report 1-57.
3. Workman, R.D. Calculation of Decompression Schedules for Nitrogen-Oxygen and Helium-Oxygen Dives. U.S. Navy Experimental Diving Unit Research Report 6-65.
4. U.S. Navy Diving Manual, NAVSHIPS 0994-001-9010, Volume 2, Revision 1.

ANNEX A

MODEL INDEPENDENT
INPUT-OUTPUT
PROGRAM LISTINGS

ANNEX A-1

PROGRAM DMDB7
LISTING

```

0001 FTN4
0002 PROGRAM DMD87(3,99), 26 SEPT 82 VER 1.0
0003 C
0004 C
0005 C MODEL INDEPENDENT DECOMPRESSION PROFILE GENERATOR.
0006 C DECOMPRESSION MODEL WRITTEN IN 8 SUBROUTINES
0007 C
0008 C ACCEPTS PROFILE COORDINATE INPUTS FROM A PROFILE COORDINATE INPUT
0009 C FILE AND PRINTS OUT A DECOMPRESSION PROFILE ON THE LINE PRINTER.
0010 C
0011 C
0012 C
0013 C
0014 C
0015 C CDR EDWARD D. THALMANN (MC) USN
0016 C
0017 C
0018 C U.S. NAVY EXPERIMENTAL DIVING
0019 C UNIT
0020 C PANAMA CITY, FLORIDA 32407
0021 C
0022 C
0023 C
0024 C *****
0025 C
0026 C * VARIABLES *
0027 C
0028 C *****
0029 C
0030 C * VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0031 C OPERATING SYSTEM
0032 C
0033 C ATA "ATA" LABEL
0034 C BTMTIM DESCENT TIME INCLUDED IN "TIME"
0035 C CDEPTH CURRENT DEPTH (FSW OR MSW)
0036 C CF METRIC CONVERSION FACTOR
0037 C CFSTOP CALCULATE FIRST STOP?
0038 C CNTR POSITION IN MODEL PARAMETER FILE
0039 C CPO2 CONSTANT PARTIAL PRESSURE 02?
0040 C CSTOP COMPUTE STOP TIMES?
0041 C D PROFILE DEPTH ARRAY
0042 C *DAYTIM DATE-TIME ARRAY
0043 C DC PROFILE SUB-SEGMENT DEPTH CHANGE (FSW OR MSW)
0044 C DEPTH NEXT DEPTH (FSW OR MSW)
0045 C DFS DEPTH OF FIRST STOP (FSW OR MSW)
0046 C DFINC STOP DEPTH INCREMENTS (FSW OR MSW)
0047 C DONE DONE ENTERING CURRENT PROFILE?
0048 C FDEPTH FINAL DEPTH FOR ASCENTS (FSW OR MSW)
0049 C FN2 CURRENT INERT GAS FRACTION IN USE
0050 C GAS PROFILE INERT GAS TENSION ARRAY
0051 C GASLBL LABELS GAS TENSION AS "%" OR "ATA"
0052 C GASTEN GAS TENSION VALUE ARRAY
0053 C IGAS INERT GAS(ES) NAME(S)
0054 C *IPAR LOGICAL UNIT NUMBER ARRAY
0055 C IPRT PRINT MODEL PARAMETER INPUT FILE?
0056 C *ISES DUMMY VARIABLE
0057 C K CURRENT POSITION IN DIVE PROFILE ARRAYS
0058 C LB PROFILE COORDINATE INPUT FILE DEVICE NUMBER
0059 C LP DEVICE NUMBER FOR LINE PRINTER

```



```

0059 C      LSTOP      LAST STOP BEFORE SURFACING?
0060 C      LU         DEVICE NUMBER FOR TERMINAL
0061 C      METRIC     DEPTH AND RATE INPUTS IN METERS?
0062 C      MORE      ANOTHER DIVE PROFILE TO FOLLOW?
0063 C      MFIF      MODEL PARAMETER INPUT FILENAME
0064 C      NGAS      GAS TENSION ARRAY SUBSCRIPT
0065 C      NOCLIM     COMPUTE NO-DECOMPRESSION LIMIT?
0066 C      NOGSTP    DGN'T COMPUTE DECOMPERSSION STOPS ?
0067 C      NOPRNT    MODEL PROFILE PARAMETER OUTPUT NOT WANTED?
0068 C      OPTN      OPTION ARRAY
0069 C      PERCNT     "%" LABEL
0070 C      PO2       CURRENT OXYGEN PARTIAL PRESSURE (ATA)
0071 C      PRGID     PROFILE IDENTIFICATION LABEL
0072 C      R         DIVE PROFILE RATE ARRAY
0073 C      RATE      RATE OF CURRENT PROFILE SUB-SEGMENT (FSW OR MSW/MIN)
0074 C      T         ELAPSED TIME DIVE PROFILE ARRAY
0075 C      TC        TIME CHANGE OF CURRENT PROFILE SUB-SEGMENT (MIN)
0076 C      TIME      TIME AT CURRENT DEPTH (MIN)
0077 C      UFEET     OUTPUT LABEL FOR PROFILES IN FEET
0078 C      UMETER    OUTPUT LABEL FOR PROFILES IN METERS
0079 C      UNITS     DEPTH UNITS SWITCH
0080 C      ZT        DIVE PROFILE ZERO TIME ARRAY
0081 C
0082 C *****
0083 C
0084 C *****
0085 C
0086 C      *****
0087 C      * SUBROUTINES REQUIRED *
0088 C      *****
0089 C
0090 C
0091 C      DECOMPRESSION MODEL
0092 C
0093 C      BLOC7      INITIALIZES DATA IN COMMON BLOCK
0094 C      UPDT7      UPDATES MODEL OVER ONE PROFILE SUB-SEGMENT
0095 C      FRSP7      COMPUTES DEPTH OF FIRST STOP
0096 C      STIN7      COMPUTES STOP TIME AT A GIVEN DEPTH
0097 C      NLIN7      COMPUTES NO DECOMPRESSION TIME
0098 C      RCRD7      RECORDS OR OUTPUTS MODEL PARAMETERS
0099 C      RDIN7      READS IN MODEL PARAMETER INPUT FILE
0100 C      INIT7      INITIALIZES MODEL
0101 C
0102 C
0103 C      PROGRAM
0104 C
0105 C      * HEWLETT PACKARD RTE IV-B OPERATING SYSTEM SUBROUTINES
0106 C      AND FUNCTIONS
0107 C
0108 C      *FTIME     GETS DATE AND TIME FROM COMPUTER
0109 C      *PNPAR     PASSES LOGICAL UNIT # OF TERMINAL TO PROGRAM
0110 C      *LOGLU     LOGICAL UNIT # OF TERMINAL
0111 C      *LUTRU     LOGICAL UNIT # OF TERMINAL ON ERROR
0112 C
0113 C *****
0114 C
0115 C      MODEL INPUT VARIABLES
0116 C      THESE ARE THE ONLY VARIABLES SENT TO THE MODEL SUBROUTINES.
0117 C      THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL SUBROUTINES.
0118 C

```

```

0119      COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FH2,P02,DINC,CF
0120
0121
0122      LOGICAL CP02,CFSTOP,CSTIME,DONE,LSTOP,METRIC,NODSTF,NODLIM,BTMTIM
0123      DCUBLE PRECISION UFEET,UMETER
0124      INTEGER CNTR,OPTN(4),UNITS,FROID(20),DAYTIM(15)
0125      REAL ZT(100),T(100),D(100),R(100),GAS(100),IGAS(3),GASLBL(100)
0126      DIMENSION GASTSN(2,4),IPAR(5),MPIF(3)
0127      DATA ATA,IGAS,IPRT,LP,LB/4H ATA,3*4H      ,0.6,9/
0128      DATA PERCNT,UFEET,UMETER/4H %      ,6HFEET      ,6HMETERS/
0129
0130
0131      FORMAT('1 15A2')
0132      FORMAT(F11.2,F14.2,I10,I7,F9.2,A4)
0133      FORMAT(I4,' FOOT INCREMENT')
0134      FORMAT(I4,' METER INCREMENT')
0135      FORMAT(4X'ZERO TIME'3X'ELAPSED TIME'3X'DEPTH'3X'RATE'4X'GAS')
0136      FORMAT(/'PRINT MODEL INPUT PARAMETERS ? (1=YES 2=NO) ')
0137      FORMAT(3A2)
0138      FORMAT(20A2)
0139      FORMAT(/4X,20A2/)
0140      FORMAT(A1,I1,3A2)
0141      FORMAT(4X,15A2' DMD87')
0142      FORMAT(4X,3A2,'< "3A4" >')
0143      FORMAT(4X'PROGRAM DMD87 USING "I2" "A1"SW STOPS')
0144
0145      C *****
0146
0147      C          PROGRAM INITIALIZATION PROCEDURE
0148
0149      C *****
0150
0151      C      GET TIME AND DATE FROM RTE IV-B OPERATING SYSTEM INTO "DAYTIM".
0152
0153      C      CALL FTIME(DAYTIM)
0154
0155      C      ESTABLISH TERMINAL USED FOR PROGRAM CONTROL.
0156
0157      C      CALL RMPAR(IPAR)
0158      C      LU=IPAR(1)
0159      C      IF(LU.LE.1) LU=LUTRU(LU)
0160      C      IF(LU.LE.0) LU=LOGLU(ISES)
0161
0162      C      READ IN MODEL PARAMETER INPUT FILENAME, DEPTH UNITS,AND STOP
0163      C      DEPTH INCREMENT FROM PROFILE COORDINATE INPUT FILE DEVICE "LB".
0164
0165      C      READ (LB,22) MPIF
0166      C      WRITE(LU,22) MPIF
0167      C      READ (LB,*) UNITS,DINC
0168
0169      C      IF "UNITS" NOT 1 THEN DEPTH INPUTS WILL BE IN METERS.
0170
0171      C      METRIC=.FALSE.
0172      C      IF(UNITS.NE.1) METRIC=.TRUE.
0173      C      IF(.NOT.METRIC) WRITE(LU,3) DINC
0174      C      IF(METRIC) WRITE(LU,5) DINC
0175
0176      C      "CF" CONVERTS METERS TO FEET FOR METRIC INPUTS.
0177
0178      C      CF=1.0

```

```

0179      IF(METRIC) CF=1.0/0.3048
0180      C
0181      C      ASK IF MODEL PARAMETER PRINTOUT WANTED. IF IT IS THEN "IPRT" WILL
0182      C      BE 1 AND DATE, TIME PAGE HEADER PRINTED. RDIN7 RETURNS GAS LABEL
0183      C      "IGAS" AFTER READING DATA FROM THE MODEL INPUT PARAMETER FILE.
0184      C      RDIN7 WILL PRINTOUT MODEL INPUT PARAMETER FILE IF "IPRT" IS 1.
0185      C
0186      WRITE(LU,9)
0187      READ(LU,*) IPRT
0188      IF(IPRT.EQ.1) WRITE(LP,26) DAYTIM
0189      CALL RDIN7(LU,LP,MPIF,METRIC,IGAS,IPRT)
0190      C
0191      C
0192      C *****
0193      C
0194      C      END PROGRAM INITIALIZATION PROCEDURE
0195      C
0196      C *****
0197      C
0198      C
0199      C *****
0200      C
0201      C      PROFILE INITIALIZATION PROCEDURE
0202      C
0203      C *****
0204      C
0205      C      READ IN PROFILE IDENTIFIER.
0206      C
0207      C      200 READ(LB,23) PROID
0208      C
0209      C      READ IN INERT GAS FRACTIONS AND PARTIAL PRESSURES FROM THE
0210      C      PROFILE COORDINATE INPUT DEVICE "LB".
0211      C
0212      C      READ(LB,*) ((GASTSN(I,J),I=1,2),J=1,4)
0213      C
0214      C      INITIALIZE LOGICAL VARIABLES CONTROLLING FIRST STOP AND STOP TIME
0215      C      PROCEDURES. SET COUNTERS TO 1.
0216      C
0217      C      CFSTOP=.FALSE.
0218      C      CSTIME=.FALSE.
0219      C      CNTR=1
0220      C      K=1
0221      C
0222      C      READ IN INITIALIZATION DEPTH, FIRST NEW DEPTH, AND THE RATE
0223      C      THEN SKIP OVER PROFILE COORDINATE INPUT AT STATEMENT #210.
0224      C
0225      C      READ(LB,*) CDEPTH,DEPTH,RATE
0226      C      TIME=0.0
0227      C      GO TO 211
0228      C
0229      C *****
0230      C
0231      C      END PROFILE INITIALIZATION PROCEDURE
0232      C
0233      C *****
0234      C
0235      C
0236      C *****
0237      C
0238      C      PROFILE GENERATION AND UPDATE LOOP

```

```

0239 C
0240 C          EXIT LOOP ONLY WHEN "DONE" BECOMES TRUE.
0241 C
0242 C*****
0243 C
0244 C      READ IN PROFILE SEGMENT TIME,NEXT DEPTH AND RATE COORDINATES.
0245 C
0246 210  READ(LB,*) TIME,DEPTH,RATE
0247 C
0248 C      GIVE "RATE" PROPER SIGN.
0249 C
0250 211  RATE=ABS(RATE)
0251      IF(DEPTH.LT.CDEPTH) RATE=-RATE
0252 C
0253 C      READ IN OPTIONS AND GAS TENSION SUBSCRIPT, INITIALIZE OPTIONS.
0254 C
0255      READ(LB,25) OPTN(1),NGAS,(OPTN(I),I=2,4)
0256      NODSTP=.FALSE.
0257      LSTOP=.FALSE.
0258      DONE=.FALSE.
0259      BTMTIM=.FALSE.
0260      NODLIN=.FALSE.
0261 C
0262 C      FIRST OPTION MUST ALWAYS SPECIFY A GAS TENSION. IF NOT SKIP
0263 C      EXECUTION OF OPTIONS.
0264 C
0265      IF(OPTN(1).NE.1HF .AND. OPTN(1).NE.1HP) GO TO 216
0266 C
0267 C      SET UP GAS TENSIONS SPECIFIED BY "OPTN(1)" AND "NGAS".
0268 C
0269      IF(OPTN(1).EQ.1HP) CPO2=.TRUE.
0270      IF(OPTN(1).EQ.1HF) CPO2=.FALSE.
0271      IF(.NOT.CPO2) FN2=GASTSN(1,NGAS)
0272      IF(CPO2) P02=GASTSN(2,NGAS)
0273 C
0274 C      EXECUTE REST OF OPTIONS.
0275 C
0276      DO 214 I=2,4
0277      IF(OPTN(I).EQ.2HLS) LSTOP=.TRUE.
0278      IF(OPTN(I).EQ.2HTX) BTMTIM=.TRUE.
0279      IF(OPTN(I).EQ.2HND) NODLIN=.TRUE.
0280      IF(OPTN(I).EQ.2HFN) DONE=.TRUE.
0281      IF(OPTN(I).EQ.2HDX) NODSTP=.TRUE.
0282 214  CONTINUE
0283 C
0284 C      INITIALIZE MODEL PARAMETERS FIRST TIME THROUGH.
0285 C
0286 216  IF(K.EQ.1) CALL INIT7
0287 C
0288 C      ASCENTS ALWAYS CAUSE CHECK TO SEE IF DECOMPRESSION STOPS NEEDED.
0289 C      "CFSTOP" SET TO TRUE FOR ALL ASCENTS. IF "NODSTP" IS TRUE
0290 C      DECOMPRESSION STOPS WILL NOT BE COMPUTED AND ASCENT WILL GO
0291 C      DIRECTLY TO THE NEXT STOP WITHOUT ANY INTERVENING STOPS.
0292 C
0293      IF(RATE.LT.0.0 .AND. .NOT.NODSTP) CFSTOP=.TRUE.
0294 C
0295 C      IF "BTMTIM" IS TRUE THEN "TIME" INCLUDES DESCENT TIME. SUBTRACT
0296 C      DESCENT TIME FROM "TIME". TIMES LESS THAN 0.0 NOT ALLOWED.
0297 C
0298      IF(BTMTIM) TIME=AMAX1((TIME-T(K-1)),0.0)

```

```

0199 C
0300 C COMPUTE NO-DECOMPRESSION TIME IF "NODLIN" IS TRUE.
0301 C
0302 C IF(NODLIN) CALL NLIN7(TIME)
0303 C
0304 C RECORD PROFILE COORDINATES FOR THE FIRST SUB-SEGMENT.
0305 C STOP TIME COMPUTATION PROCEDURE REENTERS HERE.
0306 C
0307 220 D(K)=CDEPTH
0308 T(K)=TIME
0309 R(K)=RATE
0310 GAS(K)=FN2*100.
0311 GASLBL(K)=PERCNT
0312 IF(CP02) GAS(K)=P02
0313 IF(CP02) GASLBL(K)=ATA
0314 C
0315 C UPDATE MODEL PARAMETERS TO END OF FIRST SUB-SEGMENT, THEN RECORD.
0316 C
0317 RATE=0.0
0318 DC=0.0
0319 TC=TIME
0320 CALL UPDT7
0321 CALL RCRD7(0,CNTR,LP)
0322 C
0323 C IF ASCENDING ("CFSTOP" TRUE) BRANCH TO FIRST STOP DEPTH
0324 C COMPUTATION PROCEDURE. FIRST STOP PROCEDURE WILL SET "DEPTH" TO
0325 C THE DEPTH OF THE FIRST STOP AND SET "CSTIME" TO TRUE IF ANY STOPS
0326 C NEEDED. FIRST STOP PROCEDURE RETURNS TO NEXT STATEMENT (#230).
0327 C UPDATE "RATE" NOW BECAUSE FIRST STOP PROCEDURE NEEDS IT.
0328 C
0329 RATE=R(K)
0330 IF(CFSTOP) GO TO 300
0331 C
0332 C UPDATE MODEL PARAMETERS TO END OF SECOND SUB-SEGMENT THEN RECORD.
0333 C
0334 230 DC=DEPTH-CDEPTH
0335 TC=DC/RATE
0336 CALL UPDT7
0337 CALL RCRD7(0,CNTR,LP)
0338 C
0339 C RECORD PROFILE COORDINATES FOR SECOND SUB-SEGMENT.
0340 C
0341 D(K+1)=DEPTH
0342 T(K+1)=TC
0343 R(K+1)=0.0
0344 GAS(K+1)=GAS(K)
0345 GASLBL(K+1)=GASLBL(K)
0346 C
0347 C UPDATE POINTER "K" AND CURRENT DEPTH "CDEPTH" FOR NEXT SEGMENT.
0348 C
0349 CDEPTH=DEPTH
0350 K=K+2
0351 C
0352 C IF "CSTIME" IS TRUE BRANCH TO STOP TIME COMPUTATION PROCEDURE.
0353 C PROCEDURE CAUSES INPUT FROM PROFILE COORDINATE INPUT FILE TO
0354 C BE SKIPPED AND WILL RETURN TO STATEMENT 220. IF "LSTOP" IS TRUE
0355 C GO TO STOP TIME PROCEDURE TO COMPUTE LAST STOP TIME BEFORE
0356 C SURFACING.
0357 C
0358 IF(CSTIME.OR.LSTOP) GO TO 400

```

```

0359 C
0360 C IF DONE GO TO OUTPUT PROCEDURE. IF NOT GO BACK TO BEGINNING OF
0361 C LOOP.
0362 C
0363 C IF(DONE) GO TO 500
0364 C GO TO 210
0365 C
0366 C *****
0367 C
0368 C END OF PROFILE GENERATION AND UPDATE LOOP
0369 C
0370 C *****
0371 C
0372 C
0373 C *****
0374 C
0375 C FIRST STOP DEPTH COMPUTATION PROCEDURE
0376 C
0377 C IF STOPS REQUIRED BETWEEN CURRENT DEPTH AND NEXT DESIRED DEPTH
0378 C THIS PROCEDURE SETS "CSTIME" TO TRUE SO APPROPRIATE STOPS TIMES
0379 C AT PROPER DEPTH INCREMENTS WILL BE COMPUTED. THIS PROCEDURE
0380 C EXECUTES ONLY ONCE FOR EACH ASCENT.
0381 C
0382 C *****
0383 C
0384 C SET "FDEPTH" TO "DEPTH" AND COMPUTE DEPTH OF FIRST STOP (DFS).
0385 C
0386 C 300 CALL FRSP7(DFS)
0387 C FDEPTH=DEPTH
0388 C
0389 C IF DEPTH OF FIRST STOP (DFS) LESS THAN "DEPTH" NO STOPS NEEDED.
0390 C HOWEVER IF DEPTH IS 0.0 THERE IS ALWAYS A STOP AT "DINC" EVEN IF
0391 C IT IS 0.0 WHICH IT WILL BE FOR NO-DECOMPRESSION DIVES.
0392 C
0393 C IF(DFS.LE.DEPTH .AND. DEPTH.NE.0.0) GO TO 360
0394 C
0395 C SET "CSTIME" TRUE SO STOP TIMES WILL BE COMPUTED. SET DEPTH TO
0396 C FIRST STOP DEPTH (DFS) OR "DINC" WHICHEVER IS DEEPER.
0397 C
0398 C DEPTH=AMAX1(DFS,DINC)
0399 C CSTIME=.TRUE.
0400 C
0401 C SET "CFSTOP" TO FALSE SO WON'T COME BACK UNTIL THE NEXT ASCENT
0402 C OCCURS. THEN GO BACK TO PROFILE GENERATION AND UPDATE LOOP.
0403 C
0404 C 360 CFSTOP=.FALSE.
0405 C GO TO 230
0406 C
0407 C *****
0408 C
0409 C END FIRST STOP PROCEDURE
0410 C
0411 C *****
0412 C
0413 C
0414 C *****
0415 C
0416 C STOP TIME COMPUTATION PROCEDURE
0417 C
0418 C COMPUTES STOP TIMES AND THEN DECREMENTS DEPTH BY "DINC" UNTIL

```

```

0419 C      NEXT DESIRED DEPTH (FDEPTH) REACHED. AS LONG AS "CSTIME" IS TRUE
0420 C      THE INPUT FROM THE PROFILE COORDINATE INPUT FILE WILL BE SKIPPED.
0421 C      WHEN "FDEPTH" IS REACHED HAVING TAKEN ALL NECESSARY DECOMPRESSION
0422 C      STOPS THEN "CSTIME" IS SET TO FALSE. IF "LSTOP" IS TRUE THEN COME
0423 C      BACK ONE MORE TIME TO COMPUTE THE LAST STOP TIME BEFORE SURFACING.
0424 C
0425 C      PROCEDURE ALWAYS RETURNS TO STATEMENT #220.
0426 C
0427 C *****
0428 C
0429 C      IF WITHIN "DINC" OF "FDEPTH" A DIFFERENT PROCEDURE MUST BE USED.
0430 C
0431 C      400 IF((CDEPTH-FDEPTH).LE.DINC) GO TO 410
0432 C
0433 C      "TIME" IS STOP TIME AT "CDEPTH" BEFORE ASCENDING "DINC".
0434 C
0435 C      DEPTH=CDEPTH-DINC
0436 C      CALL STIM7(TIME,DEPTH)
0437 C
0438 C      RETURN TO PROFILE GENERATION AND UPDATE LOOP.
0439 C
0440 C      GO TO 220
0441 C
0442 C      IF "CSTIME" TRUE WE'RE NOT AT "FDEPTH" YET.
0443 C
0444 C      410 IF(CSTIME) GO TO 420
0445 C
0446 C      AT LAST DEPTH BEFORE SURFACING. SET "FDEPTH" TO THE SURFACE AND
0447 C      COMPUTE LAST STOP TIME. DECREMENT DEPTH BY "DINC" AND SET "CSTIME"
0448 C      TRUE SO MODEL PARAMETERS WILL BE RECORDED EVERY INCREMENT EVEN
0449 C      THOUGH STOP TIMES WILL BE 0.0. "LSTOP" SET TO FALSE BECAUSE WE
0450 C      DON'T WANT TO COME BACK AGAIN WHEN SURFACE REACHED.
0451 C
0452 C      FDEPTH=0.0
0453 C      CALL STIM7(TIME,FDEPTH)
0454 C      DEPTH=CDEPTH-DINC
0455 C      CSTIME=.TRUE.
0456 C      LSTOP=.FALSE.
0457 C      GO TO 220
0458 C
0459 C      LAST STOP TIME COMPUTED. NEXT DEPTH IS "FDEPTH".
0460 C
0461 C      420 DEPTH=FDEPTH
0462 C      CALL STIM7(TIME,FDEPTH)
0463 C
0464 C      SET "CSTIME" TO FALSE SO WON'T COME BACK UNLESS "LSTOP" IS TRUE.
0465 C
0466 C      CSTIME=.FALSE.
0467 C      GO TO 220
0468 C
0469 C *****
0470 C
0471 C      END STOP TIME PROCEDURE
0472 C
0473 C *****
0474 C
0475 C *****
0476 C *****
0477 C
0478 C      PROFILE OUTPUT PROCEDURE

```

```

0479 C
0480 C*****
0481 C
0482 C      COMPUTE ZERO TIME VALUES FROM ELAPSED TIME VALUES.
0483 C
0484 500    ZT(1)=0.0
0485      DO 510 I=2,K-1
0486 510    ZT(I)=ZT(I-1)+T(I)
0487 C
0488 C      OUTPUT MODEL PROFILE PARAMETERS ? (YES OR NO)
0489 C
0490      READ(LB,22) NOPRNT
0491 C
0492 C      OUTPUT DATE,TIME,AND STOP DEPTH INCREMENT HEADER.
0493 C
0494      WRITE(LP,1) DAYTIM
0495      IF(.NOT.METRIC) WRITE(LP,42) DINC,UFEET
0496      IF(METRIC) WRITE(LP,42) DINC,UMETER
0497 C
0498 C      WRITE OUT PROFILE IDENTIFIER,MODEL PARAMETER INPUT FILENAME AND
0499 C      INERT GAS NAME.
0500 C
0501      WRITE(LP,41) MPIF,IGAS
0502      WRITE(LP,24) PROID
0503      WRITE(LP,6)
0504 C
0505 C      WRITE OUT DIVE PROFILE.
0506 C
0507      DO 565 I=1,K-1
0508 565    WRITE(LP,2) ZT(I),T(I),D(I),R(I),GAS(I),GASLBL(I)
0509 C
0510 C      IF MODEL PARAMETERS NOT WANTED SKIP REST OF OUTPUT ROUTINE.
0511 C
0512      IF(NOPRNT.EQ.2HNO) GO TO 575
0513 C
0514 C      OUTPUT DATE,TIME,AND STOP DEPTH INCREMENT HEADER.
0515 C
0516      WRITE(LP,1) DAYTIM
0517      IF(.NOT.METRIC) WRITE(LP,42) DINC,UFEET
0518      IF(METRIC) WRITE(LP,42) DINC,UMETER
0519 C
0520 C      WRITE OUT PROFILE IDENTIFIER, MODEL PARAMETER INPUT FILENAME
0521 C      AND INERT GAS(ES) NAME(S).
0522 C
0523      WRITE(LP,41) MPIF,IGAS
0524      WRITE(LP,24) PROID
0525 C
0526 C      WRITE OUT MODEL PROFILE PARAMETERS.
0527 C
0528      CALL RCRD7(1,CNTR,LP)
0529 C
0530 C      IF ANOTHER PROFILE FOLLOWS GO BACK TO PROFILE GENERATION AND
0531 C      UPDATE LOOP. IF NOT,STOP PROGRAM AFTER FORM FEEDING LINE PRINTER.
0532 C
0533 575    READ(LB,22) MORE
0534      IF(MORE.EQ.2HYE) GO TO 200
0535      WRITE(LP,1)
0536      STOP
0537      END
0538      END*

```


ANNEX A-2

PROGRAM TBLP7
LISTING

// PRECEDING PAGE BLANK-NOT FILMED

4TBLP7 T=00004 IS ON CR00012 USING 00122 BLKS R=0000

```
0001 FTN4
0002 PROGRAM TBLP7<3,99>, 26 SEPT 82 VER 1.1
0003 C
0004 C
0005 C MODEL INDEPENDENT DECOMPRESSION TABLE COMPUTATION PROGRAM.
0006 C DECOMPRESSION MODEL WRITTEN IN 7 SUBROUTINES
0007 C
0008 C ACCEPTS PROFILE COORDINATE INPUTS FROM A PROFILE COORDINATE INPUT
0009 C FILE AND PRINTS OUT DECOMPRESSION TABLES IN U.S. NAVY FORMAT ON
0010 C THE LINE PRINTER.
0011 C
0012 C
0013 C
0014 C
0015 C
0016 C
0017 C
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C
0024 C
0025 C
0026 C
0027 C *****
0028 C *****
0029 C * VARIABLES *
0030 C *****
0031 C
0032 C * VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0033 C OPERATING SYSTEM
0034 C
0035 C ASTIM TOTAL TIME OF ASCENT (MIN)
0036 C BTMAX MAXIMUM PERMISSABLE BOTTOM TIME (MIN)
0037 C BTMTIM DESCENT TIME INCLUDED IN "TIME"?
0038 C CDEPTH CURRENT DEPTH (FSW OR MSW)
0039 C CF METRIC CONVERSION FACTOR
0040 C CFSTOP CALCULATE FIRST STOP?
0041 C CONC OXYGEN TENSION FOR PRINTOUT
0042 C CONLBL OXYGEN TENSION LABELS FOR PRINTOUT
0043 C CPO2 CONSTANT PARTIAL PRESSURE O2?
0044 C CSTIME COMPUTE STOP TIMES?
0045 C D PROFILE DEPTH ARRAY
0046 C *DAYTIM DATE TIME ARRAY
0047 C DC PROFILE SUB-SEGMENT DEPTH CHANGE (FSW OR MSW)
0048 C DEPTH NEXT DEPTH (FSW OR MSW)
0049 C DFS DEPTH OF FIRST STOP (FSW OR MSW)
0050 C DINC STOP DEPTH INCREMENTS (FSW OR MSW)
0051 C DONE DONE ENTERING CURRENT PROFILE?
0052 C DSTOPS DEPTHS OF DECOMPRESSION STOPS (FSW OR MSW)
0053 C FDEPTH FINAL DEPTH FOR ASCENTS (FSW OR MSW)
0054 C FN2 CURRENT INERT GAS FRACTION IN USE
0055 C FULBUF "IPRO" BUFFER FULL?
0056 C GAS PROFILE INERT GAS TENSION ARRAY
0057 C GASTSN GAS TENSION VALUE ARRAY
```

0058	C	ICHNG	BOTTOM DEPTH OF PROFILE GROUP BEING PRINTED
0059	C	ICONC	POINTS TO P02 OR F02 LABELS IN "CONLBL"
0060	C	IGAS	INERT GAS(ES) NAME(S)
0061	C	ILBL	POINTS TO UNITS OR SPECIFICATION IN "CONLBL"
0062	C	*IPAR	LOGICAL UNIT NUMBER ARRAY
0063	C	IPRO	DECOMPRESSION PROFILE ARRAY
0064	C	IPRT	PRINT MODEL PARAMETER INPUT FILE?
0065	C	IRATE	RATE SPECIFIED ON FIRST PROFILE (FSW OR MSW/MIN)
0066	C	*ISES	DUMMY VARIABLE
0067	C	ISTOP	STOP DEPTH AT CURRENT "IPRO" POSITION (FSW OR MSW)
0068	C	K	CURRENT POSITION IN DIVE PROFILE ARRAYS
0069	C	LB	PROFILE COORDINATE INPUT FILE DEVICE NUMBER
0070	C	LP	DEVICE NUMBER FOR LINE PRINTER
0071	C	LSTOP	LAST STOP BEFORE SURFACING?
0072	C	LU	DEVICE NUMBER FOR TERMINAL
0073	C	MAXPRO	MAXIMUM NUMBER OF PROFILES PER PAGE.
0074	C	METRIC	DEPTH AND RATE INPUTS IN METERS?
0075	C	MORE	DO ANOTHER DIVE PROFILE?
0076	C	MPIF	MODEL PARAMETER INPUT FILENAME
0077	C	NGAS	GAS TENSION ARRAY, "GASTSN", SUBSCRIPT
0078	C	NLINE	POINTS TO PROPER STATEMENT NUMBER FOR PRINTOUT
0079	C	NODLIM	COMPUTE NO-DECOMPRESSION LIMIT?
0080	C	NODSTP	DON'T COMPUTE DECOMPRESSION STOPS ?
0081	C	NORCRD	DON'T RECORD DIVE PROFILE ?
0082	C	NPRO	NUMBER OF PROFILES RECORDED IN "IPRO".
0083	C	NSTOP	MAXIMUM NUMBER OF STOPS ALLOWED BY PRINTOUT FORMAT
0084	C	OPIN	OPTION ARRAY
0085	C	P02	CURRENT OXYGEN PARTIAL PRESSURE (ATA)
0086	C	PROFL1	FIRST PROFILE TO BE READ IN?
0087	C	PROID	PROFILE IDENTIFICATION LABEL
0088	C	R	DIVE PROFILE RATE ARRAY
0089	C	RATE	RATE OF CURRENT PROFILE SUB-SEGMENT (FSW OR MSW/MIN)
0090	C	T	ELAPSED TIME DIVE PROFILE ARRAY
0091	C	TC	TIME CHANGE OF CURRENT PROFILE SUB-SEGMENT (MIN)
0092	C	TDIMAX	MAXIMUM PERMISSABLE TOTAL DIVE TIME (MIN)
0093	C	TFS	ASCENT TIME TO FIRST STOP (MIN)
0094	C	TIME	TIME AT CURRENT DEPTH (MIN)
0095	C	TMIN	WHOLE MINUTES PORTION OF TIMES
0096	C	TSEC	WHOLE SECONDS PORTION OF TIMES
0097	C	UFEET	FEET LABEL
0098	C	ULBL	DEPTH UNITS LABEL FOR PRINTOUT
0099	C	UMETER	METERS LABEL
0100	C	UNITS	DEPTH UNITS INDICATOR (1=FSW,2=MSW)
0101	C	ZT	DIVE PROFILE ZERO TIME ARRAY
0102	C		
0103	C	*****	
0104	C		
0105	C	*****	
0106	C		
0107	C		
0108	C		
0109	C		
0110	C		
0111	C		
0112	C		
0113	C		
0114	C		
0115	C		
0116	C		
0117	C		

* SUBROUTINES REQUIRED *

DECOMPRESSION MODEL

BLOC7	INITIALIZES DATA IN COMMON BLOCK
UPDT7	UPDATES MODEL OVER ONE PROFILE SUB-SEGMENT
FRSP7	COMPUTES DEPTH OF FIRST STOP
STIN7	COMPUTES STOP TIME AT A GIVEN DEPTH

```

0118 C      NLIM7   COMPUTES NO DECOMPRESSION TIME
0119 C      RDIN7   READS IN MODEL PARAMETER INPUT FILE
0120 C      INIT7   INITIALIZES MODEL

0122 C
0123 C      PROGRAM
0124 C
0125 C      * HEWLETT PACKARD RTE IV-B OPERATING SYSTEM SUBROUTINES
0126 C      AND FUNCTIONS.
0127 C
0128 C      *FTIME   GETS DATE AND TIME FROM COMPUTER
0129 C      *RMPAR   PASSES LOGICAL UNIT # OF TERMINAL TO PROGRAM
0130 C      *LOGLU   LOGICAL UNIT # OF TERMINAL
0131 C      *LUTRU   LOGICAL UNIT # OF TERMINAL ON ERROR
0132 C
0133 C *****
0134 C
0135 C      MODEL INPUT PARAMETERS
0136 C      THIS IS THE ONLY DATA TRANSFERRED TO THE MODEL SUBROUTINES.
0137 C      THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL SUBROUTINES.
0138 C
0139 C      COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF
0140 C
0141 C
0142 C      LOGICAL CP02,CFSTOP,CSTIME,DONE,LSTOP,METRIC,NODSTP,PROFL1,FULBUF
0143 C      LOGICAL MODLIN,STMTIM,NORCRD
0144 C      DOUBLE PRECISION UFEET,UMETER,ULBL
0145 C      INTEGER IPAR(5),MPIF(3),PROID(20),DAYTIM(15)
0146 C      INTEGER DSTOPS(15),IPRO(24,26),OPTN(4),UNITS
0147 C      REAL ZT(100),T(100),D(100),R(100),GAS(100),IGAS(3)
0148 C      REAL CONLBL(2,2),GASTSN(2,4)
0149 C      DATA CONLBL,DSTOPS/4H ATA,4HZ ,4H P02,4H F02,15*0/
0150 C      DATA IGAS,IPRO,IPRT,LP,LP,MAXPRO/3*4H ,624*0,0,9,6,25/
0151 C      DATA NPRO,NSTOP,PROFL1,NORCRD/0,15,.TRUE.,.FALSE./
0152 C      DATA UFEET,UMETER/6HFEET ,6HMETERS/
0153 C
0154 3      FORMAT(I4," FOOT INCREMENT")
0155 5      FORMAT(I4," METER INCREMENT")
0156 9      FORMAT(/"PRINT MODEL INPUT PARAMETERS ? (1=YES 2=NO) ")
0157 22     FORMAT(3A2)
0158 25     FORMAT(A1,I1,3A2)
0159 26     FORMAT(4X,15A2" TBLP7")
0160 42     FORMAT(" :4X,15A2" TBLP7 "3A2 ("A6")"/)
0161 43     FORMAT(
0162 " :4X"DEPTH 8TM TM TO"T39"DECOMPRESSION STOPS ("A1
0163 "SW)"T83"TOTAL"/
0164 " :4X"("A1"SW) TIM FIRST"T43"STOP TIMES (MIN)"T83
0165 "ASCNT"/T13 "(M) STOP"T83"TIME"/" :6X,T17
0166 "M:S)"I3,14I4,2X,"M:S)"/)
0167 44     FORMAT(" :")
0168 46     FORMAT(" :6X,79*")
0169 47     FORMAT("1")
0170 48     FORMAT(" :6X,F4.2,A4" FIXED"A4" IN "3A4,3X"DESCENT RATE"13,1X,A1
0171 " PM ASCENT RATE"13,1X,A1"PM"/)
0172 50     FORMAT(" :6X,13,14,13," :",211,55X, 14,14," :",211)
0173 51     FORMAT(" :6X,13,14,13," :",211,51X, 214,14," :",211)
0174 52     FORMAT(" :6X,13,14,13," :",211,47X, 314,14," :",211)
0175 53     FORMAT(" :6X,13,14,13," :",211,43X, 414,14," :",211)
0176 54     FORMAT(" :6X,13,14,13," :",211,39X, 514,14," :",211)
0177 55     FORMAT(" :6X,13,14,13," :",211,35X, 614,14," :",211)

```

```

0178 56 FORMAT(" :6X,13,14,13,":",211,31X, 714,14,":",211)
0179 57 FORMAT(" :6X,13,14,13,":",211,27X, 814,14,":",211)
0180 58 FORMAT(" :6X,13,14,13,":",211,23X, 914,14,":",211)
0181 59 FORMAT(" :6X,13,14,13,":",211,19X,1014,14,":",211)
0182 60 FORMAT(" :6X,13,14,13,":",211,15X,1114,14,":",211)
0183 61 FORMAT(" :6X,13,14,13,":",211,11X,1214,14,":",211)
0184 62 FORMAT(" :6X,13,14,13,":",211, 7X,1314,14,":",211)
0185 63 FORMAT(" :6X,13,14,13,":",211, 3X,1414,14,":",211)
0186 64 FORMAT(" :6X,13,14,13,":",211, 13,1414,14,":",211)
0187 C
0188 C *****
0189 C
0190 C PROGRAM INITIALIZATION PROCEDURE
0191 C
0192 C *****
0193 C
0194 C
0195 C GET TIME AND DATE FROM RTE IV-B OPERATING SYSTEM INTO "DAYTIM".
0196 C
0197 C CALL FTIME(DAYTIM)
0198 C
0199 C ESTABLISH TERMINAL USED FOR PROGRAM CONTROL.
0200 C
0201 C CALL RMPAR(IPAR)
0202 C LU=IPAR(1)
0203 C IF(LU.LE.1) LU=LUTRUK(LU)
0204 C IF(LU.LE.0) LU=LOGLUK(1SES)
0205 C
0206 C READ IN MODEL PARAMETER INPUT FILE NAME, DEPTH UNITS, AND STOP
0207 C DEPTH INCREMENT FROM PROFILE COORDINATE INPUT FILE DEVICE "LB".
0208 C
0209 C READ (LB, 22) MPIF
0210 C WRITE(LU, 22) MPIF
0211 C READ (LB,*) UNITS,DINC
0212 C
0213 C IF "UNITS" NOT 1 THEN DEPTH INPUT WILL BE IN METERS.
0214 C
0215 C METRIC=.FALSE.
0216 C IF(UNITS.NE.1) METRIC=.TRUE.
0217 C IF(.NOT.METRIC) WRITE(LU,3) DINC
0218 C IF(METRIC) WRITE(LU,5) DINC
0219 C
0220 C "CF" CONVERTS METERS TO FEET FOR METRIC INPUTS.
0221 C
0222 C CF=1.0
0223 C IF(METRIC) CF=1.0/0.3048
0224 C
0225 C ASK IF MODEL PARAMETER PRINTOUT WANTED. IF IT IS THEN "IPRT" WILL
0226 C BE 1 AND DATE, TIME PAGE HEADER PRINTED. RDIN7 RETURNS GAS LABEL
0227 C "IGAS" AFTER READING DATA FROM THE MODEL INPUT PARAMETER FILE.
0228 C RDIN7 WILL PRINTOUT MODEL INPUT PARAMETER FILE IF "IPRT" IS 1.
0229 C
0230 C WRITE(LU,9)
0231 C READ(LU,*) IPRT
0232 C IF(IPRT.EQ.1) WRITE(LP,26) DAYTIM
0233 C CALL RDIN7(LU,LP,MPIF,METRIC,IGAS,IPRT)
0234 C
0235 C COMPUTE STOP DEPTHS FOR LATER TABLE PRINTOUTS.
0236 C
0237 C DSTOPS(1)=NSTOP*DINC

```

```

0239      DO 100 I=2,NSTOP
0239 100  DSTOPS(I)=DSTOPS(I-1)-DINC
0240      C
0241      C      SET VALUES FOR MAXIMUM TOTAL DIVE AND BOTTOM TIMES.
0242      C
0243      BTMAX=365.
0244      TOTMAX=180.0
0245      C
0246      C *****
0247      C
0248      C      END PROGRAM INITIALIZATION
0249      C
0250      C *****
0251      C
0252      C
0253      C *****
0254      C
0255      C      PROFILE INITIALIZATION PROCEDURE
0256      C
0257      C *****
0258      C
0259      C      SKIP PROFILE IDENTIFIER, NOT NEEDED.
0260      C
0261      C      200  READ(LB)
0262      C
0263      C      READ IN INERT GAS FRACTIONS AND PARTIAL PRESSURES FROM THE PROFILE
0264      C      COORDINATE INPUT DEVICE "LB" ON THE FIRST PROFILE ONLY. SPACE PAST
0265      C      THIS INPUT ON ALL OTHER PROFILES. "PROFL1" SET TRUE IN DATA
0266      C      STATEMENT.
0267      C
0268      C      IF(PROFL1) READ(LB,*)((GASTSN(I,J),I=1,2),J=1,4)
0269      C      IF(.NOT.PROFL1) READ(LB)
0270      C
0271      C      INITIALIZE LOGICAL VARIABLES CONTROLLING FIRST STOP AND STOP TIME
0272      C      PROCEDURES. SET PROFILE ARRAY SUBSCRIPT TO 1.
0273      C
0274      C      CFSTOP=.FALSE.
0275      C      CSTIME=.FALSE.
0276      C      K=1
0277      C
0278      C      READ IN INITIALIZATION DEPTH, FIRST NEW DEPTH, AND THE RATE THEN
0279      C      SKIP OVER THE PROFILE COORDINATE INPUT AT STATEMENT #210. THE RATE
0280      C      SPECIFIED HERE WILL BE USED FOR ALL SUBSEQUENT PROFILES. "PROFL1"
0281      C      SET TO FALSE AND NO FURTHER RATES WILL BE ASSIGNED TO "IRATE"
0282      C      UNLESS THE PROGRAM IS RESTARTED.
0283      C
0284      C      READ(LB,*) CDEPTH,DEPTH,RATE
0285      C      TIME=0.0
0286      C      IF(PROFL1) IRATE=RATE
0287      C      PROFL1=.FALSE.
0288      C      GO TO 211
0289      C
0290      C *****
0291      C
0292      C      END PROFILE INITIALIZATION PROCEDURE
0293      C
0294      C *****
0295      C
0296      C
0297      C *****

```

AD-A125 064


COMPUTER ALGORITHMS USED IN COMPUTING THE MK 15/16
CONSTANT 07 ATA OXYGEN..(U) NAVY EXPERIMENTAL DIVING
UNIT PANAMA CITY FL E D THALMANN JAN 83 NEDU-1-83


23

UNCLASSIFIED

F/G 6/19

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A


```

0298 C
0299 C           PROFILE GENERATION AND UPDATE LOOP
0300 C
0301 C           EXIT LOOP ONLY WHEN "DONE" BECOMES TRUE.
0302 C
0303 C*****
0304 C
0305 C       READ TIME AND NEXT DEPTH COORDINATES ONLY, IGNORE RATE.
0306 C
0307 210  READ(LB,*) TIME,DEPTH
0308 C
0309 C       "RATE" ALWAYS SET TO "IRATE" WHICH WAS SPECIFIED IN FIRST PROFILE.
0310 C
0311 C       RATE=IRATE
0312 C
0313 C       GIVE RATE PROPER SIGN.
0314 C
0315 211  RATE=ABS(RATE)
0316 C       IF(DEPTH.LT.CDEPTH) RATE=-RATE
0317 C
0318 C       READ IN OPTIONS AND GAS TENSION ARRAY SUBSCRIPT.
0319 C
0320 C       READ(LB,25) OPTN(1),NGAS,(OPTN(1),I=2,4)
0321 C
0322 C       INITIALIZE VARIABLES SET BY OPTIONS.
0323 C
0324 C       NODSTP=.FALSE.
0325 C       LSTOP=.FALSE.
0326 C       DONE=.FALSE.
0327 C       BTNTIM=.FALSE.
0328 C       NODLIM=.FALSE.
0329 C
0330 C       FIRST OPTION MUST ALWAYS SPECIFY A GAS TENSION. IF IT DOESN'T THEN
0331 C       SKIP EXECUTION OF OPTIONS.
0332 C
0333 C       IF(OPTN(1).NE.1HP .AND. OPTN(1).NE.1HF) GO TO 216
0334 C
0335 C       SET UP GAS TENSIONS SPECIFIED BY "OPTN(1)" AND "NGAS".
0336 C
0337 C       IF(OPTN(1).EQ.1HP) CP02=.TRUE.
0338 C       IF(OPTN(1).EQ.1HF) CP02=.FALSE.
0339 C       IF(.NOT.CP02) PN2=GASTSN(1,NGAS)
0340 C       IF(CP02) P02=GASTSN(2,NGAS)
0341 C
0342 C       EXECUTE REST OF OPTIONS.
0343 C
0344 C       DO 214 I=1,4
0345 C       IF(OPTN(I).EQ.2HLS) LSTOP=.TRUE.
0346 C       IF(OPTN(I).EQ.2HTX) BTNTIM=.TRUE.
0347 C       IF(OPTN(I).EQ.2HND) NODLIM=.TRUE.
0348 C       IF(OPTN(I).EQ.2HFN) DONE=.TRUE.
0349 C       IF(OPTN(I).EQ.2HDX) NODSTP=.TRUE.
0350 214  CONTINUE
0351 C
0352 C       INITIALIZE MODEL PARAMETERS FIRST TIME THROUGH
0353 C
0354 216  IF(K.EQ.1) CALL INIT7
0355 C
0356 C       ASCENTS ALWAYS CAUSE CHECK TO SEE IF DECOMPRESSION STOPS NEEDED.
0357 C       "CFSTOP" SET TO TRUE FOR ALL ASCENTS. IF "NODSTP" IS TRUE

```

```

0358 C   DECOMPRESSION STOPS WILL NOT BE COMPUTED AND ASCENT WILL GO
0359 C   DIRECTLY TO THE NEXT DEPTH WITHOUT ANY INTERVENING STOPS.
0360 C
0361 C   IF((RATE.LT.0.0).AND.(.NOT.MODSTP)) CFSTOP=.TRUE.
0362 C
0363 C   IF "BTMTIN" IS TRUE THEN "TIME" INCLUDES DESCENT TIME. SUBTRACT
0364 C   DESCENT TIME FROM "TIME". TIMES LESS THAN 0.0 NOT ALLOWED.
0365 C
0366 C   IF(BTMTIN) TIME=AMAX1((TIME-T(K-1)),0.0)
0367 C
0368 C   COMPUTE NO-DECOMPRESSION TIME IF "MODLIN" IS TRUE. ADD NO-D TIME
0369 C   (MINIMUM VALUE .99) TO DESCENT TIME, TRUNCATE AND SUBTRACT DESCENT
0370 C   TIME (RESULT WILL NOT BE LESS THAN ROUNDED UP DESCENT TIME). THIS
0371 C   ENSURES THAT BOTTOM TIME (SUM OF DESCENT TIME AND TIME AT DEPTH)
0372 C   WILL ALWAYS BE IN WHOLE MINUTES. DON'T EXCEED MAXIMUM BOTTOM TIME.
0373 C
0374 C   IF(.NOT.MODLIN) GO TO 219
0375 C   CALL NLIN7(TIME)
0376 C   IF((TIME+T(K-1)).GT.BTMAX) TIME=BTMAX-T(K-1)
0377 C   TIME=AMAX1(TIME,0.99)+T(K-1)-T(K-1)
0378 C
0379 C   ADD 0.001 TO "TIME" TO TAKE CARE OF POTENTIAL ROUNDOFF ERROR WHEN
0380 C   THE DESCENT TIME AND TIME AT DEPTH ARE ADDED DURING ZERO TIME
0381 C   COMPUTATION IN THE PROFILE RECORDING PROCEDURE.
0382 C
0383 C   TIME=TIME+0.001
0384 C
0385 C   RECORD PROFILE COORDINATES FOR FIRST SUB-SEGMENT.
0386 C   STOP TIME COMPUTATION PROCEDURE REENTERS HERE.
0387 C
0388 C   D(K)=CDEPTH
0389 C   T(K)=TIME
0390 C   R(K)=RATE
0391 C
0392 C   UPDATE MODEL PARAMETERS TO END OF FIRST SUB-SEGMENT, THEN RECORD.
0393 C
0394 C   RATE=0.0
0395 C   DC=0.0
0396 C   TC=TIME
0397 C   CALL UPDT7
0398 C
0399 C   IF ASCENDING ("CFSTOP" TRUE) BRANCH TO FIRST STOP DEPTH
0400 C   COMPUTATION PROCEDURE. FIRST STOP PROCEDURE WILL SET "DEPTH" TO
0401 C   THE DEPTH OF THE FIRST STOP AND SET "CSTIME" TO TRUE IF STOPS
0402 C   NEEDED. FIRST STOP PROCEDURE RETURNS TO NEXT STATEMENT (0230).
0403 C   UPDATE "RATE" NOW BECAUSE FIRST STOP PROCEDURE NEEDS IT.
0404 C
0405 C   RATE=R(K)
0406 C   IF(CFSTOP) GO TO 300
0407 C
0408 C   UPDATE MODEL PARAMETERS TO END OF SECOND SUB-SEGMENT THEN RECORD.
0409 C
0410 C   DC=DEPTH-CDEPTH
0411 C   TC=DC/RATE
0412 C   CALL UPDT7
0413 C
0414 C   RECORD PROFILE COORDINATES FOR SECOND SUB-SEGMENT.
0415 C
0416 C   D(K+1)=DEPTH
0417 C   T(K+1)=TC

```

```

0418 R(K+1)=0.0
0419 C
0420 C UPDATE POINTER "K" AND CURRENT DEPTH "CDEPTH" FOR NEXT SEGMENT.
0421 C
0422 CDEPTH=DEPTH
0423 K=K+2
0424 C
0425 C IF "CSTIME" IS TRUE BRANCH TO STOP TIME COMPUTATION PROCEDURE.
0426 C PROCEDURE CAUSES INPUT FROM PROFILE COORDINATE INPUT FILE TO
0427 C BE SKIPPED AND WILL RETURN TO STATEMENT #220. IF "LSTOP" IS
0428 C TRUE BRANCH TO COMPUTE LAST STOP TIME BEFORE SURFACING.
0429 C
0430 C IF(CSTIME.OR.LSTOP) GO TO 400
0431 C
0432 C IF DONE GO TO OUTPUT PROCEDURE. IF NOT GO TO BEGINNING OF LOOP.
0433 C
0434 C IF(DONE) GO TO 500
0435 C GO TO 210
0436 C
0437 C *****
0438 C
0439 C END OF PROFILE GENERATION AND UPDATE LOOP
0440 C
0441 C *****
0442 C
0443 C
0444 C *****
0445 C
0446 C FIRST STOP DEPTH COMPUTATION PROCEDURE
0447 C
0448 C IF STOPS REQUIRED BETWEEN CURRENT DEPTH AND NEXT DESIRED DEPTH
0449 C THIS PROCEDURE SETS "CSTIME" TO TRUE SO APPROPRIATE STOPS TIMES
0450 C AT PROPER DEPTH INCREMENTS WILL BE COMPUTED. THIS PROCEDURE
0451 C EXECUTES ONLY ONCE FOR EACH ASCENT.
0452 C
0453 C *****
0454 C
0455 C SET "FDEPTH" TO "DEPTH" AND COMPUTE DEPTH OF FIRST STOP (DFS).
0456 C
0457 300 CALL FRSP7(DFS)
0458 FDEPTH=DEPTH
0459 C
0460 C IF DEPTH OF FIRST STOP (DFS) LESS THAN "DEPTH" NO STOPS NEEDED.
0461 C HOWEVER IF DEPTH IS 0.0 THERE IS ALWAYS A STOP AT "DINC" EVEN IF
0462 C IT IS 0.0 WHICH IT WILL BE FOR NO-DECOMPRESSION DIVES.
0463 C
0464 C IF(DFS.LE.DEPTH .AND. DEPTH.NE.0.0) GO TO 360
0465 C
0466 C SET "CSTIME" TRUE SO STOP TIMES WILL BE COMPUTED. SET DEPTH TO
0467 C FIRST STOP DEPTH (DFS) OR "DINC" WHICHEVER IS DEEPER.
0468 C
0469 C DEPTH=AMAX1(DFS,DINC)
0470 C CSTIME=.TRUE.
0471 C
0472 C SET "CFSTOP" TO FALSE SO WON'T COME BACK UNTIL THE NEXT ASCENT
0473 C OCCURS. THEN GO BACK TO PROFILE GENERATION AND UPDATE LOOP.
0474 C
0475 360 CFSTOP=.FALSE.
0476 GO TO 230
0477 C

```

```

0478 C*****
0479 C
0480 C           END FIRST STOP PROCEDURE
0481 C
0482 C*****
0483 C
0484 C
0485 C*****
0486 C
0487 C           STOP TIME COMPUTATION PROCEDURE
0488 C
0489 C           COMPUTES STOP TIMES AND THEN DECREMENTS DEPTH BY "DINC" UNTIL
0490 C           NEXT DESIRED DEPTH (FDEPTH) REACHED. AS LONG AS "CSTIME" IS TRUE
0491 C           THE INPUT FROM THE PROFILE COORDINATE INPUT FILE WILL BE SKIPPED.
0492 C           WHEN "FDEPTH" IS REACHED HAVING TAKEN ALL NECESSARY DECOMPRESSION
0493 C           STOPS THEN "CSTIME" IS SET TO FALSE. IF "LSTOP" IS TRUE THEN COME
0494 C           BACK ONE MORE TIME TO COMPUTE THE LAST STOP TIME BEFORE SURFACING.
0495 C
0496 C           PROCEDURE ALWAYS RETURNS TO STATEMENT #220
0497 C
0498 C*****
0499 C
0500 C           IF WITHIN "DINC" OF "FDEPTH" A DIFFERENT PROCEDURE MUST BE USED.
0501 C
0502 C 400 IF((CDEPTH-FDEPTH).LE.DINC) GO TO 410
0503 C
0504 C           "TIME" IS STOP TIME AT "CDEPTH" BEFORE ASCENDING "DINC". GO ROUND
0505 C           OFF TIME BEFORE RETURNING TO PROFILE GENERATION AND UPDATE LOOP.
0506 C
0507 C           DEPTH=CDEPTH-DINC
0508 C           CALL STIM7(TIME,DEPTH)
0509 C           GO TO 440
0510 C
0511 C           IF "CSTIME" TRUE THEN WE'RE NOT AT "FDEPTH" YET.
0512 C
0513 C 410 IF(CSTIME) GO TO 420
0514 C
0515 C           AT LAST DEPTH BEFORE SURFACING. SET "FDEPTH" TO THE SURFACE AND
0516 C           COMPUTE LAST STOP TIME, SET "LSTOP" TO FALSE SO WON'T COME BACK
0517 C           AGAIN WHEN SURFACE REACHED. "CSTIME" SET TO TRUE SO 0.0 MIN STOP
0518 C           TIMES WILL BE RECORDED FOR LATER OUTPUT. "DEPTH" DECREMENTED TO
0519 C           NEXT SHALLOWER STOP DEPTH.
0520 C
0521 C           FDEPTH=0.0
0522 C           CALL STIM7(TIME,FDEPTH)
0523 C           DEPTH=CDEPTH-DINC
0524 C           CSTIME=.TRUE.
0525 C           LSTOP=.FALSE.
0526 C           GO TO 440
0527 C
0528 C           LAST STOP TIME COMPUTED. LAST DEPTH IS "FDEPTH".
0529 C
0530 C 420 DEPTH=FDEPTH
0531 C           CALL STIM7(TIME,DEPTH)
0532 C
0533 C           LAST TIME THROUGH, SET "CSTIME" TO FALSE SO WON'T COME BACK AGAIN.
0534 C
0535 C           CSTIME=.FALSE.
0536 C
0537 C           ROUND UP STOP TIME TO NEAREST 0.9 MINUTES. MINIMUM TIME 1 MIN. FOR

```

```

0538 C      NON-ZERO STOP TIMES.
0539 C
0540 440 IF<TIME.GT.0.0> TIME=MAX1<<TIME+0.9>,1.0>
0541 C
0542 C      RETURN TO PROFILE GENERATION AND UPDATE LOOP.
0543 C
0544 C      GO TO 220
0545 C
0546 C*****
0547 C
0548 C      END STOP TIME PROCEDURE
0549 C
0550 C*****
0551 C
0552 C
0553 C*****
0554 C
0555 C      PROFILE RECORDING PROCEDURE
0556 C
0557 C      RECORDS PROFILES IN ARRAY "IPRO" FOR LATER PRINTOUT IN U.S. NAVY
0558 C      FORMAT. "IPRO" HOLDS "MAXPRO" PROFILES AND WHEN IT IS FULL THE
0559 C      PROGRAM BRANCHES TO THE PRINTOUT PROCEDURE TO PRINT A PAGE OF
0560 C      TABLES.
0561 C
0562 C*****
0563 C
0564 C      IF FIRST STOP DEPTH GREATER THAN THAT ALLOWED BY OUTPUT FORMAT
0565 C      RECORDING PROCEDURE. IF NOT DECREMENT "K" TO GET TO LAST POSITION
0566 C      RECORDED IN PROFILE ARRAY.
0567 C
0568 500 IF<INT<D<6>>.GT.DSTOPS<1>> GO TO 560
0569 C      K=K-1
0570 C
0571 C      COMPUTE ZERO TIME VALUES FROM ELAPSED TIME VALUES.
0572 C
0573 C      ZT<1>=0.0
0574 C      DO 510 I=2,K
0575 510 ZT<I>=ZT<I-1>+T<I>
0576 C
0577 C      IF TOTAL DIVE TIME EXCEEDS MAXIMUM, SET "NORCRD" TO TRUE. ALL
0578 C      SUBSEQUENT PROFILES WHERE MAXIMUM TIME EXCEEDED WILL NOT BE
0579 C      RECORDED.
0580 C
0581 C      IF<ZT<K>.LE.TDTHAX> GO TO 513
0582 C      IF<NORCRD> GO TO 560
0583 C      NORCRD=.TRUE.
0584 C      GO TO 515
0585 513 NORCRD=.FALSE.
0586 C
0587 C      ALWAYS RECORD FIRST PROFILE COMPUTED BY THE PROGRAM (NPRO=0) AND
0588 C      PROFILES WHERE THE DIVE DEPTH IS DIFFERENT FROM THE PREVIOUS ONE.
0589 C
0590 515 IF<NPRO.EQ.0> GO TO 520
0591 C      IF<INT<D<5>>.NE.IPRO<1,NPRO>> GO TO 520
0592 C
0593 C      DO NOT RECORD PROFILES IF THE BOTTOM TIME IS LESS THAN OR EQUAL TO
0594 C      THAT OF THE PREVIOUSLY RECORDED PROFILE. OTHERWISE RECORD ALL
0595 C      PROFILES REQUIRING DECOMPRESSION STOPS.
0596 C
0597 C      IF<INT<ZT<5>>.LE.IPRO<2,NPRO>> GO TO 560

```

```

0598      IF(D<7>).GT.DINC .OR. T<7>).NE.0.0) GO TO 520
0599      C
0600      C      OVERWRITE PREVIOUSLY RECORDED NO-D PROFILES UNTIL FIRST
0601      C      DECOMPRESSION PROFILE ENCOUNTERED. DON'T INCREMENT "NPRO" YET.
0602      C
0603      GO TO 540
0604      C
0605      C      EVERY RECORDED PROFILE INCREMENTS "NPRO" UNTIL "IPRO" FULL
0606      C
0607      520      NPRO=NPRO+1
0608      C
0609      C      COMPUTE ASCENT TIME (ASTIM), ROUND TO NEAREST SECOND, RECORD
0610      C      MINUTES, TENS AND UNITS OF SECONDS SEPERATELY INTO ARRAY "IPRO".
0611      C
0612      540      ASTIM=ZT(K)-ZT(5)+(.5/60.)
0613      THIN=INT(ASTIM)
0614      TSEC=(ASTIM-THIN)*60.
0615      IPRO(NSTOP+6,NPRO)=THIN
0616      IPRO(NSTOP+7,NPRO)=TSEC/10.0
0617      IPRO(NSTOP+8,NPRO)=INT(TSEC)-IPRO(NSTOP+7,NPRO)*10
0618      C
0619      C      COMPUTE TIME TO THE FIRST STOP (TFS) WHICH WILL EQUAL "ASTIM" FOR
0620      C      NO-D DIVES. ROUND OFF AND RECORD THE SAME AS FOR "ASTIM" ABOVE.
0621      C
0622      TFS=T<6>+ (.5/60.)
0623      IF(INT(T<7>).EQ.0 .AND. D<6>).EQ.DINC) TFS=ASTIM
0624      THIN=INT(TFS)
0625      TSEC=(TFS-THIN)*60.
0626      IPRO(3,NPRO)=THIN
0627      IPRO(4,NPRO)=TSEC/10.
0628      IPRO(5,NPRO)=INT(TSEC)-IPRO(4,NPRO)*10
0629      C
0630      C      RECORD DEPTH OF DIVE AND BOTTON TIME INTO "IPRO".
0631      C
0632      IPRO(1,NPRO)=D<5>
0633      IPRO(2,NPRO)=ZT<5>
0634      C
0635      C      "IJ" POINTS TO POSITION OF THE FIRST STOP IN "IPRO" AND "D<6>" IS
0636      C      THE DEPTH OF THE FIRST STOP.
0637      C
0638      IJ=NSTOP+6-INT(D<6>/DINC)
0639      C
0640      C      THE NUMBER OF STOPS IS STORED IN THE LAST POSITION IN "IPRO".
0641      C
0642      IPRO(NSTOP+9,NPRO)=INT(D<6>/DINC)
0643      C
0644      C      "ISTOP" INITIALLY SET TO DEPTH OF FIRST STOP IN PROFILE DEPTH
0645      C      ARRAY "D". "NK" POINTS TO DEPTH OF STOP RECORDED IN ARRAY "IPRO".
0646      C
0647      NK=6
0648      ISTOP=INT(D<6>)
0649      C
0650      C      RECORD STOP TIMES INTO "IPRO". "NK+1" POINTS TO ARRAY POSITION
0651      C      CONTAINING STOP TIME.
0652      C
0653      DO 550 I=IJ,NSTOP+5
0654      545      IPRO(I,NPRO)=IPRO(I,NPRO)+T(NK+1)
0655      NK=NK+2
0656      C
0657      C      IF THE NEXT RECORDED DEPTH IS STILL THE SAME AS "ISTOP" ADD THE

```

```

0658 C      STOP TIME TO THE STOP TIME ALREADY RECORDED IN "IPRO".
0659 C
0660 C      IF<INT<D<NK>>.EQ.ISTOP> GO TO 545
0661 550    ISTOP=ISTOP-DINC
0662 C
0663 C      SPACE PAST THE NEXT RECORD WHICH IS NOT NEEDED FOR THIS PROGRAM.
0664 C      THIS MAINTAINS INPUT FILE COMPATIBILITY WITH PROGRAM DMDB7. READ
0665 C      IN VALUE OF "MORE" (YES OR NO) TO SPECIFY IF ANOTHER PROFILE WILL
0666 C      FOLLOW.
0667 C
0668 560    READ<LB>
0669        READ<LB,22> MORE
0670 C
0671 C      IF "IPRO" BUFFER FULL SET "FULBUF" TO TRUE AND PRINTOUT A PAGE OF
0672 C      TABLES BEFORE CONTINUING.
0673 C
0674 570    FULBUF=.FALSE.
0675        IF<NPRO.EQ.<MAXPRO+1>> FULBUF=.TRUE.
0676        IF<FULBUF> GO TO 588
0677 C
0678 C      IF ANOTHER PROFILE FOLLOWS GO BEGIN READING IT IN.
0679 C
0680        IF<MORE.EQ.2HYES> GO TO 200
0681 C
0682 C*****
0683 C
0684 C      END PROFILE RECORDING PROCEDURE
0685 C
0686 C*****
0687 C
0688 C
0689 C*****
0690 C
0691 C      TABLE PRINTOUT PROCEDURE
0692 C
0693 C      PRINTS OUT ONE PAGE OR A PARTIAL PAGE<LAST PAGE ONLY> OF TABLES
0694 C
0695 C*****
0696 C
0697 C      VALUE OF "ICONC" DEPENDS ON WHETHER CONSTANT FRACTION OF INERT GAS
0698 C      OR CONSTANT P02 USED FOR TABLES AND GETS PROPER LABELS FROM THE
0699 C      THE GAS LABEL ARRAY "CONLBL".
0700 C
0701 588    CONC=P02
0702        ICONC=1
0703        IF<CP02> GO TO 590
0704        CONC=<1-FN2>*100.
0705        ICONC=2
0706 C
0707 C      SET UP CORRECT LABELS FOR DEPTH UNITS <ULBL> FOR PRINTOUT.
0708 C
0709 590    ULBL=UFEET
0710        IF<METRIC> ULBL=UMETER
0711 C
0712 C      PRINTOUT PAGE HEADER
0713 C
0714        WRITE<LP,42> DAYTIN,MPIF,ULBL
0715        WRITE<LP,48>CONC,<CONLBL<ICONC,ILBL>,ILBL=1,2>,IGAS,IRATE,ULBL,
0716        "      IRATE,ULBL
0717        WRITE<LP,43> ULBL,ULBL,DSTOPS

```

```

0718 C
0719 C "ICHNG" USED TO DETERMINE IF DEPTH OF PROFILES HAS CHANGED. IT'S
0720 C INITIALLY SET TO DEPTH OF FIRST PROFILE CURRENTLY IN "IPRO". THE
0721 C MAXIMUM VALUE OF "NPRO" FOR PRINTOUT IS "MAXPRO".
0722 C
0723 C ICHNG=IPRO(1,1)
0724 C IF(FULBUF) NPRO=MAXPRO
0725 C
0726 C BEGINNING OF LOOP WHICH PRINTS OUT PAGE OF PROFILES
0727 C
0728 C DO 670 I=1,NPRO
0729 C
0730 C IF DEPTH OF PROFILE HASN'T CHANGED SKIP DELIMITER LINE PRINTOUT.
0731 C
0732 C IF(ICHNG.EQ.IPRO(1,I)) GO TO 630
0733 C
0734 C RESET "ICHNG" TO NEXT PROFILE DEPTH. PRINT DELIMITER LINE.
0735 C
0736 C ICHNG=IPRO(1,I)
0737 C WRITE(LP,46)
0738 C GO TO 640
0739 630 WRITE(LP,44)
0740 C
0741 C "NLINE" SELECTS PROPER WRITE STATEMENT FOR NUMBER OF STOPS.
0742 C "IJ" POINTS TO POSITION OF FIRST STOP TIME IN "IPRO" ARRAY.
0743 C
0744 640 NLINE=IPRO(NSTOP+9,I)
0745 C IJ=NSTOP+6-NLINE
0746 C GO TO (650,651,652,653,654,655,656,657,658,659,660,661,
0747 C * 662,663,664),NLINE
0748 C
0749 C WRITE OUT A SINGLE PROFILE LINE IN THE CURRENT PAGE OF TABLES.
0750 C
0751 650 WRITE(LP,50) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0752 C GO TO 670
0753 651 WRITE(LP,51) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0754 C GO TO 670
0755 652 WRITE(LP,52) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0756 C GO TO 670
0757 653 WRITE(LP,53) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0758 C GO TO 670
0759 654 WRITE(LP,54) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0760 C GO TO 670
0761 655 WRITE(LP,55) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0762 C GO TO 670
0763 656 WRITE(LP,56) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0764 C GO TO 670
0765 657 WRITE(LP,57) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0766 C GO TO 670
0767 658 WRITE(LP,58) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0768 C GO TO 670
0769 659 WRITE(LP,59) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0770 C GO TO 670
0771 660 WRITE(LP,60) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0772 C GO TO 670
0773 661 WRITE(LP,61) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0774 C GO TO 670
0775 662 WRITE(LP,62) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)
0776 C GO TO 670
0777 663 WRITE(LP,63) (IPRO(J,I),J=1,5),(IPRO(J,I),J=IJ,NSTOP+8)

```



```

0778      GO TO 670
0779 664  WRITE(LP,64) (IPRO(J,I),J=1,5),(IPRO(J,I),J=1J,NSTOP+8)
0780 670  CONTINUE
0781      C
0782      C  MOVE PROFILE IN LAST POSITION IN "IPRO" TO THE FIRST POSITION.
0783      C  FILL REST OF "IPRO" WITH ZEROS.
0784      C
0785      DO 680 I=1,MAXPRO+1
0786      DO 680 J=1,NSTOP+9
0787      IPRO(J,I)=0
0788 680  IF(I.EQ.1) IPRO(J,I)=IPRO(J,MAXPRO+1)
0789      C
0790      C  DONE WITH PAGE PRINTOUT. NOW ONLY 1 PROFILE LEFT IN "IPRO".
0791      C
0792      NPRO=1
0793      C
0794      C  IF MORE PROFILES FOLLOW EXECUTE FORM FEED AND GO READ THEM IN.
0795      C
0796      IF(MORE.NE.2HVE) GO TO 690
0797      WRITE(LP,47)
0798      GO TO 200
0799      C
0800      C  IF "IPRO" WAS FULL THERE'S ONE MORE PROFILE TO PRINT OUT.
0801      C
0802 690  IF(FULBUF) GO TO 570
0803      C
0804      C  PRINT OUT DELIMITER LINE ,FROM FEED LINE PRINTER, STOP.
0805      C
0806      WRITE(LP,46)
0807      WRITE(LP,47)
0808      STOP
0809      END
0810      ENDS

```

ANNEX B

**DECOMPRESSION MODEL
SUBROUTINE LISTINGS**

ANNEX B-1

SUBROUTINE BLOC7
LISTING

```

0001 FTN4
0002 BLOCK DATA, BLOC7 24 SEPT 82 VER 1.1
0003 C
0004 C INITIALIZES DATA IN MODEL COMMON BLOCKS "PARAM" AND "BLDVL".
0005 C
0006 C
0007 C
0008 C
0009 C
0010 C
0011 C
0012 C
0013 C
0014 C
0015 C
0016 C
0017 C
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C
0024 C
0025 C
0026 C
0027 C
0028 C
0029 C
0030 C
0031 C
0032 C
0033 C
0034 C
0035 C
0036 C
0037 C
0038 C
0039 C
0040 C
0041 C
0042 C
0043 C
0044 C
0045 C
0046 C
0047 C
0048 C
0049 C
0050 C
0051 C
0052 C
0053 C
0054 C
0055 C
0056 C
0057 C

```

0058

END*

ANNEX 3-2

SUBROUTINE UPDT7
EXPONENTIAL-LINEAR VERSION
LISTING


```

0058 C    KSAT      TIME CONSTANT FOR SATURATING TISSUES (1/MIN)
0059 C    M         TISSUE MAXIMUM GAS TENSION ARRAY (FSW)
0060 C    NITR      NUMBER OF TIMES NEWTON-RAPHSON ITERATION PERFORMED
0061 C    NTISS     NUMBER OF HALFTIME TISSUES (9 MAX.)
0062 C    P         TISSUE GAS TENSION ARRAY (FSW)
0063 C    PACO2     ARTERIAL CO2 PARTIAL PRESSURE (FSW)
0064 C    PAMB      AMBIENT PRESSURE (FSW)
0065 C    PAN2      ARTERIAL INERT GAS TENSION (FSW)
0066 C    PAO2      ARTERIAL O2 TENSION (FSW)
0067 C    PBOVP     GAS PHASE OVERPRESSURE (FSW)
0068 C    PH2O      PARTIAL PRESSURE OF WATER VAPOR (FSW)
0069 C    PO2       INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0070 C    PTISS     TISSUE DISSOLVED INERT GAS TENSION (FSW)
0071 C    PVC02     VENOUS CO2 PARTIAL PRESSURE (FSW)
0072 C    PVN2      VENOUS INERT GAS TENSION (FSW)
0073 C    PVO2      VENOUS O2 PARTIAL PRESSURE (FSW)
0074 C    PVSAT     INERT GAS TENSION NEEDED FOR VENOUS SATURATION (FSW)
0075 C    RANB      RATE OF AMBIENT PRESSURE CHANGE (FSW/MIN)
0076 C    RATE      RATE OF DEPTH CHANGE (FSW OR MSW/MIN)
0077 C    RINRT     RATE OF INSPIRED INERT GAS TENSION CHANGE (FSW/MIN)
0078 C    RO2       RATE OF INSPIRED O2 TENSION CHANGE (FSW/MIN)
0079 C    SHCHK     VARIABLE USED TO CHECK FOR SIGN CHANGE
0080 C    SDR       SATURATION-DESATURATION HALFTIME RATIO
0081 C    T         TIME (MIN)
0082 C    T1        TRIAL TIME IN NEWTON-RAPHSON ITERATION (MIN)
0083 C    TC         TIME CHANGE DURING ASCENT (MIN)
0084 C    TERROR     MAXIMUM TIME ERROR IN NEWTON-RAPHSON ITERATION (MIN)
0085 C    TEXP       TIME FOR EXPONENTIAL UPDATE (MIN)
0086 C    TI         TIME INTERVAL FOR LINEAR-EXPONENTIAL CROSSOVER (MIN)
0087 C    TLIN       TIME FOR LINEAR UPDATE (MIN)
0088 C    TMODE      TIME OF MINIMUM OR MAXIMUM TISSUE TENSION (MIN)
0089 C    TXCOVER    TIME TO CROSSOVER TO OTHER GAS TRANSPORT MODE (MIN)
0090 C    VALIT      ARRAY FOR STORING NEWTON-RAPHSON VALUES
0091 C    Y         NEWTON-RAPHSON NULL VARIABLE
0092 C    Y1        TRIAL VALUE OF "Y"
0093 C
0094 C
0095 C    NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW=1 ATA.
0096 C
0097 C
0098 C *****
0099 C
0100 C *****
0101 C
0102 C
0103 C    * SUBROUTINES REQUIRED *
0104 C
0105 C
0106 C    NONE
0107 C *****
0108 C
0109 C    MODEL INPUT VARIABLES
0110 C    THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0111 C    MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0112 C    SUBROUTINES.
0113 C
0114 C    COMMON/MDATA/ TC,DC,DEPTH,RATE,CP02,FN2,PO2,DINC,CF
0115 C
0116 C    MODEL COMMON
0117 C    THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.

```



```

0118 C      THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0119 C
0120 C      COMMON/PARAM/M(9,30),P(9),HLFTM(9),MTISS,SDR(9),IAD
0121 C      COMMON/BLDVL/PAC02,PH20,PVC02,PV02,ANBA02,PBOVP
0122 C
0123 C
0124 C      LOGICAL CP02,DESAT
0125 C      REAL N,K,KSAT,KDSAT,VALIT(4,10)
0126 C
0127 C      FORMAT(//10X"NEWTON RAPHSON ITERATION"//
0128 C      +4X"HLFTM"2X"CEDEPTH"5X"TC"8X"PTISS"8X"RATE"8X"RINRT"7X"PAN2"
0129 C      +7X"PVSAT"9X"A"11X"B"11X"C"/4X,I4,4X,I4,9(F11.6,1X)//
0130 C      +9X"Y"17X"Y"14X"DY"13X" Y/DY"/10(4F16.7)/)///)
0131 C
0132 C*****
0133 C
0134 C      INITIALIZATION PROCEDURE
0135 C
0136 C      SET IPRNT=1 IF ITERATION VALUES ALWAYS WANTED, OTHERWISE LEAVE AS
0137 C      0. ITERATION VALUES ALWAYS PRINTED IF ERROR LIMITS EXCEEDED.
0138 C
0139 C*****
0140 C
0141 C      IPRNT=0
0142 C
0143 C      IF TIME INTERVAL "TC" IS 0 NO UPDATE NEEDED.
0144 C
0145 C      IF(TC.EQ.0.0) RETURN
0146 C
0147 C      RATES OF AMBIENT PRESSURE CHANGE ALWAYS IN FEET/MIN, CONVERT
0148 C      METRIC RATES TO FEET/MIN. SET RATE TO 0 IF NO DEPTH CHANGE.
0149 C      COMPUTE INITIAL AMBIENT PRESSURE.
0150 C
0151 C      RANB=CF+RATE
0152 C      IF(DC.EQ.0.) RANB=0.
0153 C      PANB=CDEPTH+CF+33
0154 C
0155 C      FOLLOWING VARIABLES DEPEND ON WHETHER CONSTANT OXYGEN PARTIAL
0156 C      PRESSURE OF CONSTANT INERT GAS FRACTION USED. LOGICAL VARIABLE
0157 C      "CP02" IS TRUE FOR CONSTANT P02 OTHERWISE IT'S FALSE.
0158 C
0159 C      IF (CP02) GO TO 30
0160 C      PA02=(PANB-PH20)*(1-FN2)-ANBA02
0161 C      RINRT=FN2+RANB
0162 C      RO2=(1-FN2)+RANB
0163 C      GO TO 40
0164 C 30 PA02=P02+33*(1.0-PH20/PANB)-ANBA02
0165 C      RINRT=RANB
0166 C      RO2=0.0
0167 C 40 CONTINUE
0168 C
0169 C*****
0170 C
0171 C      END INITIALIZATION PROCEDURE
0172 C
0173 C*****
0174 C
0175 C
0176 C*****
0177 C

```

```

0178 C          TISSUE UPDATE LOOP
0179 C
0180 C          EXECUTE LOOP FOR ALL "NTISS" TISSUES.
0181 C
0182 C*****
0183 C
0184 C          COMPUTE TIME CONSTANTS FOR SATURATING AND DESATURATING TISSUES
0185 C          ("KSAT" AND "KDSAT"). INITIALIZE ARTERIAL AND VENOUS SATURATION
0186 C          INERT GAS TENSIONS.
0187 C
0188 C          DO 500 I=1,NTISS
0189 C             KSAT=ALOG(2.0)/HLFTM(I)
0190 C             KDSAT=KSAT*SDR(I)
0191 C             PAN2=PAMB-(PAO2+PACO2+PH2O)
0192 C             PVSAT=PAMB-(PVO2+PVC02+PH2O)
0193 C
0194 C          INITIALIZE TISSUE TENSION TO DEFAULT VALUE.
0195 C
0196 C          PTISS=P(I)
0197 C
0198 C          IF TISSUE TENSION INITIALLY GREATER THAN "PVSAT" GO TO LINEAR
0199 C          UPDATE PROCEDURE.
0200 C
0201 C          IF (PTISS.GT.(PVSAT+PSOVP)) GO TO 300
0202 C
0203 C*****
0204 C
0205 C          EXPONENTIAL NODE TIME COMPUTATION PROCEDURE
0206 C
0207 C          THIS PROCEDURE CHECKS TO SEE IF INITIALLY EXPONENTIALLY SATURATING
0208 C          OR DESATURATING TISSUES WILL GO THROUGH A MINIMUM OR MAXIMUM
0209 C          (NODE) DURING THE TIME INTERVAL "TC". IF A NODE OCCURS THE TISSUE
0210 C          TENSIONS ARE UPDATED TO THE TIME OF THE NODE (TNODE). THERE ARE
0211 C          TWO EXITS FROM THIS PROCEDURE. IF NO NODE OCCURS OR IF THE TISSUE
0212 C          REMAINS EXPONENTIAL FOR THE WHOLE TIME INTERVAL THE EXIT IS TO THE
0213 C          EXPONENTIAL UPDATE PROCEDURE (STATEMENT 400). OTHERWISE THE EXIT
0214 C          IS TO THE EXPONENTIAL-LINEAR CROSSOVER TIME COMPUTATION PROCEDURE
0215 C          (STATEMENT 200).
0216 C
0217 C          EXITS TO STATEMENT 200 OR 400
0218 C
0219 C*****
0220 C
0221 C          SET "TI" (TIME REMAINING IN INTERVAL "TC" AFTER NODE HAS OCCURED)
0222 C          TO "TC" INITIALLY. ALSO INITIALIZE "TEXP" TO "TC".
0223 C
0224 C          TI=TC
0225 C          TEXP=TC
0226 C
0227 C          IF TISSUE INERT GAS TENSION GREATER THAN ARTERIAL IT'S
0228 C          DESATURATING OTHERWISE IT'S SATURATING ("DESAT" IS FALSE).
0229 C
0230 C          DESAT=.FALSE.
0231 C          IF(PTISS.GT.PAN2) DESAT=.TRUE.
0232 C
0233 C          IF INITIALLY SATURATING AND DESCENDING,NO NODE WILL OCCUR DURING
0234 C          "TC" AND TISSUE CONTINUES SATURATING EXPONENTIALLY.
0235 C
0236 C          IF(RATE.GT.0 .AND. .NOT.DESAT) GO TO 400
0237 C

```

```

0238 C      INITIALLY DESATURATING TISSUES UNDERGOING ASCENT HAVE NO NODE.
0239 C      TISSUE CONTINUES DESATURATING AND A CROSSOVER TO LINEAR DESAT-
0240 C      URATION WILL OCCUR SO GO TO CROSSOVER TIME COMPUTATION PROCEDURE.
0241 C
0242 C      IF(RATE.LT.0 .AND. DESAT) GO TO 200
0243 C
0244 C      AT THIS POINT THE ONLY TISSUE CONDITIONS WHICH HAVE NOT BEEN
0245 C      ELIMINATED ARE INITIALLY EXPONENTIALLY SATURATING UNDERGOING
0246 C      ASCENT OR INITIALLY EXPONENTIALLY DESATURATING UNDERGOING
0247 C      DESCENT. IF "RATE" IS 0 NO NODE FOR EITHER CONDITION AND
0248 C      TISSUE WILL STAY IN THE EXPONENTIAL MODE.
0249 C
0250 C      IF (RATE.EQ.0) GO TO 400
0251 C
0252 C      COMPUTE TIME AT WHICH NODE WILL OCCUR (TNODE).
0253 C
0254 C      K=KSAT
0255 C      IF(DESAT) K=KDSAT
0256 C      C=(K/RINRT)*(PTISS-PAN2)
0257 C      TNODE=(1/K)*ALOG(C+1.0)
0258 C
0259 C      IF "TNODE" IS 0 GO TO EXPONENTIAL-LINEAR CROSSOVER TIME PROCEDURE.
0260 C      (CAN ONLY HAPPEN FOR INITIALLY SATURATED TISSUE UNDERGOING ASCENT)
0261 C
0262 C      IF(TNODE.LE.0.0) GO TO 200
0263 C
0264 C      IF "TNODE" GREATER THAN THE TIME INCREMENT "TC" THERE IS NO NODE
0265 C      AND TISSUE REMAINS IN THE EXPONENTIAL MODE.
0266 C
0267 C      IF(TNODE.GE.TC) GO TO 400
0268 C
0269 C      UPDATE "PAN2", "PVSAT" TO "TNODE" AND COMPUTE A NEW TIME INTERVAL
0270 C      "TI". AT "TNODE" TISSUE AND ARTERIAL INERT GAS TENSION ARE EQUAL
0271 C      BY DEFINITION.
0272 C
0273 C      PAN2=PAN2+RINRT*TNODE
0274 C      PVSAT=PVSAT+RINRT*TNODE
0275 C      TI=TC-TNODE
0276 C      PTISS=PAN2
0277 C
0278 C      EXPONENTIAL UPDATE TIME INITIALLY ASSUMED TO EQUAL "TI".
0279 C
0280 C      TEXP=TI
0281 C
0282 C      IF THE TISSUE WAS INITIALLY SATURATING THEN AFTER THE NODE IT WILL
0283 C      BE DESATURATING AND A CROSSOVER TO THE LINEAR MODE MAY OCCUR.
0284 C
0285 C      IF(.NOT.DESAT) GO TO 200
0286 C
0287 C      AT THIS POINT ONLY THE DESATURATING TISSUE IS LEFT AND AFTER THE
0288 C      NODE IT WILL BE SATURATING AND THEREFORE WILL REMAIN IN THE
0289 C      EXPONENTIAL MODE. SET "DESAT" TO FALSE BEFORE GOING TO THE
0290 C      EXPONENTIAL UPDATE PROCEDURE.
0291 C
0292 C      DESAT=.FALSE.
0293 C      GO TO 400
0294 C
0295 C      *****
0296 C
0297 C      END OF EXPONENTIAL MODE TIME PROCEDURE

```

```

0298 C
0299 C*****
0300 C
0301 C
0302 C*****
0303 C
0304 C      EXPONENTIAL-LINEAR CROSSOVER TIME COMPUTATION PROCEDURE
0305 C
0306 C
0307 C      THIS PROCEDURE COMPUTES THE TIME AT WHICH THE TISSUE WILL GO FROM
0308 C      THE INITIAL EXPONENTIAL DESATURATION MODE TO THE LINEAR
0309 C      DESATURATION MODE. THIS CROSSOVER OCCURS AT THE TIME WHEN THE
0310 C      TOTAL TISSUE GAS TENSION EXCEEDS THE TOTAL AMBIENT PRESSURE BY
0311 C      THE GAS PHASE OVERPRESSURE (PBOVP), THAT IS WHEN:
0312 C
0313 C      (1)       $P(I) + PV_{O2} + PV_{CO2} + PH_{2O} = P_{AMB} + R_{AMB} \cdot T + P_{BOVP}$ 
0314 C
0315 C      WHERE FOR THE CONDITION WHERE NO GAS PHASE IS PRESENT:
0316 C
0317 C      (2)       $P(I) = (P_{TISS} - P_{AN2} + R_{INRT}/K) \cdot (\exp(-K \cdot T) - 1) + R_{INRT} \cdot T + P_{TISS}$ 
0318 C
0319 C      "PTISS" AND "PAMB" ARE THE VALUES OF THE TISSUE INERT GAS TENSION
0320 C      AND AMBIENT PRESSURE RESPECTIVELY AT THE START OF THE DEPTH
0321 C      CHANGE. "RAMB" IS THE RATE OF DEPTH CHANGE AND "T" THE TIME SINCE
0322 C      THE BEGINNING OF THE DEPTH CHANGE. "K" IS THE EXPONENTIAL TIME
0323 C      CONSTANT WHICH IS EQUAL TO EITHER "KSAT" OR "KDSAT" DEPENDING ON
0324 C      WHETHER THE TISSUE IS SATURATING OR DESATURATING. IN THE CONSTANT
0325 C      PO2 MODE "RAMB" AND "RINRT" ARE EQUAL AND EQUATION(1) CAN BE
0326 C      SOLVED FOR "T" (SEE STATEMENT 210). IN THE CONSTANT INERT FRACTION
0327 C      MODE "RAMB" AND "RINRT" ARE NOT EQUAL AND EQUATION(1) CANNOT BE
0328 C      EXPLICITLY SOLVED FOR "T" AND MUST BE SOLVED BY ITERATION.
0329 C
0330 C
0331 C      THE ONLY EXIT IS TO THE LINEAR UPDATE PROCEDURE AT STATEMENT 450.
0332 C
0333 C*****
0334 C
0335 C      CROSSOVER TIME INITIALLY ASSUMED EQUAL TO "TI".
0336 C
0337 C      TXOVER=TI
0338 C
0339 C      SEE IF EQUATION(2) ASYMPTOTE LINE INTERCEPT GREATER THAN THAT OF
0340 C      THE CROSSOVER PRESSURE LINE, IF IT IS CROSSOVER WILL ALWAYS OCCUR
0341 C      SO GO COMPUTE CROSSOVER TIME.
0342 C
0343 C      IF(RINRT.LT.(KDSAT*(PAN2-(PVSAT+PBOVP)))) GO TO 210
0344 C
0345 C      IF ASYMPTOTE INTERCEPT NOT GREATER THAN THAT OF CROSSOVER LINE
0346 C      NO CROSSOVER OCCURS IF PO2 IS CONSTANT.
0347 C
0348 C      IF(CPO2) GO TO 400
0349 C
0350 C      COMPUTE TIME WHERE ASYMPTOTE INTERSECTS CROSSOVER LINE.
0351 C
0352 C       $T = (P_{AN2} - (P_{VSAT} + P_{BOVP}) - R_{INRT}/K_{DSAT}) / (R_{AMB} - R_{INRT})$ 
0353 C
0354 C      IF "T" GREATER OR EQUAL TO THE TIME INTERVAL "TI" NO CROSSOVER.
0355 C      IF NOT, "T" USED AS TRIAL TIME TO START ITERATION.
0356 C
0357 C      IF(T.GE.TI) GO TO 400

```

```

0358      GO TO 220
0359      C
0360      C      COMPUTE THE CROSSOVER TIME ASSUMING THAT A CONSTANT P02 IS BEING
0361      C      USED.
0362      C
0363      210      T=-(1/KDSAT)*ALOG(1-(PTISS-(PVSAT+PBOVP))/(PTISS-PAN2+RAMB/KDSAT))
0364      C
0365      C      IF IN CONSTANT P02 MODE, THEN THE ABOVE TIME IS THE EXACT
0366      C      TIME TO CROSSOVER. IF WE'RE IN THE CONSTANT INERT GAS FRACTION
0367      C      MODE THEN "T" IS THE MAXIMUM TIME TO CROSSOVER AND IS USED AS A
0368      C      STARTING POINT FOR THE ITERATION.
0369      C
0370      C      IF(CP02) GO TO 280
0371      C
0372      C-----
0373      C
0374      C      NEWTON RAPHSON ITERATION
0375      C
0376      C      IF WE'RE IN THE CONSTANT INERT GAS FRACTION MODE THE CROSSOVER
0377      C      TIME IS THE INDEPENDANT VARIABLE IN THE NON-INVERTABLE EQUATION(1)
0378      C      AND CAN ONLY BE COMPUTED BY ITERATION.
0379      C
0380      C-----
0381      C
0382      C      COMPUTE CONSTANTS FOR ITERATION
0383      C
0384      220      A=(PTISS-PAN2+RINRT/KDSAT)
0385      B=(PVSAT+PBOVP-PTISS)
0386      C=RAMB-RINRT
0387      NITR=0
0388      C
0389      C      "Y" IS THE NULL FUNCTION WHICH WILL BE EXACTLY 0.0 WHEN "T" IS
0390      C      EXACTLY THE CROSSOVER TIME. "DY" IS THE FIRST DERIVITIVE OF "Y".
0391      C
0392      230      EXPN=EXP(-KDSAT*T)
0393      Y=B-A*(EXPN-1)+C*T
0394      DY=C+KDSAT*A*EXPN
0395      C
0396      C      SEED ERROR CHECK WITH "T" AND "Y" ON FIRST PASS.
0397      C
0398      C      IF(NITR.GT.0) GO TO 240
0399      T1=T
0400      Y1=Y
0401      240      NITR=NITR+1
0402      C
0403      C      SAVE ITERATION VALUES FOR IN CASE PRINTOUT OCCURS.
0404      C
0405      VALIT(1,NITR)=T
0406      VALIT(2,NITR)=Y
0407      VALIT(3,NITR)=DY
0408      VALIT(4,NITR)=Y/DY
0409      C
0410      C      STOP ITERATION IF "Y" AND "Y/DY" ARE BOTH LESS THAN THE ACCEPTABLE
0411      C      ERROR.
0412      C
0413      C      IF(ABS(Y/DY).LE.0.00001 .AND. ABS(Y).LT.0.001) GO TO 270
0414      C
0415      C      STOP ITERATION AFTER 10 PASSES NO MATTER WHAT.
0416      C
0417      C      IF(NITR.EQ.10) GO TO 270

```

```

0418 C
0419 C IF "Y" HAS UNDERGONE A SIGN CHANGE SINCE LAST RECORDING "T1" THEN
0420 C "ABS(T-T1)" IS THE MAXIMUM ERROR FOR "T". IF THIS ERROR IS
0421 C ACCEPTABLE THEN STOP ITERATION. THIS TERMINATES ITERATIONS WHERE
0422 C "Y" OSCILLATES AROUND ZERO MORE RAPIDLY. IF "SCHK" IS POSITIVE
0423 C THEN NO SIGN CHANGE OCCURED AND NO ERROR CHECK MADE.
0424 C
0425 C SCHK=SIGN(1.0,Y)*SIGN(1.0,Y1)
0426 C IF(SCHK.GT.0) GO TO 260
0427 C TERROR=ABS(T1-T)
0428 C IF(TERROR.LT.0.0001) GO TO 270
0429 C T1=T
0430 C Y1=Y
0431 C
0432 C COMPUTE NEW ESTIMATE OF THE CROSSOVER TIME FOR THE NEXT PASS.
0433 C
0434 260 T=T-(Y/DY)
0435 C GO TO 230
0436 C
0437 C WRITE OUT ITERATION VALUES IF CONVERGENCE TO ERROR LIMITS HAS NOT
0438 C OCCURED IN 10 ITERATIONS OR IF PRINT MODE ON (IPRNT=1).
0439 C
0440 270 IF(NITR.LT.10 .AND. IPRNT.EQ.0) GO TO 280
0441 C WRITE(6,1) HLFTH(I),CDEPTH,TI,PTISS,RAMB,RINRT,PAN2,PVSAT,A,B,C,
0442 C *(VALIT(J,L),J=1,4),L=1,NITR)
0443 C
0444 C +-----+
0445 C
0446 C END OF NEWTON RAPHSOON ITERATION
0447 C
0448 C +-----+
0449 C
0450 C CROSSOVER TIME IS THE VALUE OF "T" AT THE FINISH OF THE NEWTON
0451 C RAPHSOON ITERATION OR THE VALUE COMPUTED IN STATEMENT 210 IF IN THE
0452 C CONSTANT P02 MODE. IF CROSSOVER TIME EXCEEDS "TI" GO TO
0453 C EXPONENTIAL UPDATE.
0454 C
0455 280 TXOVER=T
0456 C IF(T.GT.TI) GO TO 400
0457 C
0458 C COMPUTE VENOUS SATURATION INERT GAS TENSION AND ARTERIAL INERT GAS
0459 C TENSION AT CROSSOVER TIME. BY DEFINITION THE VENOUS INERT GAS
0460 C TENSION EXCEEDS THE VENOUS SATURATION INERT GAS TENSION BY THE
0461 C GAS PHASE OVERPRESSURE (PBOVP) AT THE CROSSOVER TIME.
0462 C
0463 C PVSAT=PVSAT+RAMB*TXOVER
0464 C PAN2=PAN2+RINRT*TXOVER
0465 C PVN2=PVSAT+PBOVP
0466 C
0467 C VENOUS AND DISSOLVED TISSUE INERT GAS TENSION EQUAL WHEN GAS PHASE
0468 C FORMS. COMPUTE TIME REMAINING FOR LINEAR UPDATE AFTER CROSSOVER.
0469 C
0470 C PTISS=PVN2
0471 C TLIN=TI-TXOVER
0472 C GO TO 450
0473 C
0474 C +-----+
0475 C
0476 C END EXP-LIN CROSSOVER TIME COMPUTATION PROCEDURE
0477 C

```

```

0478 C*****
0479 C
0480 C*****
0481 C
0482 C      LINEAR-EXPONENTIAL CROSSOVER TIME COMPUTATION PROCEDURE
0483 C
0484 C
0485 C      CROSSOVER OCCURS WHEN THE TOTAL DISSOLVED INERT GAS TENSION FALLS
0486 C      TO A LEVEL WHICH JUST EXCEEDS THE AMBIENT PRESSURE BY THE GAS
0487 C      PHASE OVERPRESSURE (PBOVP) ,THAT IS WHEN:
0488 C
0489 C      (3)           $P(I) + PV_{O2} + PV_{CO2} + PH_{2O} = P_{AMB} + R_{AMB} * T + P_{BOVP}$ 
0490 C
0491 C      WHERE, WHEN A GAS PHASE IS PRESENT:
0492 C
0493 C      (4)           $P(I) = P_{TISS} + K_{DSAT} * (P_{AN2} - P_{VN2}) * T - (R_{O2} * K_{DSAT} / 2) * T^2$ 
0494 C
0495 C      "PTISS" AND "PAMB" ARE THE TISSUE DISSOLVED INERT GAS TENSION AND
0496 C      THE AMBIENT PRESSURE RESPECTIVELY AT THE BEGINNING OF THE LINEAR
0497 C      DEPTH CHANGE. "RAMB" IS THE RATE OF DEPTH CHANGE AND "T" THE TIME
0498 C      SINCE THE BEGINNING OF THE DEPTH CHANGE. EQUATION(3) CAN BE EASILY
0499 C      SOLVED FOR "T" IN THE CONSTANT PO2 MODE SINCE "RO2" IS 0. IN THE
0500 C      CONSTANT INERT FRACTION MODE THE QUADRATIC FORMULA MUST BE USED.
0501 C
0502 C*****
0503 C
0504 C      TIME IN LINEAR UPDATE MODE INITIALLY ASSUMED EQUAL TO "TC".
0505 C
0506 C      300  TLIN=TC
0507 C
0508 C      WHEN A GAS PHASE IS PRESENT THE VENOUS INERT GAS TENSION EXCEEDS
0509 C      THE VENOUS SATURATION INERT GAS TENSION BY THE GAS PHASE
0510 C      OVERPRESSURE.
0511 C
0512 C       $P_{VN2} = P_{VSAT} + P_{BOVP}$ 
0513 C
0514 C      VARIABLES "A", "B", AND "C" ARE COEFFICIENTS OF THE LINEAR-
0515 C      EXPONENTIAL CROSSOVER TIME QUADRATIC EQUATION. "D" IS THE SQUARE
0516 C      ROOT TERM OF THE QUADRATIC FORMULA.
0517 C
0518 C       $A = R_{O2} * K_{DSAT} / 2$ 
0519 C       $B = R_{AMB} - K_{DSAT} * (P_{AN2} - P_{VN2})$ 
0520 C       $C = P_{VN2} - P_{TISS}$ 
0521 C       $D = B^2 - 4 * A * C$ 
0522 C
0523 C      CHECK TO SEE IF NO CROSSOVER WILL OCCUR.
0524 C
0525 C      IF (D.LT.0.0 .OR. B.LE.0.0) GO TO 450
0526 C
0527 C      VALUE OF CROSSOVER TIME DEPENDS ON WHETHER OR NOT THE OXYGEN
0528 C      TENSION IS CHANGING.
0529 C
0530 C      IF (R02.EQ.0.0) TXOVER=-(C/B)
0531 C      IF (R02.NE.0.0) TXOVER=(-B+SQRT(D))/(2*A)
0532 C
0533 C      IF CROSSOVER NOT WITHIN TIME INTERVAL "TC" STAY LINEAR.
0534 C
0535 C      IF (TXOVER.GE.TC) GO TO 450
0536 C
0537 C      COMPUTE TISSUE AND ARTERIAL INERT GAS TENSION AT CROSSOVER.

```

```

0538 C      TISSUE DISSOLVED AND VENOUS INERT GAS TENSION EQUAL AT CROSSOVER.
0539 C      COMPUTE "TEXP" AS TIME REMAINING AFTER CROSSOVER OCCURS. AFTER
0540 C      CROSSOVER TISSUE WILL BE EXPONENTIALLY DESATURATING.
0541 C
0542 C      PTISS=PVH2+RANB*TXOVER
0543 C      PAN2=PAN2+RINRT*TXOVER
0544 C      TEXP=TC-TXOVER
0545 C      DESAT=.TRUE.
0546 C
0547 C      EXPONENTIAL UPDATE EXPECTS TISSUES TO BE UPDATED TO A NODE IF
0548 C      IT OCCURS. IF NO INERT GAS TENSION CHANGE OCCURS NO NODE.
0549 C
0550 C      IF(RINRT.EQ.0) GO TO 400
0551 C
0552 C      COMPUTE TIME OF NODE "TNODE".
0553 C
0554 C      C=(KDSAT/RINRT)*(PTISS-PAN2)
0555 C      TNODE=(1/KDSAT)*ALOG(C+1)
0556 C
0557 C      IF NODE WILL NOT OCCUR WITHIN REMAINING TIME GO DIRECTLY TO THE
0558 C      EXPONENTIAL UPDATE.
0559 C
0560 C      IF(TNODE.GE.TEXP) GO TO 400
0561 C
0562 C      UPDATE ARTERIAL INERT GAS TENSION TO "TNODE". AT "TNODE" THE
0563 C      TISSUE AND ARTERIAL INERT GAS TENSIONS ARE EQUAL BY DEFINITION.
0564 C
0565 C      PAN2=PAN2+RINRT*TNODE
0566 C      PTISS=PAN2
0567 C
0568 C      COMPUTE REMAINING TIME AFTER NODE OCCURS. TISSUE NOW SATURATING.
0569 C
0570 C      TEXP=TEXP-TNODE
0571 C      DESAT=.FALSE.
0572 C
0573 C      *****
0574 C
0575 C      TISSUE INERT GAS UPDATE PROCEDURES
0576 C
0577 C      UPDATE TISSUE TENSIONS EITHER EXPONENTIALLY OR LINEARLY AND STORE
0578 C      RESULTS IN ARRAY "P".
0579 C
0580 C      *****
0581 C
0582 C      EXPONENTIAL UPDATE.
0583 C
0584 C      400      K=KDSAT
0585 C              IF(DESAT) K=KDSAT
0586 C              A=PTISS-PAN2+RINRT/K
0587 C              B=RINRT*TEXP+PTISS
0588 C              P(I)=A*(EXP(-K*TEXP)-1)+B
0589 C              GO TO 500
0590 C
0591 C      LINEAR UPDATE.
0592 C
0593 C      450      A=KDSAT*(PAN2-PVH2)
0594 C              B=KDSAT*RO2/2
0595 C              P(I)=PTISS+A*TLIN-B*TLIN**2
0596 C
0597 C      *****

```



```

0598 C
0599 C
0600 C
0601 C
0602 C
0603 C
0604 C
0605 C
0606 C
0607 500 CONTINUE
0608 C
0609 C
0610 C
0611 C
0612 C
0613 C
0614 C
0615 C
0616 C
0617 C
0618 C
0619 C
0620 C
0621 C
0622 C
0623 C
0624 C
0625 C
0626 C
0627 C
0628 C
0629 510 CONTINUE
0630 550 IJ=IJ-1
0631 C
0632 C
0633 C
0634 C
0635 600 IAD=DINC*IJ
0636 C
0637 C
0638 C
0639 C
0640 C
0641 C
0642 C
0643 C
0644 C
0645 C
0646 C
0647 C

```

END TISSUE UPDATE PROCEDURES

```

*****
END OF UPDATE, GO UPDATE NEXT TISSUE OR DROP THROUGH TO COMPUTE
THE INSTANTANEOUS ASCENT DEPTH IF ALL "NTISS" TISSUES HAVE BEEN
UPDATED.
*****
END OF TISSUE UPDATE LOOP
*****
INSTANTANEOUS ASCENT DEPTH COMPUTATION PROCEDURE
*****
START AT 30 DEPTH INCREMENTS AND WORK UP ONE DEPTH INCREMENT AT A
TIME UNTIL AT LEAST ONE TISSUE TENSION EXCEEDS ITS MAXIMUM
ALLOWABLE VALUE.
*****
IJ =30
DO 550 J=1,30
DO 510 I=1,NTISS
IF(P(I).GT.M(I,IJ)) GO TO 600
CONTINUE
510
550 IJ=IJ-1
*****
SUBSCRIPT "IJ" OF ARRAY "M" SPECIFIES NUMBER OF DEPTH INCREMENTS
FOR THE INSTANTANEOUS ASCENT DEPTH (IAD).
*****
END INSTANTANEOUS ASCENT DEPTH COMPUTATION PROCEDURE
*****
ALL DONE, RETURN
RETURN
END
END$

```

ANNEX B-3

SUBROUTINE UPDT7
EXPONENTIAL-EXPONENTIAL VERSION
LISTING


```

0059 C    PAN2      ARTERIAL INERT GAS TENSION (FSW)
0059 C    PAO2      ARTERIAL O2 TENSION (FSW)
0060 C    PBOVP     GAS PHASE OVERPRESSURE (FSW)
0061 C    PH2O      PARTIAL PRESSURE OF WATER VAPOR (FSW)
0062 C    PO2       INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0063 C    PTISS     TISSUE DISSOLVED INERT GAS TENSION (FSW)
0064 C    PVC02     VENOUS CO2 PARTIAL PRESSURE (FSW)
0065 C    PYO2      VENOUS O2 PARTIAL PRESSURE (FSW)
0066 C    RAMB      RATE OF AMBIENT PRESSURE CHANGE (FSW/MIN)
0067 C    RATE      RATE OF DEPTH CHANGE (FSW OR MSW/MIN)
0068 C    RINRT     RATE OF INSPIRED INERT GAS TENSION CHANGE (FSW/MIN)
0069 C    SDR       SATURATION-DESATURATION HALFTIME RATIO
0070 C    TC        TIME CHANGE DURING ASCENT (MIN)
0071 C    TI        TIME INTERVAL FOR LINEAR-EXPONENTIAL CROSSOVER (MIN)
0072 C    TNODE     TIME OF MINIMUM OR MAXIMUM TISSUE TENSION (MIN)
0073 C
0074 C
0075 C    NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW=1 ATA.
0076 C
0077 C
0078 C *****
0079 C
0080 C *****
0081 C
0082 C    * SUBROUTINES REQUIRED *
0083 C    *****
0084 C
0085 C
0086 C    NONE
0087 C *****
0088 C
0089 C    MODEL INPUT VARIABLES
0090 C    THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0091 C    MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0092 C    SUBROUTINES.
0093 C
0094 C    COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,PO2,DINC,CF
0095 C
0096 C    MODEL COMMON
0097 C    THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0098 C    THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0099 C
0100 C    COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0101 C    COMMON/BLDVL/PACO2,PH2O,PVC02,PY02,ANBA02,PBOVP
0102 C
0103 C
0104 C    LOGICAL CP02,DESAT
0105 C    REAL M,K,KSAT,KOSAT
0106 C
0107 C *****
0108 C
0109 C    INITIALIZATION PROCEDURE
0110 C
0111 C
0112 C *****
0113 C
0114 C    IF TIME INTERVAL "TC" IS 0 NO UPDATE NEEDED.
0115 C
0116 C    IF(TC.EQ.0.0) RETURN
0117 C

```

```

0118 C      RATES OF AMBIENT PRESSURE CHANGE ALWAYS IN FEET/MIN, CONVERT
0119 C      METRIC RATES TO FEET/MIN. SET RATE TO 0 IF NO DEPTH CHANGE.
0120 C      COMPUTE INITIAL AMBIENT PRESSURE.
0121 C
0122 C      RAMB=CF*RATE
0123 C      IF(DC.EQ.0.) RAMB=0.
0124 C      PAMB=CDEPTH*CF+33
0125 C
0126 C      FOLLOWING VARIABLES DEPEND ON WHETHER CONSTANT OXYGEN PARTIAL
0127 C      PRESSURE OF CONSTANT INERT GAS FRACTION USED, LOGICAL VARIABLE
0128 C      "CP02" IS TRUE FOR CONSTANT P02 OTHERWISE IT'S FALSE.
0129 C
0130 C      IF(CP02) GO TO 30
0131 C      PA02=(PAMB-PH20)*(1-FN2)-AMBA02
0132 C      RINRT=FN2*RAMB
0133 C      GO TO 40
0134 30      PA02=P02*33*(1.0-PH20/PAMB)-AMBA02
0135 C      RINRT=RAMB
0136 40      CONTINUE
0137 C
0138 C*****
0139 C
0140 C      END INITIALIZATION PROCEDURE
0141 C
0142 C*****
0143 C
0144 C
0145 C*****
0146 C
0147 C      TISSUE UPDATE LOOP
0148 C
0149 C      EXECUTE LOOP FOR ALL "NTISS" TISSUES.
0150 C
0151 C*****
0152 C
0153 C      COMPUTE TIME CONSTANTS FOR SATURATING AND DESATURATING TISSUES
0154 C      ("KSAT" AND "KDSAT"). INITIALIZE ARTERIAL INERT GAS TENSION.
0155 C
0156 C      DO 500 I=1,NTISS
0157 C      KSAT=ALOG(2.0)/HLFTK(I)
0158 C      KDSAT=KSAT*SDR(I)
0159 C      PAN2=PAMB-(PA02+PAC02+PH20)
0160 C
0161 C      INITIALIZE TISSUE TENSION TO DEFAULT VALUE.
0162 C
0163 C      PTISS=P(I)
0164 C
0165 C*****
0166 C
0167 C      NODE TIME COMPUTATION PROCEDURE
0168 C
0169 C      THIS PROCEDURE CHECKS TO SEE IF INITIALLY EXPONENTIALLY SATURATING
0170 C      OR DESATURATING TISSUES WILL GO THROUGH A MINIMUM OR MAXIMUM
0171 C      (NODE) DURING THE TIME INTERVAL "TC". IF A NODE OCCURS THE TISSUE
0172 C      TENSIONS ARE UPDATED TO THE TIME OF THE NODE (TNODE) BEFORE GOING
0173 C      TO THE EXPONENTIAL UPDATE PROCEDURE.
0174 C
0175 C      EXITS TO STATEMENT 400
0176 C
0177 C*****

```

```

0178 C
0179 C SET "TI" (TIME REMAINING IN INTERVAL "TC" AFTER NODE HAS OCCURED)
0180 C TO "TC" INITIALLY.
0181 C
0182 C TI=TC
0183 C
0184 C IF TISSUE INERT GAS TENSION GREATER THAN ARTERIAL IT'S
0185 C DESATURATING OTHERWISE IT'S SATURATING ("DESAT" IS FALSE).
0186 C
0187 C DESAT=.FALSE.
0188 C IF(PTISS.GT.PAN2) DESAT=.TRUE.
0189 C
0190 C IF NO DEPTH CHANGE NO NODE WILL OCCUR.
0191 C
0192 C IF(RATE.EQ.0.0) GO TO 400
0193 C
0194 C IF INITIALLY SATURATING AND DESCENDING,NO NODE WILL OCCUR DURING
0195 C "TC" AND TISSUE CONTINUES SATURATING EXPONENTIALLY.
0196 C
0197 C IF(RATE.GT.0 .AND. .NOT.DESAT) GO TO 400
0198 C
0199 C INITIALLY DESATURATING TISSUES UNDERGOING ASCENT HAVE NO NODE.
0200 C TISSUE CONTINUES DESATURATING EXPONENTIALLY.
0201 C
0202 C IF(RATE.LT.0 .AND. DESAT) GO TO 400
0203 C
0204 C COMPUTE TIME AT WHICH NODE WILL OCCUR (TNODE).
0205 C
0206 C K=KSAT
0207 C IF(DESAT) K=KDSAT
0208 C C=(K/RINRT)*(PTISS-PAN2)
0209 C TNODE=(1/K)*ALOG(C+1)
0210 C
0211 C IF "TNODE" GREATER THAN THE TIME INCREMENT "TC" OR IS LESS THAN
0212 C 0.0 THE NODE WILL NOT OCCUR WITHIN THE TIME INTERVAL.
0213 C
0214 C IF(TNODE.GE.TC .OR. TNODE.LE.0.0) GO TO 400
0215 C
0216 C UPDATE "PAN2" TO "TNODE" AND COMPUTE A NEW TIME INTERVAL
0217 C "TI". AT "TNODE" TISSUE AND ARTERIAL INERT GAS TENSION ARE EQUAL
0218 C BY DEFINITION.
0219 C
0220 C PAN2=PAN2+RINRT*TNODE
0221 C TI=TC-TNODE
0222 C PTISS=PAN2
0223 C
0224 C AFTER THE NODE TISSUE GAS TRANSFER IS OPPOSITE TO WHAT IT WAS
0225 C INITIALLY.
0226 C
0227 C DESAT=.NOT.DESAT
0228 C
0229 C*****
0230 C
0231 C END NODE TIME COMPUTATION PROCEDURE
0232 C
0233 C*****
0234 C
0235 C*****
0236 C
0237 C EXPONENTIAL UPDATE PROCEDURE

```

```

0238 C
0239 C*****
0240 400 K=KSAT
0241 IF<DESAT> K=KDSAT
0242 A=PTISS-PAN2+RINRT/K
0243 B=RINRT+TI+PTISS
0244 P<I>=A*(EXP(-K*TI)-1)+B
0245 C
0246 C*****
0247 C
0248 C END EXPONENTIAL UPDATE PROCEDURE
0249 C
0250 C*****
0251 C
0252 C END OF UPDATE, GO UPDATE NEXT TISSUE OR DROP THROUGH TO COMPUTE
0253 C THE INSTANTANEOUS ASCENT DEPTH IF ALL "NTISS" TISSUES HAVE BEEN
0254 C UPDATED.
0255 C
0256 500 CONTINUE
0257 C
0258 C*****
0259 C
0260 C END OF TISSUE UPDATE LOOP
0261 C
0262 C*****
0263 C
0264 C*****
0265 C
0266 C INSTANTANEOUS ASCENT DEPTH COMPUTATION PROCEDURE
0267 C
0268 C START AT 30 DEPTH INCREMENTS AND WORK UP ONE DEPTH INCREMENT AT A
0269 C TIME UNTIL AT LEAST ONE TISSUE TENSION EXCEEDS ITS MAXIMUM
0270 C ALLOWABLE VALUE.
0271 C
0272 C*****
0273 C
0274 C IJ =30
0275 C DO 550 J=1,30
0276 C DO 510 I=1,NTISS
0277 C IF<P<I>,CT.M<I,IJ>> GO TO 600
0278 510 CONTINUE
0279 550 IJ=IJ-1
0280 C
0281 C SUBSCRIPT "IJ" OF ARRAY "M" SPECIFIES NUMBER OF DEPTH INCREMENTS
0282 C FOR THE INSTANTANEOUS ASCENT DEPTH (IAD).
0283 C
0284 600 IAD=DINC=IJ
0285 C
0286 C*****
0287 C
0288 C END INSTANTANEOUS ASCENT DEPTH COMPUTATION PROCEDURE
0289 C
0290 C*****
0291 C
0292 C ALL DONE, RETURN
0293 C
0294 C RETURN
0295 C END
0296 C

```

ANNEX B-4

SUBROUTINE FRSP7
LISTING

&FRSP7 T=00004 IS ON CR00012 USING 00032 BLKS R=0000

```
0001 FTN4
0002 SUBROUTINE FRSP7(DFS), 01 MAR 83 VER 1.2
0003 C
0004 C
0005 C FINDS DEPTH OF FIRST STOP (DFS). TRIAL STOP DEPTH (MIND)
0006 C INITIALLY SET TO CURRENT INSTANTANEOUS ASCENT DEPTH (IAD). A
0007 C TRIAL ASCENT TO "MIND" IS DONE TO SEE IF "IAD" CHANGES DURING
0008 C ASCENT. IF "IAD" CHANGES A NEW TRIAL ASCENT FROM "CDEPTH" TO THE
0009 C NEW "IAD" IS DONE. ITERATION CONTINUES UNTIL THE "IAD" AFTER
0010 C ASCENT AND "MIND" ARE EQUAL.
0011 C
0012 C DEPTH OF FIRST STOP WILL NEVER BE DEEPER THAN THE CURRENT
0013 C DEPTH. IF ASCENTS ALWAYS ACCOMPANIED BY APPROPRIATE DECOMPRESSION
0014 C NO PROBLEMS WILL OCCUR. HOWEVER, IF AN ASCENT IS TAKEN WITHOUT
0015 C DECOMPRESSION STOPS THEN A FIRST STOP DEPTH SOUGHT, THE "IAD" MAY
0016 C BE DEEPER THAN THE CURRENT DEPTH. IN THESE CASES THE FIRST STOP
0017 C DEPTH WILL BE THE CURRENT DEPTH.
0018 C
0019 C
0020 C
0021 C
0022 C WRITTEN BY
0023 C
0024 C CDR EDWARD D. THALMANN (MC) USN
0025 C
0026 C
0027 C U.S. NAVY EXPERIMENTAL DIVING
0028 C UNIT
0029 C PANAMA CITY, FLORIDA 32407
0030 C
0031 C
0032 C
0033 C
0034 C *****
0035 C *****
0036 C * VARIABLES *
0037 C *****
0038 C
0039 C AMBA02 AMBIENT-ARTERIAL OXYGEN GRADIENT (FSW)
0040 C CDEPTH CURRENT DEPTH (FSW OR MSW)
0041 C CF METRIC CONVERSION FACTOR
0042 C CP02 CONSTANT PARTIAL PRESSURE O2?
0043 C DC DEPTH CHANGE (FSW OR MSW)
0044 C DFS DEPTH OF FIRST STOP (FSW OR MSW)
0045 C DINC STOP DEPTH INCREMENTS (FSW OR MSW)
0046 C FN2 INERT GAS FRACTION
0047 C HLFTM COMPARTMENT HALFTIMES (MIN)
0048 C IAD INSTANTANEOUS ASCENT DEPTH (FSW OR MSW)
0049 C IADTMP VARIABLE TO TEMPORARILY STORE CURRENT VALUE OF "IAD".
0050 C LASTIT LAST TIME THROUGH ITERATION LOOP?
0051 C M COMPARTMENT MAXIMUM GAS TENSION ARRAY (FSW)
0052 C MIND TRIAL FIRST STOP DEPTH (FSW OR MSW)
0053 C N Tiss NUMBER OF HALFTIME COMPARTMENTS (9 MAX.)
0054 C P COMPARTMENT GAS TENSION ARRAY (FSW)
0055 C PAC02 ARTERIAL CO2 PARTIAL PRESSURE (FSW)
0056 C PBOVP GAS PHASE OVERPRESSURE (FSW)
0057 C PH2O PARTIAL PRESSURE OF WATER VAPOR (FSW)
0058 C PO2 INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
```

```

0059 C   PVC02      VENOUS CO2 PARTIAL PRESSURE (FSW)
0060 C   PV02       VENOUS O2 PARTIAL PRESSURE (FSW)
0061 C   RATE      RATE OF TRAVEL DURING DEPTH CHANGE (FSW OR MSW/MIN)
0062 C   SDR        SATURATION-DESATURATION HALFTIME RATIO
0063 C   TC         TIME CHANGE DURING ASCENT (MIN)
0064 C   TP         ARRAY TO TEMPORARILY STORE COMPARTMENT GAS TENSIONS
0065 C
0066 C
0067 C   NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW=1 ATA.
0068 C
0069 C
0070 C *****
0071 C
0072 C *****
0073 C   *****
0074 C   * SUBROUTINES REQUIRED *
0075 C   *****
0076 C
0077 C   UPDT7        UPDATES MODEL OVER A SINGLE TIME INTERVAL
0078 C
0079 C *****
0080 C
0081 C   MODEL INPUT VARIABLES
0082 C   THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0083 C   MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0084 C   SUBROUTINES.
0085 C
0086 C   COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF
0087 C
0088 C   MODEL COMMON
0089 C   THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0090 C   THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0091 C
0092 C   COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0093 C   COMMON/BLDVL/PAC02,PH2O,PVCO2,PV02,AMBA02,PBOVP
0094 C
0095 C
0096 C   LOGICAL CP02,LASTIT
0097 C   REAL M
0098 C   DIMENSION TP(9)
0099 C
0100 C *****
0101 C
0102 C   INITIALIZATION PROCEDURE
0103 C
0104 C *****
0105 C
0106 C   INITIALIZE DEPTH OF FIRST STOP TO CURRENT DEPTH. IF "CDEPTH" EQUAL
0107 C   TO OR SHALLOWER THAN "IAD" FIRST STOP IS AT "CDEPTH".
0108 C
0109 C   DFS=CDEPTH
0110 C   IF(INT(CDEPTH) .LE. IAD) RETURN
0111 C
0112 C   INITIALIZE "LAST ITERATION" SWITCH. SAVE TISSUE TENSIONS AND
0113 C   "IAD" TEMPORARILY.
0114 C
0115 C   LASTIT=.FALSE.
0116 C   DO 20 I=1,NTISS
0117 C     TP(I)=P(I)
0118 C     IADTMP=IAD

```

```

0119 C
0120 C*****
0121 C
0122 C          END OF INITIALIZATION
0123 C
0124 C*****
0125 C
0126 C*****
0127 C
0128 C          DEPTH OF FIRST STOP ITERATION LOOP
0129 C
0130 C          ALL EXITS GO TO STATEMENT #50
0131 C
0132 C*****
0133 C          TRY FIRST STOP DEPTH AS "IAD". DEFINITION OF ASCENT CRITERIA
0134 C          REQUIRES THEY BE MET "DINC" DEEPER THAN FINAL FIRST STOP DEPTH.
0135 C
0136 30      MIND=IAD
0137          DC=MIND-CDEPTH+DINC
0138          TC=DC/RATE
0139 C
0140 C          SUBROUTINE UPDT7 WILL COMPUTE NEW "IAD" AFTER TRIAL ASCENT.
0141 C          REESTABLISH TISSUE TENSIONS AFTER CALLING SUBROUTINE UPDT7.
0142 C
0143          CALL UPDT7
0144          DO 32 I=1,NTISS
0145 32      P(I)=TP(I)
0146 C
0147 C          IF "IAD" HASN'T CHANGED OR HAS DECREASED DURING TRIAL ASCENT TO
0148 C          "MIND+DINC" THEN ASCENT TO "MIND" MAY BE POSSIBLE WITHOUT
0149 C          VIOLATING THE ASCENT CRITERIA. GIVE IT A TRY. REESTABLISH TISSUE
0150 C          TENSIONS WHEN DONE.
0151 C
0152          IF(IAD.GT.MIND) GO TO 42
0153          DC=MIND-CDEPTH
0154          TC=DC/RATE
0155          CALL UPDT7
0156          DO 40 I=1,NTISS
0157 40      P(I)=TP(I)
0158 C
0159 C          IF NEW "IAD" AND "MIND" EQUAL AFTER TRIAL ASCENT, WE'RE DONE.
0160 C
0161 42      IF(IAD.EQ.MIND) GO TO 50
0162 C
0163 C          IF NEW "IAD" IS SHALLOWER THAN "MIND" SET "LASTIT" TO TRUE. THIS
0164 C          WILL STOP THE ITERATION IF "IAD" BECOMES GREATER THAN "MIND" THE
0165 C          NEXT TIME AROUND. THIS WILL PREVENT GETTING STUCK IN THE LOOP IF
0166 C          THERE IS A TISSUE STILL SATURATING AT "MIND" IN WHICH CASE "IAD"
0167 C          WILL NEVER EQUAL "MIND" BUT WILL OSCILLATE ONE DEPTH INCREMENT
0168 C          DEEPER AND SHALLOWER ON SUCCESSIVE ITERATIONS. IN THESE CASES THE
0169 C          FIRST STOP DEPTH IS THE FIRST VALUE OF "MIND" WHICH CAUSES "IAD"
0170 C          TO INCREASE IN VALUE AFTER IT HAD DECREASED ON THE PREVIOUS
0171 C          ITERATION.
0172 C
0173          IF(IAD.LT.MIND) LASTIT=.TRUE.
0174          IF(IAD.GT.MIND .AND. LASTIT) GO TO 50
0175 C
0176 C          SET UP FOR ASCENT TO NEW "IAD".
0177 C
0178          GO TO 30

```

```

0179 C
0180 C*****
0181 C
0182 C          END OF ITERATION LOOP
0183 C
0184 C*****
0185 C
0186 C      REESTABLISH "IAD". DEPTH OF FIRST STOP IS "MIND".
0187 C
0188 50      IAD=IADTMP
0189      DFS=MIND
0190      RETURN
0191      END
0192      END*

```

ANNEX B-5

SUBROUTINE STIM7
EXPONENTIAL-LINEAR VERSION
LISTING

```

0001 FTN4 SUBROUTINE STIM7(TIME,SDEPTH), 24 SEPT 82 VER 1.4
0002
0003 C
0004 C EXPONENTIAL-LINEAR VERSION
0005 C
0006 C FINDS THE TIME WHICH NEEDS TO BE SPENT AT "CDEPTH" IN ORDER
0007 C TO ASCEND TO "SDEPTH". "SDEPTH" IS USED TO COMPUTE THE DEPTH (ROW)
0008 C SUBSCRIPT "IJ" FOR ARRAY "M". IF "SDEPTH" IS NOT AN EXACT MULTIPLE
0009 C OF "DINC" "IJ" POINTS TO THE NEXT SHALLOWER DEPTH WHICH IS, IN
0010 C ORDER TO ASCEND TO "SDEPTH" SUFFICIENT TIME MUST BE SPENT AT
0011 C "CDEPTH" SO THAT ALL TISSUE TENSIONS BECOME LESS THAN OR EQUAL TO
0012 C THE MAXIMUM TISSUE TENSIONS IN THE "IJ" ROW OF THE ARRAY "M".
0013 C THE NORMAL MODE IS FOR THE NEXT STOP TO BE ONE "DINC" SHALLOWER
0014 C THAN THE CURRENT DEPTH. WHEN THE NEXT STOP IS MORE THAN ONE "DINC"
0015 C SHALLOWER THE INITIALLY COMPUTED STOP TIME IS SHORTENED TO TAKE
0016 C ADVANTAGE OF THE ADDITIONAL DECOMPRESSION GAINED AFTER THE FIRST
0017 C "DINC" OF ASCENT.
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C
0024 C CDR EDWARD D. THALMANN (MC) USN
0025 C
0026 C
0027 C U.S. NAVY EXPERIMENTAL DIVING
0028 C UNIT
0029 C PANAMA CITY,FLORIDA 32407
0030 C
0031 C
0032 C
0033 C *****
0034 C
0035 C * VARIABLES *
0036 C *****
0037 C
0038 C AMBA02 AMBIENT-ARTERIAL OXYGEN GRADIENT (FSU)
0039 C CDEPTH CURRENT DEPTH (FSU OR MSU)
0040 C CF METRIC CONVERSION FACTOR
0041 C CP02 CONSTANT PARTIAL PRESSURE 02?
0042 C DC DEPTH CHANGE (FSU OR MSU)
0043 C DFS DEPTH OF FIRST STOP (FSU OR MSU)
0044 C DINC STOP DEPTH INCREMENTS (FSU OR MSU)
0045 C FIRSTM FIRST TIME THROUGH OPTIMIZATION PROCEDURE?
0046 C FN2 INERT GAS FRACTION
0047 C HLFTM COMPARTMENT HALFTIMES (MIN)
0048 C IAD INSTANTANEOUS ASCENT DEPTH (FSU OR MSU)
0049 C IADTMP TEMPORARY IAD STORAGE
0050 C IDFS HAS "DFS" EVER BEEN GREATER THAN "SDEPTH"?
0051 C IJ DEPTH (ROW) SUBSCRIPT FOR ARRAY "M".
0052 C KDSAT TIME CONSTANT FOR DESATURATING TISSUE (1/MIN)
0053 C KSAT TIME CONSTANT FOR SATURATING TISSUES (1/MIN)
0054 C M COMPARTMENT MAXIMUM GAS TENSION ARRAY (FSU)
0055 C NTISS NUMBER OF HALFTIME COMPARTMENTS (9 MAX.)
0056 C P COMPARTMENT GAS TENSION ARRAY (FSU)
0057 C PAC02 ARTERIAL CO2 PARTIAL PRESSURE (FSU)

```

```

0050 C      PAMB      AMBIENT PRESSURE (FSW)
0059 C      PAN2      ARTERIAL INERT GAS TENSION (FSW)
0060 C      PAO2      ARTERIAL O2 TENSION (FSW)
0061 C      PBOVP     GAS PHASE OVERPRESSURE (FSW)
0062 C      PH2O      PARTIAL PRESSURE OF WATER VAPOR (FSW)
0063 C      PLIN      INERT GAS TENSION AT END OF LINEAR UPDATE (FSW)
0064 C      PO2       INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0065 C      PVC02     VENOUS CO2 PARTIAL PRESSURE (FSW)
0066 C      PVN2      VENOUS INERT GAS TENSION (FSW)
0067 C      PVO2      VENOUS O2 PARTIAL PRESSURE (FSW)
0068 C      RATE      RATE OF TRAVEL DURING DEPTH CHANGE (FSW OR MSW/MIN)
0069 C      SDEPTH    NEXT DEPTH AFTER STOP (FSW OR MSW)
0070 C      SDR       SATURATION-DESATURATION HALFTIME RATIO
0071 C      T         TRIAL NO DECOMPRESSION TIME (MIN)
0072 C      TC        TIME CHANGE DURING ASCENT (MIN)
0073 C      TDSAT     STOP TIME FOR DESATURATING TISSUE (MIN)
0074 C      TEXP      TIME FOR EXPONENTIAL UPDATE PORTION (MIN)
0075 C      TIME      STOP TIME (MIN)
0076 C      TLIN      TIME FOR LINEAR UPDATE PORTION (MIN)
0077 C      TP        TEMPORARY GAS TENSION STORAGE ARRAY
0078 C      TSAT      STOP TIME FOR SATURATING TISSUE (MIN)
0079 C
0080 C
0081 C      NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW = 1 ATA.
0082 C
0083 C
0084 C*****
0085 C
0086 C*****
0087 C      *****
0088 C      * SUBROUTINES REQUIRED *
0089 C      *****
0090 C
0091 C      UPDT7      UPDATES TISSUE TENSIONS, COMPUTES "IAD"
0092 C      FRSP7     COMPUTES DEPTH OF FIRST STOP
0093 C
0094 C*****
0095 C
0096 C      MODEL INPUT VARIABLES
0097 C      THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0098 C      MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0099 C      SUBROUTINES.
0100 C
0101 C      COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,PO2,DINC,CF
0102 C
0103 C      MODEL COMMON
0104 C      THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0105 C      THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0106 C
0107 C      COMMON/PARAM/N(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0108 C      COMMON/BLDVL/PAC02,PH2O,PVC02,PVO2,AMBA02,PBOVP
0109 C
0110 C
0111 C      LOGICAL CP02,IDF8,FIRSTH
0112 C      REAL M,K,KSAT,KDSAT,TP(9)
0113 C
0114 C*****
0115 C
0116 C      INITIALIZATION PROCEDURE
0117 C

```

```

0118 C*****
0119 C
0120 C      COMPUTE AMBIENT PRESSURE IN FSW.
0121 C
0122 C      PAMB=CDEPTH*CF+33.
0123 C
0124 C      IF CP02 SET USE CONSTANT P02 MODE FOR COMPUTING P02. COMPUTE
0125 C      VENOUS AND ARTERIAL INERT GAS TENSIONS.
0126 C
0127 C      PA02=(PAMB-PH20)*(1-FN2)-AMBA02
0128 C      IF(CP02) PA02=P02*33.*(1.0-PH20/PAMB)-AMBA02
0129 C      PVN2=PAMB-(PV02+PVC02+PH20)+PBOVP
0130 C      PAN2=PAMB-(PA02+PAC02+PH20)
0131 C
0132 C      INITIALIZE SATURATION AND DESATURATION TIMES.
0133 C
0134 C      TDSAT=0.0
0135 C      TSAT=9999.
0136 C
0137 C      COMPUTE DEPTH SUBSCRIPT FOR ARRAY "M" CORRESPONDING TO "SDEPTH".
0138 C
0139 C      IJ=(SDEPTH/DINC)+1
0140 C
0141 C*****
0142 C
0143 C      END OF INITIALIZATION
0144 C
0145 C*****
0146 C
0147 C*****
0148 C
0149 C      TRIAL DESATURATION AND SATURATION STOP TIME COMPUTATION PROCEDURE
0150 C
0151 C      STOP TIME IS THE TIME AT WHICH TISSUE DISSOLVED INERT GAS TENSION
0152 C      (P<I)) EQUALS THE MAXIMUM PERMISSIBLE TENSION AT THE NEXT DESIRED
0153 C      DEPTH. AT A GIVEN STOP SOME TISSUES MAY BE SATURATING, OTHERS
0154 C      DESATURATING. THE STOP TIME IS THE LESSER OF THE SATURATION TIME
0155 C      AND DESATURATION TIME TO THE MAXIMUM VALUE IN ARRAY "M".
0156 C
0157 C*****
0158 C
0159 C      COMPUTE TRIAL SATURATION OR DESATURATION STOP TIME FOR EACH TISSUE
0160 C
0161 C      DO 300 I=1,NTISS
0162 C
0163 C      COMPUTE TIME CONSTANTS FOR SATURATING AND DESATURATING TISSUES.
0164 C
0165 C      KSAT=ALOG(2.0)/HLFTM(I)
0166 C      KDSAT=KSAT*SDR(I)
0167 C
0168 C      IF TISSUE SATURATING GO TO SATURATION TIME COMPUTATION.
0169 C
0170 C      IF(P<I).LE.PAN2) GO TO 100
0171 C
0172 C*****
0173 C
0174 C      FIND TRIAL STOP TIME FOR DESATURATING TISSUES
0175 C
0176 C*****
0177 C

```



```

0178 C      IF TISSUE TENSION LESS THAN THE MAXIMUM PERMISSIBLE TENSION THEN
0179 C      THE TRIAL STOP TIME IS 0.0.
0180 C
0181 C      T=0.0
0182 C      IF(P<I).LE.M(I,IJ)) GO TO 50
0183 C
0184 C      IF ARTERIAL TENSION GREATER THAN MAXIMUM PERMISSIBLE TENSION THEN
0185 C      STOP TIME IS INFINITE (9999 MIN.).
0186 C
0187 C      T=9999.
0188 C      IF(PAN2.GE.M(I,IJ)) GO TO 50
0189 C
0190 C      IF TISSUE TENSION LESS THAN "PVN2" TISSUE IS ALREADY IN THE
0191 C      EXPONENTIAL PORTION OF DESATURATION AND LINEAR PORTION OF THE
0192 C      STOP TIME IS 0.0. THIS IS ACCOMPLISHED BY SETTING "PLIN" TO "P(I)"
0193 C      SO "TLIN" WILL BE COMPUTED AS 0.0.
0194 C
0195 C      IF(P<I).LE.PVN2) PLIN=P(I)
0196 C
0197 C      COMPUTE STOP TIME FOR THE LINEAR PORTION OF DESATURATION. "PLIN"
0198 C      IS THE VALUE OF THE TISSUE TENSION AT THE COMPLETION OF THE LINEAR
0199 C      DESATURATION TO THE MAXIMUM TISSUE TENSION.
0200 C
0201 C      IF(P<I).GT.PVN2) PLIN=PVN2
0202 C      IF(M(I,IJ).GE.PVN2) PLIN=M(I,IJ)
0203 C      TLIN=(1/KDSAT)*(PLIN-P(I))/(PAN2-PVN2))
0204 C
0205 C      IF THE MAXIMUM TISSUE TENSION GREATER THAN "PVN2" NO EXPONENTIAL
0206 C      DESATURATION WILL OCCUR AND EXPONENTIAL PORTION OF THE STOP TIME
0207 C      WILL BE 0.0.
0208 C
0209 C      TEXP=0.0
0210 C      IF(M(I,IJ).GE.PVN2) GO TO 40
0211 C
0212 C      COMPUTE EXPONENTIAL PORTION OF THE STOP TIME.
0213 C
0214 C      TEXP=(1/KDSAT)*ALOG(PLIN-PAN2)/(M(I,IJ)-PAN2))
0215 C
0216 C      DESATURATION STOP TIME IS THE SUM OF THE EXPONENTIAL AND LINEAR
0217 C      TIMES.
0218 C
0219 C      T=TLIN+TEXP
0220 C
0221 C      LARGEST ALLOWABLE TIME IS 9999 MIN. WHICH IS ESSENTIALLY INFINITE.
0222 C
0223 C      IF(T.GT.9999.) T=9999.
0224 C
0225 C      SAVE LARGEST DESATURATION TIME COMPUTED SO FAR.
0226 C
0227 C      TDSAT=AMAX1(TDSAT,T)
0228 C      GO TO 300
0229 C
0230 C      +-----+
0231 C
0232 C      TRIAL STOP TIME COMPUTATION FOR SATURATING TISSUES
0233 C
0234 C      +-----+
0235 C
0236 C      SATURATION TIME IS 0.0 IF TISSUE TENSION ALREADY GREATER THAN THE
0237 C      MAXIMUM PERMISSIBLE VALUE.

```

```

0238 C
0239 100 T=0.0
0240 IF(P<I).GE.M<I,IJ>> GO TO 150
0241 C
0242 C WILL NEVER REACH MAXIMUM VALUE IF ARTERIAL TENSION LESS THAN THE
0243 C MAXIMUM PERMISSIBLE VALUE.
0244 C
0245 T=9999.
0246 IF(PAN2.LE.M<I,IJ>> GO TO 150
0247 C
0248 C COMPUTE SATURATION TIME.
0249 C
0250 T=(1/KSAT)*ALOG((P<I)-PAN2)/(M<I,IJ)-PAN2))
0251 IF(T.LT.0.0) T=0.0
0252 C
0253 C SAVE THE SMALLEST DESATURATION TIME SO FAR THEN GO BACK AND DO
0254 C ANOTHER TISSUE OR DROP THROUGH IF ALL "NTISS" TISSUES DONE.
0255 C
0256 150 TSAT=AMIN1(T,TSAT)
0257 300 CONTINUE
0258 C
0259 C*****
0260 C
0261 C END TRIAL STOP TIME COMPUTATION PROCEDURES
0262 C
0263 C*****
0264 C
0265 C TIME IS LESSER OF SATURATION AND DESATURATION TIME.
0266 C
0267 TIME=AMIN1(TSAT,TDSAT)
0268 C
0269 C IF NEXT DEPTH ONLY "DINC" SHALLOWER WE'RE DONE.
0270 C
0271 IF((CDEPTH-SDEPTH).LE.DINC) RETURN
0272 C
0273 C IF TRIAL STOP TIME 0.0 OR 9999 THEN NO OPTIMIZATION, RETURN.
0274 C
0275 IF(TIME.EQ.0.0 .OR. TIME.GE.9999.) RETURN
0276 C
0277 C*****
0278 C
0279 C STOP TIME OPTIMIZATION PROCEDURE
0280 C
0281 C IF ASCENDING MORE THAN ONE STOP DEPTH INCREMENT AFTER TAKING A
0282 C DECOMPRESSION STOP SOME ADDITIONAL TISSUE OFFGASSING MAY OCCUR
0283 C DURING ASCENT. IF POSSIBLE THE STOP TIME IS SHORTENED UNTIL THE
0284 C DEPTH OF THE FIRST STOP (DFS) AS COMPUTED BY SUBROUTINE FRSP7 IS
0285 C JUST EQUAL TO "SDEPTH". THIS IS DONE BY FIRST SHORTENING THE
0286 C STOP TIME IN 0.1 MIN. INCREMENTS UNTIL "DFS" EXCEEDS "SDEPTH" AND
0287 C THEN SHORTENING THE TIME IN 0.005 MIN. INCREMENTS UNTIL "DFS" JUST
0288 C EQUALS "SDEPTH". THE OPTIMIZED TIME IS THEN 0.005 MIN. TOO LONG AT
0289 C THE MOST.
0290 C
0291 C*****
0292 C
0293 C INITIALIZE LOGICAL VARIABLES.
0294 C
0295 IDFS=.FALSE.
0296 FIRST=.TRUE.
0297 C

```

```

0298 C      STORE TISSUE TENSIONS AND CURRENT "IAD" TEMPORARILY.
0299 C
0300 400    DO 410 I=1,NTISS
0301 410    TP(I)=P(I)
0302      IADTMP=IAD
0303 C
0304 C      DO TRIAL UPDATE AT "CDEPTH" AND FIND DEPTH OF FIRST STOP.
0305 C
0306      DC=0.0
0307      TC=TIME
0308      CALL UPDT7
0309      CALL FRSP7(DFS)
0310 C
0311 C      RESTORE TISSUE TENSIONS AND "IAD".
0312 C
0313      DO 420 I=1,NTISS
0314 420    P(I)=TP(I)
0315      IAD=IADTMP
0316 C
0317 C      IF FIRST STOP BELOW "SDEPTH" TRIAL STOP TIME MAY BE TOO SHORT.
0318 C
0319      IF(DFS.GT.SDEPTH) GO TO 430
0320 C
0321      "FIRSTM" SET TO FALSE AFTER FIRST PASS.
0322 C
0323      FIRSTM=.FALSE.
0324 C
0325 C      IF "IDFS" HAS BEEN SET TO TRUE BY THE PROCEDURE BELOW WE'RE DONE
0326 C      AS SOON AS "DFS" EQUALS "SDEPTH". WE'RE ALSO DONE IF THE TRIAL
0327 C      STOP TIME HAS DECREASED TO 0.0.
0328 C
0329      IF(IDFS .OR. TIME.EQ.0.0) RETURN
0330 C
0331 C      SUBTRACT TIME IN 0.1 MIN INCREMENTS AND REPEAT TRIAL UPDATE UNTIL
0332 C      "DFS" JUST EQUALS "SDEPTH". TIMES LESS THAN 0.0 NOT ALLOWED.
0333 C
0334      TIME=AMAX1((TIME-0.1),0.0)
0335      GO TO 400
0336 C
0337 C      IF WE END UP HERE THE FIRST TIME THROUGH OPTIMIZATION NOT POSSIBLE.
0338 C      AFTER FIRST TIME THROUGH SET "FIRSTM" TO FALSE.
0339 C
0340 430      IF(FIRSTM) RETURN
0341      FIRSTM=.FALSE.
0342 C
0343 C      INCREASE TIME IN 0.005 MIN INCREMENTS UNTIL FIRST STOP DEPTH
0344 C      DECREASES TO "SDEPTH". SETTING "IDFS" TO TRUE CAUSES EXIT FROM THE
0345 C      ITERATION AS SOON AS THIS HAPPENS.
0346 C
0347      TIME=TIME+0.005
0348      IDFS=.TRUE.
0349      GO TO 400
0350 C
0351 C*****
0352 C
0353 C      END OF STOP TIME OPTIMIZATION PROCEDURE
0354 C
0355 C*****
0356      END
0357      END*

```

ANNEX B-6

SUBROUTINE STIM7
EXPONENTIAL-EXPONENTIAL VERSION
LISTING

%STIME T=00004 IS ON CR00012 USING 00051 BLKS R=0000

```
0001 FTM4
0002 SUBROUTINE STIM7(TIME,SDEPTH), 24 SEPT 82 VER 2.1
0003 C
0004 C EXPONENTIAL-EXPONENTIAL VERSION
0005 C
0006 C FINDS THE TIME WHICH NEEDS TO BE SPENT AT "CDEPTH" IN ORDER
0007 C TO ASCEND TO "SDEPTH". "SDEPTH" IS USED TO COMPUTE THE DEPTH (ROW)
0008 C SUBSCRIPT "IJ" FOR ARRAY "M". IF "SDEPTH" IS NOT AN EXACT MULTIPLE
0009 C OF "DINC" "IJ" POINTS TO THE NEXT SHALLOWER DEPTH WHICH IS. IN
0010 C ORDER TO ASCEND TO "SDEPTH" SUFFICIENT TIME MUST BE SPENT AT
0011 C "CDEPTH" SO THAT ALL TISSUE TENSIONS BECOME LESS THAN OR EQUAL TO
0012 C THE MAXIMUM TISSUE TENSIONS IN THE "IJ" ROW OF THE ARRAY "M".
0013 C THE NORMAL MODE IS FOR THE NEXT STOP TO BE ONE "DINC" SHALLOWER
0014 C THAN THE CURRENT DEPTH. WHEN THE NEXT STOP IS MORE THAN ONE "DINC"
0015 C SHALLOWER THE INITIALLY COMPUTED STOP TIME IS SHORTENED TO TAKE
0016 C ADVANTAGE OF THE ADDITIONAL DECOMPRESSION GAINED AFTER THE FIRST
0017 C "DINC" OF ASCENT.
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C
0024 C
0025 C
0026 C
0027 C
0028 C
0029 C
0029 C
0030 C
0031 C
0032 C
0033 C
0034 C *****
0035 C
0036 C
0037 C
0038 C
0039 C AMBA02 AMBIENT-ARTERIAL OXYGEN GRADIENT (FSW)
0040 C CDEPTH CURRENT DEPTH (FSW OR MSW)
0041 C CF METRIC CONVERSION FACTOR
0042 C CP02 CONSTANT PARTIAL PRESSURE O2?
0043 C DC DEPTH CHANGE (FSW OR MSW)
0044 C DFS DEPTH OF FIRST STOP (FSW OR MSW)
0045 C DINC STOP DEPTH INCREMENTS (FSW OR MSW)
0046 C FIRSTM FIRST TIME THROUGH OPTIMIZATION PROCEDURE?
0047 C FN2 INERT GAS FRACTION
0048 C HLFTM COMPARTMENT HALFTIMES (MIN)
0049 C IAD INSTANTANEOUS ASCENT DEPTH (FSW OR MSW)
0050 C IADTMP TEMPORARY IAD STORAGE
0051 C IDFS HAS "DFS" EVER BEEN GREATER THAN "SDEPTH"?
0052 C IJ DEPTH (ROW) SUBSCRIPT FOR ARRAY "M".
0053 C KDSAT TIME CONSTANT FOR DESATURATING TISSUE (1/MIN)
0054 C KSAT TIME CONSTANT FOR SATURATING TISSUES (1/MIN)
0055 C M COMPARTMENT MAXIMUM GAS TENSION ARRAY (FSW)
0056 C NTISS NUMBER OF HALFTIME COMPARTMENTS (9 MAX.)
0057 C P COMPARTMENT GAS TENSION ARRAY (FSW)
```

```

0058 C      PACO2      ARTERIAL CO2 PARTIAL PRESSURE (FSW)
0059 C      PAMB      AMBIENT PRESSURE (FSW)
0060 C      PAN2      ARTERIAL INERT GAS TENSION (FSW)
0061 C      PAO2      ARTERIAL O2 TENSION (FSW)
0062 C      PBOVP     GAS PHASE OVERPRESSURE (FSW)
0063 C      PH2O      PARTIAL PRESSURE OF WATER VAPOR (FSW)
0064 C      PLIN      INERT GAS TENSION AT END OF LINEAR UPDATE (FSW)
0065 C      PO2       INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0066 C      PVC02     VENOUS CO2 PARTIAL PRESSURE (FSW)
0067 C      PV02     VENOUS O2 PARTIAL PRESSURE (FSW)
0068 C      RATE      RATE OF TRAVEL DURING DEPTH CHANGE (FSW OR MSW/MIN)
0069 C      SDEPTH    NEXT DEPTH AFTER STOP (FSW OR MSW)
0070 C      SDR       SATURATION-DESATURATION HALFTIME RATIO
0071 C      T         TRIAL NO DECOMPRESSION TIME (MIN)
0072 C      TC        TIME CHANGE DURING ASCENT (MIN)
0073 C      TDSAT     STOP TIME FOR DESATURATING TISSUE (MIN)
0074 C      TIME      STOP TIME (MIN)
0075 C      TP        TEMPORARY GAS TENSION STORAGE ARRAY
0076 C      TSAT      STOP TIME FOR SATURATING TISSUE (MIN)
0077 C
0078 C
0079 C      NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW = 1 ATA.
0080 C
0081 C
0082 C *****
0083 C
0084 C *****
0085 C      * SUBROUTINES REQUIRED *
0086 C      * SUBROUTINES REQUIRED *
0087 C
0088 C
0089 C      UPDT7      UPDATES TISSUE TENSIONS, COMPUTES "IAD"
0090 C      FRSP7     COMPUTES DEPTH OF FIRST STOP
0091 C
0092 C *****
0093 C
0094 C      MODEL INPUT VARIABLES
0095 C      THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0096 C      MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0097 C      SUBROUTINES.
0098 C
0099 C      COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,PO2,DINC,CF
0100 C
0101 C      MODEL COMMON
0102 C      THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0103 C      THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0104 C
0105 C      COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0106 C      COMMON/BLDVL/PACO2,PH2O,PVC02,PV02,AMB02,PBOVP
0107 C
0108 C
0109 C      LOGICAL CP02,IDS,FIRSTH
0110 C      REAL N,K,KSAT,KDSAT,TP(9)
0111 C
0112 C *****
0113 C
0114 C      INITIALIZATION PROCEDURE
0115 C
0116 C *****
0117 C

```

```

0118 C    COMPUTE AMBIENT PRESSURE IN FSW.
0119 C
0120 C    PAMB=CDEPTH*CF+33.
0121 C
0122 C    IF CP02 SET USE CONSTANT P02 MODE FOR COMPUTING P02. COMPUTE
0123 C    ARTERIAL INERT GAS TENSION.
0124 C
0125 C    PA02=(PAMB-PH20)*(1-FN2)-AMB02
0126 C    IF(CP02) PA02=P02*33.*(1.0-PH20/PAMB)-AMB02
0127 C    PAN2=PAMB-(PA02+PAC02+PH20)
0128 C
0129 C    INITIALIZE SATURATION AND DESATURATION TIMES.
0130 C
0131 C    TDSAT=0.0
0132 C    TSAT=9999.
0133 C
0134 C    COMPUTE DEPTH SUBSCRIPT FOR ARRAY "M" CORRESPONDING TO "SDEPTH".
0135 C
0136 C    IJ=(SDEPTH/DINC)+1
0137 C
0138 C *****
0139 C
0140 C    END OF INITIALIZATION
0141 C
0142 C *****
0143 C
0144 C *****
0145 C
0146 C    TRIAL DESATURATION AND SATURATION STOP TIME COMPUTATION PROCEDURE
0147 C
0148 C    STOP TIME IS THE TIME AT WHICH TISSUE DISSOLVED INERT GAS TENSION
0149 C    (P(I)) EQUALS THE MAXIMUM PERMISSIBLE TENSION AT THE NEXT DESIRED
0150 C    DEPTH. AT A GIVEN STOP SOME TISSUES MAY BE SATURATING, OTHERS
0151 C    DESATURATING. THE STOP TIME IS THE LESSER OF THE SATURATION TIME
0152 C    AND DESATURATION TIME TO THE MAXIMUM VALUE IN ARRAY "M".
0153 C
0154 C *****
0155 C
0156 C    COMPUTE TRIAL SATURATION OR DESATURATION STOP TIME FOR EACH TISSUE
0157 C
0158 C    DO 300 I=1,NTISS
0159 C
0160 C    COMPUTE TIME CONSTANTS FOR SATURATING AND DESATURATING TISSUES.
0161 C
0162 C    KSAT=ALOG(2.0)/HLFTM(I)
0163 C    KDSAT=KSAT*SDR(I)
0164 C
0165 C    IF TISSUE SATURATING GO TO SATURATION TIME COMPUTATION.
0166 C
0167 C    IF(P(I).LE.PAN2) GO TO 100
0168 C
0169 C *****
0170 C
0171 C    FIND TRIAL STOP TIME FOR DESATURATING TISSUES
0172 C
0173 C *****
0174 C
0175 C    IF TISSUE TENSION LESS THAN THE MAXIMUM PERMISSIBLE TENSION THEN
0176 C    THE TRIAL STOP TIME IS 0.0.
0177 C

```

```

0178      T=0.0
0179      IF(P(I).LE.M(I,IJ)) GO TO 50
0180 C
0181 C      IF ARTERIAL TENSION GREATER THAN MAXIMUM PERMISSIBLE TENSION THEN
0182 C      STOP TIME IS INFINITE (9999 MIN.).
0183 C
0184      T=9999.
0185      IF(PAN2.GE.M(I,IJ)) GO TO 50
0186 C
0187 C      COMPUTE SATURATION STOP TIME.
0188 C
0189      T=(1/KDSAT)*ALOG((P(I)-PAN2)/(M(I,IJ)-PAN2))
0190 C
0191 C      LARGEST ALLOWABLE TIME IS 9999 MIN. WHICH IS ESSENTIALLY INFINITE.
0192 C
0193      IF(T.GT.9999.) T=9999.
0194 C
0195 C      SAVE LARGEST DESATURATION TIME COMPUTED SO FAR.
0196 C
0197 50      TDSAT=AMAX1(TDSAT,T)
0198      GO TO 300
0199 C
0200 C*****
0201 C
0202 C      TRIAL STOP TIME COMPUTATION FOR SATURATING TISSUES
0203 C
0204 C*****
0205 C
0206 C      SATURATION TIME IS 0.0 IF TISSUE TENSION ALREADY GREATER THAN THE
0207 C      MAXIMUM PERMISSIBLE VALUE.
0208 C
0209 100      T=0.0
0210      IF(P(I).GE.M(I,IJ)) GO TO 150
0211 C
0212 C      WILL NEVER REACH MAXIMUM VALUE IF ARTERIAL TENSION LESS THAN THE
0213 C      MAXIMUM PERMISSIBLE VALUE.
0214 C
0215      T=9999.
0216      IF(PAN2.LE.M(I,IJ)) GO TO 150
0217 C
0218 C      COMPUTE SATURATION TIME.
0219 C
0220      T=(1/KSAT)*ALOG((P(I)-PAN2)/(M(I,IJ)-PAN2))
0221      IF(T.LT.0.0) T=0.0
0222 C
0223 C      SAVE THE SMALLEST DESATURATION TIME SO FAR.
0224 C
0225 150      TSAT=AMIN1(T,TSAT)
0226 C
0227 C      END OF LOOP. GO BACK AND DO ANOTHER TISSUE OR DROP THROUGH IF ALL
0228 C      "NTISS" TISSUES DONE.
0229 C
0230 300      CONTINUE
0231 C
0232 C*****
0233 C
0234 C      END TRIAL STOP TIME COMPUTATION PROCEDURES
0235 C
0236 C*****
0237 C

```



```

0238 C    TIME IS LESSER OF SATURATION AND DESATURATION TIME.
0239 C
0240 C    TIME=AMIN1(TSAT,TDSAT)
0241 C
0242 C    IF NEXT DEPTH ONLY "DINC" SHALLOWER WE'RE DONE.
0243 C
0244 C    IF<(CDEPTH-SDEPTH).LE.DINC) RETURN
0245 C
0246 C    IF TRIAL STOP TIME 0.0 OR 9999 THEN NO OPTIMIZATION, RETURN.
0247 C
0248 C    IF<TIME.EQ.0.0 .OR. TIME.GE.9999.) RETURN
0249 C
0250 C *****
0251 C
0252 C                STOP TIME OPTIMIZATION PROCEDURE
0253 C
0254 C    IF ASCENDING MORE THAN ONE STOP DEPTH INCREMENT AFTER TAKING A
0255 C    DECOMPRESSION STOP SOME ADDITIONAL TISSUE OFFGASSING MAY OCCUR
0256 C    DURING ASCENT. IF POSSIBLE THE STOP TIME IS SHORTENED UNTIL THE
0257 C    DEPTH OF THE FIRST STOP (DFS) AS COMPUTED BY SUBROUTINE FRSP7 IS
0258 C    JUST EQUAL TO "SDEPTH". THIS IS DONE BY FIRST SHORTENING THE
0259 C    STOP TIME IN 0.1 MIN. INCREMENTS UNTIL "DFS" EXCEEDS "SDEPTH" AND
0260 C    THEN SHORTENING THE TIME IN 0.005 MIN. INCREMENTS UNTIL "DFS" JUST
0261 C    EQUALS "SDEPTH". THE OPTIMIZED TIME IS THEN 0.005 MIN. TOO LONG AT
0262 C    THE MOST.
0263 C
0264 C *****
0265 C
0266 C    INITIALIZE LOGICAL VARIABLES.
0267 C
0268 C    IDFS=.FALSE.
0269 C    FIRSTN=.TRUE.
0270 C
0271 C    STORE TISSUE TENSIONS AND CURRENT "IAD" TEMPORARILY.
0272 C
0273 C    DO 410 I=1,NTISS
0274 C    410 TP(I)=P(I)
0275 C    IADTMP=IAD
0276 C
0277 C    DO TRIAL UPDATE AT "CDEPTH" AND FIND DEPTH OF FIRST STOP.
0278 C
0279 C    DC=0.0
0280 C    TC=TIME
0281 C    CALL UPDT7
0282 C    CALL FRSP7(DFS)
0283 C
0284 C    RESTORE TISSUE TENSIONS AND "IAD".
0285 C
0286 C    DO 420 I=1,NTISS
0287 C    420 P(I)=TP(I)
0288 C    IAD=IADTMP
0289 C
0290 C    IF FIRST STOP BELOW "SDEPTH" TRIAL STOP TIME MAY BE TOO SHORT.
0291 C
0292 C    IF<DFS.GT.SDEPTH) GO TO 430
0293 C
0294 C    "FIRSTN" SET TO FALSE AFTER FIRST PASS.
0295 C
0296 C    FIRSTN=.FALSE.
0297 C

```

```

0298 C      IF "IDFS" HAS BEEN SET TO TRUE BY THE PROCEDURE BELOW WE'RE DONE
0299 C      AS SOON AS "DFS" EQUALS "SDEPTH". WE'RE ALSO DONE IF THE TRIAL
0300 C      STOP TIME HAS DECREASED TO 0.0.
0301 C
0302 C      IF(IDFS .OR. TIME.EQ.0.0) GO TO 440
0303 C
0304 C      SUBTRACT TIME IN 0.1 MIN INCREMENTS AND REPEAT TRIAL UPDATE UNTIL
0305 C      "DFS" JUST EQUALS "SDEPTH". TIMES LESS THAN 0.0 NOT ALLOWED.
0306 C
0307 C      TIME=AMAX1((TIME-0.1),0.0)
0308 C      GO TO 400
0309 C
0310 C      IF WE END UP HERE THE FIRST TIME THROUGH OPTIMIZATION NOT POSSIBLE.
0311 C      AFTER FIRST TIME THROUGH SET "FIRSTM" TO FALSE.
0312 C
0313 C      430 IF(FIRSTM) RETURN
0314 C      FIRSTM=.FALSE.
0315 C
0316 C      INCREASE TIME IN 0.005 MIN INCREMENTS UNTIL FIRST STOP DEPTH
0317 C      DECREASES TO "SDEPTH". SETTING "IDFS" TO TRUE CAUSES EXIT FROM THE
0318 C      ITERATION AS SOON AS THIS HAPPENS.
0319 C
0320 C      TIME=TIME+0.005
0321 C      IDFS=.TRUE.
0322 C      GO TO 400
0323 C
0324 C*****
0325 C
0326 C      END OF STOP TIME OPTIMIZATION PROCEDURE
0327 C
0328 C*****
0329 C
0330 C      EXIT SUBROUTINE.
0331 C
0332 C      440 RETURN
0333 C      END
0334 C      ENDS

```

ANNEX B-7

SUBROUTINE NLIM7
LISTING


```

0058 C PAN2 ARTERIAL INERT GAS TENSION (FSW)
0059 C PAO2 ARTERIAL O2 TENSION (FSW)
0060 C PBOVP GAS PHASE OVERPRESSURE (FSW)
0061 C PH2O PARTIAL PRESSURE OF WATER VAPOR (FSW)
0062 C PO2 INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0063 C PVC02 VENOUS CO2 PARTIAL PRESSURE (FSW)
0064 C PYO2 VENOUS O2 PARTIAL PRESSURE (FSW)
0065 C RATE RATE OF TRAVEL DURING DEPTH CHANGE
0066 C SDR SATURATION-DESATURATION HALFTIME RATIO
0067 C T TRIAL NO DECOMPRESSION TIME (MIN)
0068 C TC TIME CHANGE DURING ASCENT (MIN)
0069 C TIME NO DECOMPRESSION TIME (MIN)
0070 C TP ARRAY TO TEMPORARILY STORE COMPARTMENT GAS TENSIONS
0071 C
0072 C
0073 C NOTE: FOR PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW=1 ATA.
0074 C
0075 C
0076 C *****
0077 C
0078 C *****
0079 C *****
0080 C * SUBROUTINES REQUIRED *
0081 C *****
0082 C
0083 C FRSP? COMPUTES DEPTH OF FIRST STOP
0084 C UPDT? UPDATES MODEL OVER A SINGLE TIME INTERVAL
0085 C
0086 C *****
0087 C
0088 C MODEL INPUT VARIABLES
0089 C THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
0090 C MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
0091 C SUBROUTINES.
0092 C
0093 C COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF
0094 C
0095 C MODEL COMMON
0096 C THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0097 C THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0098 C
0099 C COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0100 C COMMON/BLDVL/PAC02,PH2O,PVC02,PY02,AMBA02,PBOVP
0101 C
0102 C
0103 C LOGICAL CP02,IDFS
0104 C REAL M
0105 C DIMENSION TP(9)
0106 C
0107 C *****
0108 C
0109 C INITIALIZATION PROCEDURE
0110 C
0111 C *****
0112 C
0113 C IDFS=.FALSE.
0114 C PAMB=CDEPTH*CF+33.
0115 C PA02=(PAMB-PH2O)*(1-FN2)-AMBA02
0116 C
0117 C IF CP02 SET USE CONSTANT P02 MODE

```

```

0118 C
0119 IF(CP02) PA02=P02*33.*(1.0-PH20/PAMB)-AMB02
0120 PAN2=PAMB-(PA02+PAC02+PH20)
0121 C
0122 C START BY ASSUMING NO DECOMPRESSION TIME ESSENTIALLY INFINITE.
0123 C
0124 C TIME=9999.
0125 C
0126 C *****
0127 C
0128 C END OF INITIALIZATION
0129 C
0130 C *****
0131 C
0132 C *****
0133 C
0134 C TRIAL NO-DECOMPRESSION TIME COMPUTATION PROCEDURE
0135 C
0136 C FIND TIME REQUIRED FOR EACH TISSUE TO SATURATE TO ITS MAXIMUM
0137 C SURFACING TENSION "M(I,1)". TRIAL NO DECOMPRESSION TIME IS THE
0138 C SHORTEST TIME FOR ANY TISSUE TO REACH THIS VALUE.
0139 C
0140 C *****
0141 C
0142 C DO 10 I=1,NTISS
0143 C
0144 C IF TISSUE TENSION GREATER THAN SURFACING MAX. , NO-DECOMPRESSION
0145 C TIME IS 0.0 .
0146 C
0147 C T=0.0
0148 C IF(P(I).GE.M(I,1)) GO TO 9
0149 C
0150 C IF ARTERIAL INERT GAS TENSION LESS THAN SURFACING MAX. TISSUE CAN
0151 C SATURATE AT "CDEPTH" AND STILL BE WITHIN NO-DECOMPRESSION LIMITS.
0152 C
0153 C T=9999.
0154 C IF(PAN2 .LE.M(I,1))GO TO 9
0155 C
0156 C COMPUTE "A". SHOULD NEVER BE LESS THAN 1.0 UNLESS ROUND OFF ERROR.
0157 C
0158 C A=(P(I)-PAN2)/(M(I,1)-PAN2)
0159 C IF(A.LT.1.0) A=1.0
0160 C
0161 C COMPUTE "T" FOR THIS TISSUE, SAVE SHORTEST TIME COMPUTED SO FAR.
0162 C
0163 C T=(HLFTM(I)/ALOG(2.))*ALOG(A)
0164 C TIME=AMIN1(TIME,T)
0165 C 10 CONTINUE
0166 C
0167 C *****
0168 C
0169 C DONE FINDING TRIAL MINIMUM SATURATION TIME
0170 C
0171 C *****
0172 C
0173 C STORE CURRENT "IAD" TEMPORARILY.
0174 C
0175 C IADTMP=IAD
0176 C
0177 C IF "TIME" IS 9999, OR 0.0 NO OPTIMIZATION POSSIBLE, DONE.

```

```

0178 C
0179 IF<TIME.GE.9999, .OR. TIME.EQ.0.0> GO TO 40
0180 C
0181 C*****
0182 C
0183 C          NO-DECOMPRESSION TIME OPTIMIZATION PROCEDURE
0184 C
0185 C      DO TRIAL TISSUE UPDATE AT "CDEPTH". FIND THE DEPTH OF THE FIRST
0186 C      STOP, ADJUST TRIAL NO-D TIME AND CONTINUE ITERATING UNTIL LONGEST
0187 C      POSSIBLE NO-D TIME FOUND.
0188 C
0189 C*****
0190 C
0191 C      STORE TISSUE TENSIONS TEMPORARILY IN ARRAY "TP".
0192 C
0193 15      DO 16 I=1,NTISS
0194 16      TP(I)=P(I)
0195 C
0196 C      DO TRIAL UPDATE AT "CDEPTH" AND FIND DEPTH OF FIRST STOP.
0197 C
0198 C          DC=0.0
0199 C          TC=TIME
0200 C          CALL UPDT7
0201 C          CALL FRSP7<DFS>
0202 C
0203 C      RESTORE TISSUE TENSIONS
0204 C
0205 C          DO 25 I=1,NTISS
0206 25      P(I)=TP(I)
0207 C
0208 C      IF FIRST STOP AT OR BELOW "DINC" TRIAL NO-D TIME TOO LONG.
0209 C
0210 C          IF<DFS .GE. DINC > GO TO 30
0211 C
0212 C      ADD TIME IN 0.1 MIN INCREMENTS UNTIL FIRST STOP DEPTH INCREASES TO
0213 C      "DINC". THEN REPEAT TRIAL UPDATE. IF "IDFS" HAS BEEN SET TO TRUE
0214 C      BY PROCEDURE BELOW THEN WE'RE DONE.
0215 C
0216 C
0217 C          IF<IDFS> GO TO 40
0218 C          TIME=TIME+0.1
0219 C          GO TO 15
0220 C
0221 C      DECREASE TIME IN 0.005 MIN INCREMENTS UNTIL FIRST STOP DEPTH
0222 C      DECREASES TO 0. SETTING "IDFS" TO TRUE CAUSES EXIT FROM ITERATION
0223 C      AS SOON AS THIS HAPPENS. NEGATIVE TIMES NOT ALLOWED.
0224 C
0225 30      IDFS=.TRUE.
0226 C          TIME=AMAX1(<TIME-0.005>,0.0)
0227 C
0228 C      IF "TIME" HAS DECREASED TO ZERO NO-D NOT POSSIBLE, DONE.
0229 C
0230 C          IF<TIME.EQ.0.0> GO TO 40
0231 C          GO TO 15
0232 C
0233 C*****
0234 C
0235 C      END OF NO-DECOMPRESSION TIME OPTIMIZATION PROCEDURE
0236 C
0237 C*****

```

```
0238 C
0239 C   RESTORE "IAD" AND EXIT.
0240 C
0241 40   IAD=IADTNP
0242     RETURN
0243     END
0244     END$
```


ANNEX B-8

SUBROUTINE INIT7
LISTING

```

0001 FTN4
0002 SUBROUTINE INIT7 , 24 SEPT 82 VER 1.1
0003 C
0004 C
0005 C INITIALIZES TISSUE TENSIONS BY SATURATING THEM AT "CDEPTH".
0006 C
0007 C
0008 C
0009 C
0010 C
0011 C
0012 C
0013 C
0014 C
0015 C
0016 C
0017 C
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C
0024 C
0025 C
0026 C
0027 C
0028 C
0029 C
0030 C
0031 C
0032 C
0033 C
0034 C
0035 C
0036 C
0037 C
0038 C
0039 C
0040 C
0041 C
0042 C
0043 C
0044 C
0045 C
0046 C
0047 C
0048 C
0049 C
0050 C
0051 C
0052 C
0053 C
0054 C
0055 C
0056 C
0057 C

```

```

0058 C
0059 C
0060 C
0061 C
0062 C
0063 C
0064 C
0065 C
0066 C
0067 C
0068 C
0069 C
0070 C
0071 C
0072 C
0073 C
0074 C
0075 C
0076 C
0077 C
0078 C
0079 C
0080 C
0081 C
0082 C
0083 C
0084 C
0085 C
0086 C
0087 C
0088 C
0089 C
0090 C
0091 C
0092 C
0093 C
0094 C
0095 C
0096 C
0097 C
0098 C
0099 C
0100 C
0101 C
0102 C
0103 C
0104 C
0105 C
0106 C
0107 C
0108 C

```

* SUBROUTINES REQUIRED *

NONE

MODEL INPUT VARIABLES

THESE ARE THE ONLY VARIABLES SENT FROM THE MAIN PROGRAM TO THE
MODEL SUBROUTINES. THIS COMMON STATEMENT MUST APPEAR IN ALL MODEL
SUBROUTINES.

COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF

MODEL COMMON

THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.

COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
COMMON/BLDVL/PAC02,PH20,PVC02,PV02,AMBA02,PS0VP

LOGICAL CP02
REAL M

BEGIN INITIALIZATION

COMPUTE AMBIENT PRESSURE AND ARTERIAL O2 PARTIAL PRESSURE.

PAMB= CDEPTH*CF+33.
PA02=(PAMB-PH20)*(1-FN2)-AMBA02
IF(CP02) PA02=P02+33.*(1.0-PH20/PAMB)-AMBA02

SATURATE ALL COMPARTMENTS AT "CDEPTH".

DO 100 I=1,NTISS
P(I)=PAMB-(PA02+PAC02+PH20)
RETURN

END OF INITIALIZATION

END
ENDS

ANNEX B-9

SUBROUTINE RCRD7
LISTING

%RCRD7 T=00004 IS ON CR00013 USING 00021 BLKS R=0000

```
0001 FTM4
0002 SUBROUTINE RCRD7(MODE,CNTR,LP), 24 SEPT 82 VER 1.1
0003 C
0004 C
0005 C RECORDS TISSUE TENSIONS, ZERO TIME AND GAS TENSION IN ARRAY "TT"
0006 C FOR LATER PRINTOUT. WILL ALSO PRINT ARRAY "TT".
0007 C
0008 C
0009 C
0010 C
0011 C
0012 C
0013 C
0014 C
0015 C
0016 C
0017 C
0018 C
0019 C
0020 C
0021 C
0022 C
0023 C*****
0024 C
0025 C
0026 C
0027 C
0028 C CDEPTH CURRENT DEPTH
0029 C CF METRIC CONVERSION FACTOR
0030 C CPO2 CONSTANT PARTIAL PRESSURE 02?
0031 C CNTR ARRAY "TT" SUSCRIPT
0032 C DC DEPTH CHANGE
0033 C DINC STOP DEPTH INCREMENTS
0034 C FN2 INERT GAS FRACTION
0035 C HLFTM COMPARTMENT HALFTIMES (MIN)
0036 C IAD INSTANTANEOUS ASCENT DEPTH (FSW OR MSW)
0037 C LP DEVICE NUMBER OF LINE PRINTER
0038 C M COMPARTMENT MAXIMUM GAS TENSION ARRAY (FSW)
0039 C MODE IF "0" RECORD, IF "1" PRINTOUT
0040 C N Tiss NUMBER OF HALFTIME COMPARTMENTS (9 MAX.)
0041 C P COMPARTMENT GAS TENSION ARRAY (FSW)
0042 C PO2 INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0043 C RATE RATE OF TRAVEL DURING DEPTH CHANGE
0044 C SDR SATURATION-DESATURATION HALFTIME RATIO
0045 C TC TIME CHANGE DURING ASCENT (MIN)
0046 C TT MODEL PROFILE PARAMETER ARRAY
0047 C
0048 C
0049 C NOTE: ALL PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW = 1 ATA.
0050 C
0051 C
0052 C*****
0053 C
0054 C*****
0055 C
0056 C
0057 C
```

```

0058 C
0059 C
0060 C
0061 C*****
0062 C
0063 C
0064 C
0065 C
0066 C
0067 C
0068 C
0069 C
0070 C
0071 C
0072 C
0073 C
0074 C
0075 C
0076 C
0077 C
0078 C
0079 C
0080 C
0081 C
0082 C*****
0083 C
0084 C
0085 C
0086 C*****
0087 C
0088 C
0089 C
0090 C
0091 C
0092 C*****
0093 C
0094 C
0095 C
0096 C
0097 C
0098 C
0099 C*****
0100 C
0101 C
0102 C
0103 C
0104 C
0105 C
0106 C
0107 C
0108 C
0109 C
0110 C
0111 C
0112 C
0113 C
0114 C
0115 C
0116 C
0117 C

```

NONE

MODEL INPUT VARIABLES

THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.

```

COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF
COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
LOGICAL CP02
REAL M,TT(11,100)
INTEGER CNTR
DATA TT/1100*0.0/
FORMAT(9F13.5,2F8.2)
FORMAT(/,9(6X,13" MIN" )/
*9(5X,F4.2" SDR"),4X,"TIME"4X"GAS"/)
*****
BEGIN
*****
IF "MODE" IS 1 GO TO OUTPUT PROCEDURE.
IF(MODE.EQ.1) GO TO 200
*****
RECORDING PROCEDURE
AUTOMATICALLY INCREMENTS "CNTR" EACH TIME AN ENTRY INTO ARRAY "TT"
IS MADE.
*****
RECORD TISSUE TENSIONS
DO 100 I=1,NTISS
TT(I,CNTR)=P(I)
RECORD ZERO TIME. ZERO TIME FOR FIRST ENTRY (CNTR=1) IS 0.
IF(CNTR.EQ.1) GO TO 110
TT(10,CNTR)=TC+TT(10,CNTR-1)
RECORD GAS TENSION. VALUE DEPENDS OF WHETHER CONSTANT P02
CONSTANT INERT GAS TENSION BEING USED.
TT(11,CNTR)=FN2*100.
IF( CP02 ) TT(11,CNTR)=P02
INCREMENT COUNTER TO NEXT ENTRY POSITION BEFORE RETURNING.

```

```

0118 C
0119 CNTR=CNTR+1
0120 RETURN
0121 C
0122 C*****
0123 C
0124 C          END RECORDING PROCEDURE
0125 C
0126 C*****
0127 C
0128 C*****
0129 C
0130 C          PRINTOUT PROCEDURE
0131 C
0132 C          PRINTOUT ARRAY "TT" THEN RETURN.
0133 C
0134 C*****
0135 C
0136 200  WRITE(LP,2) HLFTH,SDR
0137      DO 210 J=1,CNTR-1
0138 210  WRITE(LP,1)(TT(I,J),I=1,11)
0139      RETURN
0140 C
0141 C*****
0142 C
0143 C          END PRINTOUT PROCEDURE
0144 C
0145 C*****
0146      END
0147      END$

```

ANNEX B-10

SUBROUTINE RDIN7
LISTING

RDIN7 T=00004 IS ON CR00012 USING 00038 BLKS R=0000

```
0001 FTH4
0002 SUBROUTINE RDIN7<LU,LP,IFILE,METRIC,IGAS,IPRT>, 24 SEPT 82 VER 1.1
0003 C
0004 C
0005 C
0006 C READS IN SUB-FILE OF MODEL INPUT PARAMETER FILE "IFILE" CONTAINING
0007 C MODEL PARAMETERS IN THE SPECIFIED DEPTH UNITS AND STOP DEPTH
0008 C INCREMENTS. PRINTS OUT MODEL INPUT PARAMETERS AND THE VALUES
0009 C IN COMMON BLOCK "BLDVL" IF DESIRED.
0010 C
0011 C
0012 C
0013 C
0014 C
0015 C
0016 C CDR EDWARD D. THALMANN (MC) USN
0017 C
0018 C
0019 C U.S. NAVY EXPERIMENTAL DIVING
0020 C UNIT
0021 C PANAMA CITY,FLORIDA 32407
0022 C
0023 C
0024 C
0025 C
0026 C*****
0027 C
0028 C * VARIABLES *
0029 C *****
0030 C
0031 C *
0032 C VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0033 C OPERATING SYSTEM
0034 C
0035 C ANBA02 AMBIENT-ARTERIAL OXYGEN GRADIENT (FSW)
0036 C CDEPTH CURRENT DEPTH
0037 C CF METRIC CONVERSION FACTOR
0038 C CPO2 CONSTANT PARTIAL PRESSURE O2?
0039 C DC DEPTH CHANGE
0040 C DINC STOP DEPTH INCREMENTS
0041 C FN2 INERT GAS FRACTION
0042 C HLFTM TISSUE HALFTIMES (MIN)
0043 C IAD INSTANTANEOUS ASCENT DEPTH (FSW OR MSW)
0044 C *IBUF MEMORY ARRAY FOR HOLDING DISK FILE DATA
0045 C *IDCB INPUT BUFFER ASSOCIATED WITH DISK FILE "IFILE"
0046 C IDINC INTEGERIZED VALUE OF "DINC"
0047 C IDPTH INTEGERIZED DEPTH
0048 C *IERR RTE IV-B OPERATING SYSTEM ERROR CODE
0049 C IFILE INPUT FILE NAME
0050 C IGAS ARRAY FOR HOLDING INERT GAS LABEL
0051 C *IL SPECIFIED NUMER OF CHARACTERS TO BE READ FROM FILE
0052 C IMODE DEPTH UNITS DESIRED BY CALLING PROGRAM
0053 C INCR STOP DEPTH INCREMENT OF MODEL PARAMETER SUB-FILE
0054 C IPRT PRINTOUT DESIRED IF=1
0055 C *LEN ACTUAL NUMBER OF CHARACTERS READ FROM DISK FILE
0056 C LP DEVICE NUMBER OF LINE PRINTER
0057 C LU DEVICE NUMBER OF TERMINAL
```

```

0059 C      M      MAXIMUM TISSUE GAS TENSION ARRAY (FSW)
0059 C      METRIC  DEPTH UNITS IN METERS?
0060 C      MODE   DEPTH UNITS OF MODEL PARAMETER SUB-FILE
0061 C      NTISS  NUMBER OF HALFTIME TISSUES (9 MAX.)
0062 C      P      TISSUE GAS TENSION ARRAY (FSW)
0063 C      PACO2   ARTERIAL CO2 PARTIAL PRESSURE (FSW)
0064 C      PAMB    AMBIENT PRESSURE (FSW)
0065 C      PAO2    ARTERIAL O2 TENSION (FSW)
0066 C      PBOVP   GAS PHASE OVERPRESSURE (FSW)
0067 C      PH2O    PARTIAL PRESSURE OF WATER VAPOR (FSW)
0068 C      PO2     INSPIRED OXYGEN PARTIAL PRESSURE (ATA)
0069 C      PVC02   VENOUS CO2 PARTIAL PRESSURE (FSW)
0070 C      PV02    VENOUS O2 PARTIAL PRESSURE (FSW)
0071 C      RATE    RATE OF TRAVEL DURING DEPTH CHANGE (FSW OR MSW MIN)
0072 C      SDR     SATURATION-DESATURATION HALFTIME RATIO
0073 C      TC      TIME CHANGE DURING ASCENT (MIN)
0074 C      UNITS   DEPTH UNITS OF MODEL PARAMETER SUB-FILE
0075 C
0076 C
0077 C      NOTE: ALL PARTIAL PRESSURES WHICH ARE IN FSW. 33 FSW = 1 ATA.
0078 C
0079 C
0080 C *****
0081 C
0082 C *****
0083 C      * * * * *
0084 C      * SUBROUTINES REQUIRED *
0085 C      * * * * *
0086 C
0087 C
0088 C      * HEWLETT PACKARD RTE IV-B OPERATING SYSTEM SUBROUTINES
0089 C      AND FUNCTIONS
0090 C
0091 C      *CLOSE  CLOSES SPECIFIED DISK FILE
0092 C      *CODE   ALLOWS FOLLOWING READ TO OCCUR FROM MEMORY BUFFER
0093 C      *FMPER  DECODES AND PRINTS RTE IV-B ERROR CODES ON ERROR
0094 C      *OPEN   OPENS SPECIFIED DISK FILE
0095 C      *READF  READS DATA FROM DISK FILE INTO MEMORY BUFFER
0096 C
0097 C *****
0098 C
0099 C      MODEL INPUT VARIABLES
0100 C      THESE VARIABLES ARE SENT BETWEEN MODEL SUBROUTINES ONLY.
0101 C      THESE COMMON STATEMENTS MUST APPEAR IN ALL MODEL SUBROUTINES.
0102 C
0103 C      COMMON/MDATA/ TC,DC,CDEPTH,RATE,CP02,FN2,P02,DINC,CF
0104 C      COMMON/PARAM/M(9,30),P(9),HLFTM(9),NTISS,SDR(9),IAD
0105 C      COMMON/BLDVL/PACO2,PH2O,PVC02,PV02,AMB02,PBOVP
0106 C
0107 C
0108 C      LOGICAL CP02,METRIC
0109 C      REAL M,IGAS(3),UNITS(2)
0110 C      INTEGER IDCB(144),IFILE(3),IBUF(36)
0111 C
0112 C
0113 C      DATA IL/36/,UNITS/4H FSW,4H MSW/
0114 C
0115 C
0116 C      FORMAT(9F7.2,I9)
0117 C      FORMAT(9F8.3)

```

```

0118 12  FORMAT(2I9,3A4)
0119 13  FORMAT(6//,33X"TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS"/
0120      *33X      "-----"/
0121      *45X      "(<'3A2"-- '3A4')*2/
0122      *46X      "TISSUE HALF-TIMES"2/
0123      *5X      DEPTH "9<16" MIN"))
0124 14  FORMAT(13X,9<F6.2" SDR"))
0125 15  FORMAT(
0126      *5X"-----
0127      *3X"-----)
0128 16  FORMAT(I9,A4,9F10.3)
0129 17  FORMAT(2//,43X,"BLOOD PARAMETERS",//,35X"(PRESSURE IN FSW; 33 FSW=1
0130      * ATA)"/)
0131 18  FORMAT(7X"PAC02"12X" PH20"12X"PVC02"12X" PV02"12X"AMBA02"
0132      *11X"PBOVP"/)
0133 19  FORMAT(7X,F5.2,4F17.2,F17.3)
0134 20  FORMAT("1")
0135 C
0136 C*****
0137 C
0138 C      FILE READ IN PROCEDURE
0139 C
0140 C*****
0141 C
0142 C      IF "METRIC" IS TRUE THE DEPTH INCREMENTS ARE WANTED IN METERS.
0143 C      INTEGERIZE STOP DEPTH INCREMENT DESIRED BY THE CALLING PROGRAM.
0144 C
0145 C      IMODE=1
0146 C      IF(METRIC)IMODE=2
0147 C      IDINC=DINC
0148 C
0149 C      OPEN FILE "IFILE" INTO INPUT BUFFER "IDCB". ALL SUBSEQUENT READS
0150 C      FROM "IFILE" WILL BE SPECIFIED TO BE FROM "IDCB". IF ERROR OCCURS
0151 C      PRINT ERROR MESSAGE THEN STOP.
0152 C
0153 C      CALL OPEN(IDCB,IERR,IFILE,3)
0154 C      CALL FMPE(IERR,IFILE,LU)
0155 C      IF (IERR.LT.0) STOP
0156 C
0157 C      READ IN 30 ROWS OF MAXIMUM TISSUE TENSIONS FOR 9 TISSUES FROM A
0158 C      A SUB-FILE INTO MEMORY BUFFER "IBUF". THEN READ VALUES FROM "IBUF"
0159 C      INTO ARRAY "M".
0160 C
0161 175  DO 180 J=1,30
0162      CALL READF (IDCB,IERR,IBUF,IL,LEN)
0163      CALL CODE
0164      READ (IBUF,11)X(M(I,J),I=1,9)
0165 180  CONTINUE
0166 C
0167 C      READ IN DEPTH UNITS "MODE", STOP DEPTH INCREMENT AND INERT GAS
0168 C      LABEL OF SUB-FILE.
0169 C
0170 C      CALL READF(IDCB,IERR,IBUF,IL,LEN)
0171 C      CALL CODE
0172 C      READ (IBUF,12) MODE,INCR,IGAS
0173 C
0174 C      READ IN TISSUE HALFTIMES AND NUMBER OF TISSUES FROM SUB-FILE.
0175 C
0176 C      CALL READF(IDCB,IERR,IBUF,IL,LEN)
0177 C      CALL CODE

```

```

0178      READ (IBUF,10) HLFTH,NTISS
0179 C
0180 C      READ IN SATURATION-DESATURATION RATIOS FROM SUBFILE.
0181 C
0182      CALL READF(IDC8,IERR,IBUF,IL,LEN)
0183      CALL CODE
0184      READ (IBUF,10) SDR
0185 C
0186 C      IF THE SUB-FILE JUST READ IN DOES NOT HAVE ITS PARAMETERS IN THE
0187 C      DESIRED DEPTH UNITS OR STOP DEPTH INCREMENTS READ IN THE NEXT
0188 C      SUB-FILE.
0189 C
0190      IF(MODE.NE.IMODE) GO TO 175
0191      IF(IDINC.NE.INCR) GO TO 175
0192 C
0193 C      CLOSE FILE "IFILE". IF ERROR OCCURS PRINT ERROR MESSAGE AND STOP.
0194 C
0195      CALL CLOSE(IDC8,IERR)
0196      CALL FMPE(IERR,IFILE,LU)
0197      IF(IERR.LT.0) STOP
0198 C
0199 C      IF NO PRINTOUT DESIRED THEN RETURN.
0200 C
0201      IF(IPRT.NE.1) RETURN
0202 C
0203 C *****
0204 C
0205 C      END FILE READ IN
0206 C
0207 C *****
0208 C
0209 C *****
0210 C
0211 C      MODEL PARAMETER PRINTOUT PROCEDURE
0212 C
0213 C *****
0214 C
0215 C      PRINT HEADER
0216 C
0217      WRITE(LP,13) IFILE,IGAS,(HLFTH(I),I=1,NTISS)
0218      WRITE(LP,14)(SDR(I),I=1,NTISS)
0219      WRITE(LP,15)
0220 C
0221 C      PRINTOUT TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS.
0222 C
0223      DO 200 J=1,30
0224      IDPTH=INCR+J
0225      WRITE(LP,16) IDPTH,UNITS(MODE),(M(I,J),I=1,NTISS)
0226 200 CONTINUE
0227 C
0228 C      PRINT FOOTER
0229 C
0230      WRITE(LP,15)
0231      WRITE(LP,17)
0232      WRITE(LP,18)
0233 C
0234 C      PRINTOUT VALUES IN COMMON BLOCK "BLDVL" THEN RETURN.
0235 C
0236      WRITE(LP,19)PAC02,PH20,PVC02,PV02,ANBA02,P80VP
0237      WRITE(LP,20)

```

```
0238      RETURN
0239 C
0240 C*****
0241 C
0242 C      END MODEL PARAMETER PRINTOUT
0243 C
0244 C*****
0245 C
0246      END
0247      END$
```

ANNEX C

PROGRAMS FOR COMPUTING
ASCENT CRITERIA

ANNEX C-1

PROGRAM MVALU LISTING

```

0001 FTM#4 PROGRAM MVALU(3,1000), 10 DEC 82 VER 1.1
0002
0003 C
0004 C
0005 C CREATES MODEL PARAMETER INPUT FILE. EACH FILE WILL CONTAIN THREE
0006 C SUBFILES, THE FIRST WILL HAVE 10 FSU INCREMENTS, THE SECOND WILL
0007 C HAVE 3 MSW INCREMENTS AND THE THIRD 5 MSW INCREMENTS.
0008 C
0009 C THE ACTUAL COMPUTATION OF THE MAXIMUM TISSUE TENSIONS IS DONE IN
0010 C SUBROUTINE "MCOMP".
0011 C
0012 C
0013 C
0014 C
0015 C CDR EDWARD D. THALMANN (MC) USN
0016 C
0017 C
0018 C U.S. NAVY EXPERIMENTAL DIVING
0019 C UNIT
0020 C PANAMA CITY,FLORIDA 32407
0021 C
0022 C
0023 C
0024 C *****
0025 C
0026 C * VARIABLES *
0027 C *****
0028 C
0029 C * VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0030 C OPERATING SYSTEM.
0031 C
0032 C ATMD CONVERTS DEPTH UNITS TO FSU
0033 C FACTR ARRAY HOLDING POSSIBLE VALUES OF "ATMD"
0034 C MLFTM TISSUE HALFTIME ARRAY
0035 C *IBUF MEMORY BUFFER FOR DISK FILES
0036 C ICONT HOLDS TERMINAL RESPONSES TO QUESTIONS
0037 C *IDCB DATA CONTROL BLOCK USUALLY FOR OUTPUT FILES
0038 C *IDCBM DATA CONTROL BLOCK USUALLY FOR INPUT FILES
0039 C IDPTH DEPTH FOR ROW OF "MTABLE" TISSUE TENSIONS
0040 C *IERR RTE IV-B ERROR CODE(- IF ERROR)
0041 C IFILE ARRAY CONTAINING OUTPUT FILENAME
0042 C IGAS CURRENT INERT GAS NAME
0043 C *IL SPECIFIED NUMBER OF CHARACTERS TO BE READ FOR FILE
0044 C INCR STOP DEPTH INCREMENT READ FROM FILE
0045 C IOPT NUMBER OF THE OPTION SELECTED
0046 C *IPAR LOGICAL UNIT NUMBER ARRAY
0047 C *ISES DUMMY VARIABLE
0048 C JGAS NEW INERT GAS NAME
0049 C LP DEVICE NUMBER OF LINE PRINTER
0050 C LU DEVICE NUMBER OF TERMINAL
0051 C MFILE ARRAY CONTAINING INPUT FILENAME
0052 C MODE DEPTH UNITS(1- FEET, 2-METERS)
0053 C MTABLE MODEL PARAMETER INPUT FILE OUTPUT ARRAY
0054 C MULTP DEPTH MULTIPLIER
0055 C NAM ARRAY HOLDING PROGRAM NAME
0056 C NTISS NUMBER OF TISSUES
0057 C SDR SATURATION-DESATURATION RATIOS

```



```

0053 C      STNSH      MAXIMUM TISSUE TENSIONS FOR SURFACING
0059 C      UNITS
0060 C
0061 C*****
0062 C
0063 C*****
0064 C
0065 C      *****
0066 C      * SUBROUTINES REQUIRED *
0067 C      *****
0068 C
0069 C      * HEWLETT PACKARD RTE IV-8 OPERATING SYSTEM SUBROUTINES
0070 C      AND FUNCTIONS
0071 C
0072 C      *CLOSE      CLOSES DISK FILE
0073 C      *CODE      ALLOWS NEXT READ TO OCCUR FROM MEMORY BUFFER
0074 C      *CREAT      CREATES NEW FILE
0075 C      *FMPER      DECODES AND PRINTS RTE IV-8 ERROR MESSAGES
0076 C      *LOGLU      LOGICAL UNIT # OF TERMINAL
0077 C      *LUTRU      LOGICAL UNIT NUMBER OF TERMINAL ON ERROR
0078 C      *MCOMP      COMPUTES ONE SET OF MAXIMUM TISSUE TENSIONS
0079 C      *POSTH      POSITIONS DISK FILE TO SPECIFIED RECORD
0080 C      *PURGE      ELIMINATES SPECIFIED FILE FROM DISK
0081 C      *READF      READS DATA FROM DISK FILE INTO MEMORY BUFFER
0082 C      *RMPAR      PASSES LOGICAL UNIT # OF TERMINAL TO PROGRAM
0083 C      *RWINDF     POSTIONS FILE TO FIRST RECORD
0084 C      *WRITE      WRITE FROM MEMORY BUFFER TO DISK FILE
0085 C
0086 C*****
0087 C
0088 C      INTEGER IPAR(5),NAM(3),IFILE(3),MFILE(3),IDCB(144),IBUF(36),
0089 C      *      IDC5H(144)
0090 C      REAL      UNITS(2),STNSH(9),FACTR(2),IGAS(3),JGAS(3),HLFTM(9),
0091 C      *      SDR(9),MTABLE(3,9,30),MULTP
0092 C      DATA UNITS/4H FSU, 4H MSU/, FACTR/ 1., 3.28084/, IL/36/,
0093 C      *      IGAS/3*4H /, NAM /2HMMV,2HAL,2HU /, SDR,MTISS/9*1.0,9/,
0094 C      *      HLFTM/5.,10.,20.,40.,80.,120.,160.,200.,240./
0095 C
0096 C      DATA STNSH/9*0.0/, MULTP/1.0/
0097 C
0098 C
0099 1      FORMAT(3A2)
0100 2      FORMAT("SELECT OPTION: 1-LIST ONLY 2-CREATE NEW MATRIX 6-EXIT")
0101 3      FORMAT("SELECT CREATE OPTION"/
0102 C      *25X*3-CREATE NEW FILE"/
0103 C      *25X*4-MODIFY OLD FILE"/
0104 C      *25X*5-CREATE NEW FILE USING OLD FILE AS INPUT"/
0105 C      *25X*6-EXIT PROGRAM")
0106 4      FORMAT("PRINTOUT MAXIMUM TISSUE TENSION TABLES? (YES/NO)")
0107 6      FORMAT(" CURRENT MULTIPLIER, ENTER CHANGE"/F9.2)
0108 7      FORMAT("ENTER FILE NAME FOR NEW VALUE MATRIX")
0109 8      FORMAT("INERT GAS IS "3A4" ENTER CHANGE")
0110 9      FORMAT(3A4)
0111 10     FORMAT(9F7.2,19)
0112 11     FORMAT("NTISS ="16)
0113 12     FORMAT("CURRENT HALFTIMES,ENTER CHANGES"/9F8.2)
0114 13     FORMAT("CURRENT SDR'S, ENTER CHANGES"/9F8.2)
0115 14     FORMAT(
0116 C      *" CURRENT NUMBER OF COMPARTMENTS ACTIVE IS "12". ENTER CHANGE")
0117 15     FORMAT(" CURRENT SURFACING TENSIONS, ENTER CHANGES"/9F8.3)

```

```

0118 16  FORMAT( )
0119 17  FORMAT("ENTER FILE NAME OF EXISTING MATRIX FILE")
0120 18  FORMAT(9F8.3)
0121 19  FORMAT(3(9F7.2,/,),I4)
0122 20  FORMAT(2I8,3A4)
0123 21  FORMAT("CONTINUE? (YES OR NO) -")
0124 22  FORMAT("DONE CHANGING? GO ON TO COMPUTATION? (YES OR NO) -")
0125 23  FORMAT(6/
0126      *51X          "TABLE"12/
0127      *51X          "-----"4/
0128      *33X          "TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS"/
0129      *33X          "-----"/
0130      *45X          "(",3A2"- 3A4")2/
0131 24  FORMAT(46X          "TISSUE HALF-TIMES"2/
0132      *5X          "DEPTH "9(I6" MIN")
0133 25  FORMAT(13X,9(F6.2" SDR"))
0134 26  FORMAT(
0135      *5X          "-----"
0136      *3X          "-----")
0137 27  FORMAT(I9,A4,9F10.3)
0138 28  FORMAT("1")
0139 C
0140 C*****
0141 C
0142 C          INITIALIZATION AND OPTION SELECT PROCEDURE
0143 C
0144 C*****
0145 C
0146 C          GET LOGICAL UNIT NUMBERS OF TERMINAL(LU) AND LINE PRINTER(LP).
0147 C
0148 C          CALL RMPAR(IPAR)
0149 C          LU=IPAR(1)
0150 C          IF(LU.LE.1) LU=LUTRUC LU )
0151 C          IF(LU.LE.0) LU=LOGLUKISES)
0152 C          LP=6
0153 C
0154 C          GET DESIRED OPTION FROM TERMINAL(1-PRINT 2-CREATE 6-EXIT PROGRAM)
0155 C          IF 1,2 OR 6 NOT SPECIFIED ASK FOR DESIRED OPTION AGAIN.
0156 C
0157 40  WRITE(LU,2)
0158 C          IOPT=6
0159 C          READ(LU,*) IOPT
0160 C          IF(IOPT.EQ.1) GO TO 50
0161 C          IF(IOPT.EQ.6) STOP
0162 C          IF(IOPT.NE.2) GO TO 40
0163 C
0164 C          SELECT CREATE OPTION.(3-MAKE NEW FILE, 4-MODIFY EXISTING FILE
0165 C          5-MAKE A NEW FILE STARTING WITH AN EXISTING FILE, 6-EXIT PROGRAM)
0166 C          IF A 3,4,5,OR 6 NOT SPECIFIED ASK FOR DESIRED OPTION AGAIN.
0167 C
0168 45  WRITE(LU,3)
0169 C          IOPT=6
0170 C          READ(LU,*) IOPT
0171 C          IF(IOPT.EQ.6) STOP
0172 C          IF(IOPT.EQ.3) GO TO 55
0173 C          IF(IOPT.EQ.5) GO TO 50
0174 C          IF(IOPT.NE.4) GO TO 45
0175 C
0176 C*****
0177 C

```

```

0178 C                      END INITIALIZATION AND OPTION SELECT
0179 C
0180 C *****
0181 C
0182 C *****
0183 C
0184 C                      FILE SPECIFICATION AND READ IN PROCEDURE
0185 C
0186 C          OPENS NEEDED INPUT FILES, CREATES NEEDED OUTPUT FILES, AND READS 1
0187 C          NEEDED STARTING VALUES FROM THE INPUT FILE.
0188 C
0189 C *****
0190 C
0191 C          GET INPUT FILE NAME FOR OPTIONS 1, 4, OR 5. IF NO FILENAME
0192 C          GO BACK AND ASK FOR DESIRED OPTIONS AGAIN.
0193 C
0194 50  WRITE(LU,17)
0195      READ(LU,1) MFILE
0196      IF(MFILE.NE.2H ) GO TO 53
0197      IF(IOPT.EQ.1) GO TO 40
0198      GO TO 45
0199 C
0200 C          IF OPTION 1 SELECTED GO TO PRINTOUT PROCEDURE.
0201 C
0202 53  IF(IOPT.EQ.1) GO TO 170
0203 C
0204 C          IF OPTION 4 SELECTED NO NEW OUTPUT FILE NEEDED. GO OPEN INPUT FILE
0205 C
0206 C          IF(IOPT.EQ.4) GO TO 58
0207 C
0208 C          GET NAME OF NEW OUTPUT FILE IF OPTION 3 OR 5 SELECTED.
0209 C          IF NO FILENAME SPECIFIED GO BACK AND ASK FOR DESIRED OPTION AGAIN.
0210 C
0211 55  WRITE(LU,7)
0212      READ(LU,1) IFILE
0213      IF(IFILE.EQ.2H ) GO TO 45
0214 C
0215 C          CREATE NEW OUTPUT FILE. IF AN ERROR OCCURS(IERR.LT.0) GO BACK AND
0216 C          ASK FOR ANOTHER OUTPUT FILENAME.
0217 C
0218 C          CALL CREAT(IDCBI,IERR,IFILE,29,4,0,60)
0219 C          CALL FMPER(IERR,NAM,LU)
0220 C          IF(IERR.LT.0) GO TO 55
0221 C
0222 C          IF OPTION 3 SELECTED NO FILE INPUT NEEDED. VALUES OF ALL VARIABLES
0223 C          WILL REMAIN AS THEY WERE SET IN DATA STATEMENT.
0224 C
0225 C          IF(IOPT.EQ.3) GO TO 65
0226 C
0227 C          OPEN INPUT FILE IF OPTION 4 OR 5 SELECTED. GO BACK FOR NEW
0228 C          ON ERROR.
0229 C
0230 58  CALL OPEN(IDCBI,IERR,MFILE,3)
0231      CALL FMPER(IERR,NAM,LU)
0232      IF(IERR.LT.0) GO TO 50
0233 C
0234 C          READ FIRST RECORD OF INPUT FILE INTO SURFACING TENSION ARRAY
0235 C          "STNSN".
0236 C
0237 C          CALL READF(IDCBI,IERR,IBUF,IL)

```

```

0238      CALL FMPER(IERR,NAM,LU)
0239      CALL CODE
0240      READ(IBUF,18) STNSH
0241      C
0242      C      POSITION FILE TO 31ST RECORD AND READ IT INTO UNITS MODE "MODE",
0243      C      STOP DEPTH INCREMENT "INCR" AND INERT GAS LABEL ARRAY "IGAS".
0244      C
0245      CALL POSNT(IDCBM,IERR,29,0)
0246      CALL READF(IDCBM,IERR,IBUF,IL)
0247      CALL FMPER(IERR,NAM,LU)
0248      CALL CODE
0249      READ(IBUF,20) NODE,INCR,IGAS
0250      C
0251      C      READ IN TISSUE HALFTIMES INTO ARRAY "HLFTM" AND THE NUMBER OF
0252      C      TISSUES INT "NTISS" FROM THE 32ND RECORD.
0253      C
0254      CALL READF(IDCBM,IERR,IBUF,IL)
0255      CALL FMPER(IERR,NAM,LU)
0256      CALL CODE
0257      READ(IBUF,10) HLFTM,NTISS
0258      C
0259      C      READ IN SATURATION-DESATURATION RATIOS INTO ARRAY "SDR" FROM 33RD
0260      C      RECORD.
0261      C
0262      CALL READF(IDCBM,IERR,IBUF,IL)
0263      CALL FMPER(IERR,NAM,LU)
0264      CALL CODE
0265      READ(IBUF,10) SDR
0266      C
0267      C      CLOSE INPUT FILE JUST IN CASE
0268      C
0269      CALL CLOSE(IDCBM)
0270      C
0271      C      WRITE OUT STARTING STNSH,HLFTM,SDR,AND NTISS VALUES TO TERMINAL.
0272      C
0273      65  WRITE(LU,19) STNSH,HLFTM,SDR,NTISS
0274      WRITE(LU,21)
0275      C
0276      C      WANT TO CONTINUE? IF NOT GO BACK TO SELECT DESIRED OPTION AGAIN.
0277      C
0278      READ(LU,1) ICONT
0279      IF(ICONT.NE.2HYES) GO TO 45
0280      C
0281      C*****
0282      C
0283      C      END FILE SPECIFICATION AND READ IN
0284      C
0285      C*****
0286      C
0287      C*****
0288      C
0289      C      STARTING VARIABLE CHANGE PROCEDURE
0290      C
0291      C      ALLOWS DESIRED VALUES TO BE CHANGED. HITTING A RETURN KEY RETAINS
0292      C      DISPLAYED VALUES.
0293      C
0294      C*****
0295      C
0296      C      CHANGE INERT GAS NAME.
0297      C

```

```

0298 70 WRITE(LU,8) IGAS
0299 READ(LU,9) JGAS
0300 IF(JGAS.EQ.4H ) GO TO 75
0301 DO 72 I=1,3
0302 72 IGAS(I)=JGAS(I)
0303 C
0304 C CHANGE NUMBER OF TISSUES.
0305 C
0306 75 WRITE(LU,14) NTISS
0307 READ(LU,*) NTISS
0308 C
0309 C CHANGE SURFACING TISSUE TENSIONS.
0310 C
0311 WRITE(LU,15) (STNSN(I),I=1,NTISS)
0312 READ(LU,*) STNSN
0313 C
0314 C CHANGE TISSUE HALFTIMES.
0315 C
0316 WRITE(LU,12) (HLFTM(I),I=1,NTISS)
0317 READ(LU,*) HLFTM
0318 C
0319 C CHANGE SATURATION DESATURATION RATIOS.
0320 C
0321 WRITE(LU,13) (SDR(I),I=1,NTISS)
0322 READ(LU,*) SDR
0323 C
0324 C CHANGE DEPTH MULTIPLIER.
0325 C
0326 WRITE(LU,6) MULTP
0327 READ(LU,*) MULTP
0328 C
0329 C IF DONE CHANGING GO COMPUTE TABLE OF MAXIMUM TISSUE TENSIONS. IF
0330 C MORE CHANGES DESIRED OR TO REVIEW VALUES GO BACK TO BEGINNING OF
0331 C PROCEDURE.
0332 C
0333 WRITE(LU,22)
0334 READ(LU,1) ICONT
0335 IF(ICONT.NE.2HYES) GO TO 70
0336 C
0337 C*****
0338 C
0339 C END CHANGE PROCEDURE
0340 C
0341 C*****
0342 C
0343 C*****
0344 C
0345 C MAXIMUM PERMISSIBLE TISSUE TENSION COMPUTATION PROCEDURE
0346 C
0347 C*****
0348 C
0349 C GET SURFACING TENSIONS INTO FIRST ROW OF "MTABLE".
0350 C
0351 DO 80 K=1,3
0352 DO 80 I=1,NTISS
0353 80 MTABLE(K,I,1)=STNSN(I)
0354 C
0355 C
0356 C COMPUTE THREE SETS OF MAXIMUM TISSUE TENSIONS IN 10 FSU,3 AND 5
0357 C MSW INCREMENTS.

```

```

0358 C
0359 DO 120 K=1,3
0360     MODE=1
0361     IF(K.GT.1) MODE=2
0362 C
0363 C     SELECT APPROPRIATE CONVERSION FACTOR TO CONVERT VALUE OF "INCR" TO
0364 C     UNITS OF FSW. ALL MAXIMUM TISSUE TENSIONS IN UNITS OF FSW BUT THE
0365 C     DEPTH INCREMENT MAY BE IN FEET OR METERS.
0366 C
0367     ATND=FACTR(MODE)
0368     INCR=10
0369     IF(K.EQ.2) INCR=3
0370     IF(K.EQ.3) INCR=5
0371 C
0372 C     COMPUTE ONE SET OF MAXIMUM TISSUE TENSIONS FOR 30 DEPTH INCREMENTS
0373 C
0374     CALL MCOMP(MTABLE,K,MULTP,INCR,ATND)
0375 120 CONTINUE
0376 C
0377 C*****
0378 C
0379 C     END MAXIMUM TISSUE TENSION COMPUTATION
0380 C
0381 C*****
0382 C
0383 C*****
0384 C
0385 C     FILE OUTPUT PROCEDURE
0386 C
0387 C*****
0388 C
0389 C     GET RID OF OLD FILE AND CREATE NEW FILE WITH SAME NAME FOR
0390 C     OPTION 4 ONLY.
0391 C
0392     IF(IOPT.NE.4) GO TO 140
0393     CALL PURGE(IDC8,IERR,MFILE)
0394     CALL FMPER(IERR,MFILE,LU)
0395     CALL CREAT(IDC8,IERR,MFILE,29,4,0,60)
0396     CALL FMPER(IERR,MFILE,LU)
0397     DO 130 I=1,3
0398 130     IFILE(I)=MFILE(I)
0399 C
0400 C     OPEN OUTPUT FILE, GO BACK AND ASK FOR DESIRED OPTION ON ERROR.
0401 C
0402 140     CALL OPEN(IDC8,IERR,IFILE,3)
0403     CALL FMPER(IERR,IFILE,LU)
0404     IF(IERR.LT.0) GO TO 45
0405 C
0406 C*****
0407 C
0408 C     WRITE THREE SUB-FILES TO THE OUTPUT FILE.
0409 C
0410 C*****
0411 C
0412     DO 160 K=1,3
0413 C
0414 C     SET DEPTH UNITS MODE AND INCREMENT
0415 C
0416     MODE=1
0417     IF(K.GT.1) MODE=2

```

```

0418          INCR=10
0419          IF(K.EQ.2) INCR=3
0420          IF(K.EQ.3) INCR=5
0421 C
0422 C      WRITE MTABLE TO OUTPUT FILE
0423 C
0424          DO 150 J=1,30
0425              WRITE(LU,18) (MTABLE(K,I,J),I=1,NTISS)
0426              CALL CODE
0427              WRITE(IBUF,18) (MTABLE(K,I,J),I=1,9)
0428              CALL WRITF(IDCBI,IERR,IBUF,IL)
0429 150          CONTINUE
0430 C
0431 C      WRITE OUT UNITS,DEPTH INCREMENT, AND INERT GAS NAME.
0432 C
0433          WRITE(LU,20) MODE,INCR,IGAS
0434          CALL CODE
0435          WRITE(IBUF,20) MODE,INCR,IGAS
0436          CALL WRITF(IDCBI,IERR,IBUF,14)
0437 C
0438 C      WRITE OUT HALFTIMES AND NTISS
0439 C
0440          WRITE(LU,11) NTISS
0441          WRITE(LU,10) (HLFTM(I),I=1,NTISS)
0442          CALL CODE
0443          WRITE(IBUF,10) HLFTM,NTISS
0444          CALL WRITF(IDCBI,IERR,IBUF,IL)
0445 C
0446 C      WRITE OUT SDR VALUES
0447 C
0448          WRITE(LU,10) (SDR(I),I=1,NTISS)
0449          WRITE(LU,16)
0450          CALL CODE
0451          WRITE(IBUF,10) SDR,NTISS
0452          CALL WRITF(IDCBI,IERR,IBUF,IL)
0453 160          CONTINUE
0454 C
0455 C*****
0456 C
0457 C      DONE WRITING 3 SUB-FILES
0458 C
0459 C*****
0460 C
0461 C      ASK IF PRINTOUT WANTED. IF "NO" CLOSE FILE AND GO BACK TO SELECT
0462 C      DESIRED OPTION. IF "YES" REWIND FILE BEFORE GOING TO PRINTOUT
0463 C      PROCEDURE.
0464 C
0465          WRITE(LU,4)
0466          READ(LU,1) ICONT
0467          IF(ICONT.NE.2HYES) GO TO 165
0468          CALL RWIND(IDCBI,IERR)
0469          GO TO 175
0470 165          CALL CLOSE(IDCBI,IERR)
0471          CALL FMPIR(IERR,NAM,LU)
0472          GO TO 40
0473 C
0474 C*****
0475 C
0476 C      PRINTOUT PROCEDURE
0477 C

```

```

0478 C-----
0479 C
0480 C   OPTION 1 ENTERS HERE BECAUSE INPUT FILE MUST BE OPENED FIRST.
0481 C   GO BACK TO GET ANOTHER FILENAME ON ERROR. "IFILE" AND "MFILE"
0482 C   ARE THE SAME FILE FOR OPTION 1.
0483 C
0484 170  CALL OPEN(IDCB,IERR,MFILE,3)
0485      CALL FMPER(IERR,NAM,LU)
0486      IF(IERR.LT.0) GO TO 50
0487      DO 172 I=1,3
0488 172  IFILE(I)=MFILE(I)
0489 C
0490 C-----
0491 C
0492 C   PRINT OUT THREE TABLES FROM THE THREE SUBFILES.
0493 C
0494 C-----
0495 C
0496 175  DO 210 K=1,3
0497      DO 180 J=1,30
0498          CALL READF(IDCB,IERR,IBUF,IL,LEN)
0499          CALL CODE
0500          READ(IBUF,18) (NTABLE(K,I,J),I=1,9)
0501 180  CONTINUE
0502 C
0503 C   READ IN DEPTH UNITS MODE, INCR, GAS
0504 C
0505      CALL READF(IDCB,IERR,IBUF,IL)
0506      CALL CODE
0507      READ(IBUF,20) MODE, INCR, IGAS
0508      CALL READF(IDCB,IERR,IBUF,IL)
0509      CALL CODE
0510      READ(IBUF,10) HLFTH, NTISS
0511      CALL READF(IDCB,IERR,IBUF,IL)
0512      CALL CODE
0513      READ(IBUF,10) SDR
0514 C
0515 C   PRINT HEADER
0516 C
0517      WRITE(LP,23) K, IFILE, IGAS
0518      WRITE(LP,24) (HLFTH(I), I=1, NTISS)
0519      WRITE(LP,25) (SDR(I), I=1, NTISS)
0520      WRITE(LP,26)
0521      DO 200 J=1,30
0522          IDPTH=INCR*J
0523          WRITE(LP,27) IDPTH, UNITS(MODE), (NTABLE(K,I,J), I=1, NTISS)
0524 200  CONTINUE
0525 C
0526 C   PRINT FOOTER
0527 C
0528      WRITE(LP,26)
0529      WRITE(LP,28)
0530 210  CONTINUE
0531 C
0532 C-----
0533 C
0534 C   DONE PRINTING SUB-FILES
0535 C
0536 C-----
0537 C

```



```

0538 C      CLOSE FILE AND GO BACK TO SELECT NEW OPTION.
0539 C
0540 C      CALL CLOSE(IDC8,IERR)
0541 C      CALL FMPEK(IERR,NAM,LU)
0542 C      GO TO 40
0543 C
0544 C*****
0545 C
0546 C      END PRINTOUT PROCEDURE
0547 C
0548 C*****
0549 C
0550 C      END
0551 C      END*

```

ANNEX C-2

SUBROUTINE MCOMP
(Version 1.0)
LISTING

```

0001 FTN4
0002 SUBROUTINE MCOMP(MTABLE,K,MULTP,INCR,ATMD), 10 DEC 82 VER 1.0
0003 C
0004 C
0005 C COMPUTES A TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS FROM THE
0006 C VALUES IN THE FIRST ROW OF "MTABLE" (THE SURFACING TENSIONS).
0007 C THE TENSIONS AT DEPTH ARE RELATED TO THE SURFACING TENSIONS
0008 C BY THE RELATIONSHIP:
0009 C
0010 C TENSION AT DEPTH = SURFACING TENSION + DEPTH*MULTP
0011 C
0012 C THE SURFACING TENSIONS AND THE DEPTH MULTIPLIER (MULTP) MUST BE
0013 C SPECIFIED.
0014 C
0015 C
0016 C WRITTEN BY
0017 C
0018 C CDR EDWARD D. THALMANN (MC) USN
0019 C
0020 C
0021 C U.S. NAVY EXPERIMENTAL DIVING
0022 C UNIT
0023 C PANAMA CITY,FLORIDA 32407
0024 C
0025 C
0026 C
0027 C *****
0028 C *****
0029 C * VARIABLES *
0030 C *****
0031 C
0032 C * VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0033 C OPERATING SYSTEM.
0034 C
0035 C ATMD CONVERTS DEPTH UNITS TO FSW
0036 C INCR STOP DEPTH INCREMENT READ FROM FILE
0037 C MTABLE ARRAY HOLDING THREE SUB-FILE VALUES
0038 C MULTP DEPTH MULTIPLIER
0039 C
0040 C *****
0041 C
0042 C
0043 C REAL MTABLE(3,9,30),MULTP
0044 C
0045 C
0046 C COMPUTE ONE SET OF MAXIMUM TENSIONS.
0047 C
0048 C DO 100 J=2,30
0049 C DO 100 I=1,9
0050 C MTABLE(K,I,J)=MTABLE(K,I,J-1)+MULTP*INCR*ATMD
0051 C RETURN
0052 C END
0053 C END$

```

ANNEX C-3

SUBROUTINE MCOMP
(Version 2.0)
LISTING

1MCOMP2 T=00004 IS ON CR00015 USING 00026 BLKS R=0000

```

0001 FTN4
0002 SUBROUTINE MCOMP(MTABLE,K,MULTP,INCR,ATMD), 10 DEC 82 VER 2.0
0003 C
0004 C
0005 C COMPUTES A TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS FROM THE
0006 C VALUES IN THE FIRST ROW OF "MTABLE" (THE SURFACING TENSIONS).
0007 C THE TENSIONS AT DEPTH ARE RELATED TO THE SURFACING TENSIONS BY THE
0008 C RELATIONSHIP:
0009 C
0010 C  $M = FN2 * 33 * ((SR/R)^{10} + R - 1)$ 
0011 C
0012 C WHERE:
0013 C
0014 C M = MAXIMUM PERMISSIBLE TISSUE TENSION AT A GIVEN DEPTH
0015 C SR = SURFACING TENSION / 33.*FN2 (THE SURFACING RATIO)
0016 C R = M / (DEPTH + 33)*FN2 (THE DEPTH RATIO)
0017 C FN2= FRACTION OF NITROGEN
0018 C
0019 C THE VALUES OF "SR" (SURFACING RATIOS) ARE EMPIRICALLY DERIVED. THE
0020 C ABOVE EQUATION CANNOT BE EXPLICITLY SOLVED FOR "M" AND MUST BE
0021 C SOLVED BY ITERATION.
0022 C
0023 C
0024 C
0025 C
0026 C
0027 C
0028 C
0029 C
0029 C CDR EDWARD D. THALMANN (MC) USN
0030 C
0031 C
0032 C U.S. NAVY EXPERIMENTAL DIVING
0033 C UNIT
0034 C PANAMA CITY,FLORIDA 32407
0035 C
0036 C
0037 C
0038 C
0039 C
0040 C*****
0041 C
0042 C
0043 C
0044 C
0045 C * VARIABLES ASSOCIATED WITH HEWLETT PACKARD RTE IV-B
0046 C OPERATING SYSTEM.
0047 C
0048 C ATMD CONVERTS DEPTH UNITS TO FSW
0049 C DN2 CURRENT AMBIENT INERT GAS TENSION
0050 C DN2OLD PREVIOUS AMBIENT INERT GAS TENSION
0051 C DY FIRST DERIVATIVE OF "Y"
0052 C FN2 NITROGEN FRACTION
0053 C IPRINT ALWAYS PRINT ITERATION VALUES IF = 1
0054 C M MAXIMUM TENSION AT CURRENT DEPTH
0055 C MTABLE ARRAY HOLDING THREE SUB-FILE VALUES
0056 C MULTP DEPTH MULTIPLIER
0057 C NITR NUMBER OF NEWTON RAPHSON ITERATIONS

```

```

0058 C      R      DEPTH RATIO
0059 C      SCHK    VARIABLE USED TO CHECK FOR SIGN CHANGE
0060 C      SR      SURFACING RATIO
0061 C      T      MAXIMUM TISSUE TENSION
0062 C      T1     TRIAL VALUE OF "T"
0063 C      TERROR  MAXIMUM ITERATION ERROR
0064 C      VALIT   ARRAY CONTAINING ITERATION VALUES
0065 C      Y      NEWTON RAPHSON NULL VARIABLE
0066 C      Y1     TRIAL VALUE OF "Y"
0067 C
0068 C*****
0069 C
0070 C
0071 C      REAL MTABLE(3,9,30),MULTP,M,VALIT(4,10)
0072 C
0073 C
0074 C      FORMAT(//10X"NEWTON RAPHSON ITERATION"//
0075 C      *6X"1"6X"J"6X"K"6X"M"
0076 C      */3X,14,3X,14,3X,14,3X,14,F13.6,1X//
0077 C      *9X"1"17X"Y"14X"DY"13X" Y/DY"/10(4F16.7)/)////)
0078 C
0079 C*****
0080 C
0081 C      BEGIN
0082 C
0083 C*****
0084 C
0085 C      SET "IPRNT" TO "1" IF ITERATION PRINTOUT ALWAYS WANTED. OTHERWISE
0086 C      SET TO "0".
0087 C
0088 C      IPRNT=0
0089 C
0090 C      SET INERT GAS FRACTION TO 79%.
0091 C
0092 C      FN2=0.79
0093 C
0094 C
0095 C      COMPUTE ONE SET OF MAXIMUM TENSIONS.
0096 C
0097 C      DO 400 I=1,9
0098 C      DO 400 J=2,30
0099 C
0100 C      CC..PUTE DEPTH FOR THIS AND PREVIOUS ROW OF "MTABLE".
0101 C
0102 C      DN2=(( J-1)*INCR*ATMD+33.)*FN2
0103 C      DN2OLD=(( J-2)*INCR*ATMD+33.)*FN2
0104 C
0105 C      COMPUTE SURFACING RATIO
0106 C
0107 C      SR=MTABLE(K,I,1)/(33.*FN2)
0108 C
0109 C*****
0110 C
0111 C      NEWTON RAPHSON ITERATION
0112 C
0113 C*****
0114 C
0115 C      INITIALIZE NUMBER OF ITERATIONS TO "0".
0116 C
0117 C      NITR=0

```

```

0118 C
0119 C COMPUTE DEPTH RATIO "R". "Y" WILL BE EXACTLY 0.0 WHEN "T" IS
0120 C THE CORRECT MAXIMUM TENSION FOR THIS DEPTH. "DY" IS THE FIRST
0121 C DERIVATIVE OF "Y".
0122 C
0123 C T=MTABLE(K,I,J-1)*(<DN2>/<DN2OLD>)
0124 230 R=T/<DN2>
0125 C Y=T-33.*FN2*((<SR/R>)**10+R-1)
0126 C DY=1+(<330.*FN2/T>)*(<SR/R>)**10-(<33.*FN2/DN2>)
0127 C
0128 C SEED ERROR CHECK WITH "T" AND "Y" ON FIRST PASS.
0129 C
0130 C IF(NITR.GT.0) GO TO 240
0131 C T1=T
0132 C Y1=Y
0133 240 NITR=NITR+1
0134 C
0135 C SAVE ITERATION VALUES FOR IN CASE PRINTOUT OCCURS.
0136 C
0137 C VALIT(1,NITR)=T
0138 C VALIT(2,NITR)=Y
0139 C VALIT(3,NITR)=DY
0140 C VALIT(4,NITR)=Y/DY
0141 C
0142 C STOP ITERATION IF "Y" AND "Y/DY" ARE BOTH LESS THAN THE ACCEPTABLE
0143 C ERROR.
0144 C
0145 C IF(ABS(Y/DY).LE.0.0001 .AND. ABS(Y).LT.0.001) GO TO 270
0146 C
0147 C STOP ITERATION AFTER 10 PASSES NO MATTER WHAT.
0148 C
0149 C IF(NITR.EQ.10) GO TO 270
0150 C
0151 C IF "Y" HAS UNDERGONE A SIGN CHANGE SINCE LAST RECORDING "T1" THEN
0152 C "ABS(T-T1)" IS THE MAXIMUM ERROR FOR "T". IF THIS ERROR IS
0153 C ACCEPTABLE THEN STOP ITERATION. THIS TERMINATES ITERATIONS WHERE
0154 C "Y" OSCILLATES AROUND ZERO MORE RAPIDLY. IF "SCHK" IS POSITIVE
0155 C THEN NO SIGN CHANGE OCCURED AND NO ERROR CHECK MADE.
0156 C
0157 C SCHK=SIGN(1.0,Y)*SIGN(1.0,Y1)
0158 C IF(SCHK.GT.0) GO TO 260
0159 C TERROR=ABS(T1-T)
0160 C IF(TERROR.LT.0.0001) GO TO 270
0161 C T1=T
0162 C Y1=Y
0163 C
0164 C COMPUTE NEW ESTIMATE OF THE CROSSOVER TIME FOR THE NEXT PASS.
0165 C
0166 260 T=T-(Y/DY)
0167 C GO TO 230
0168 C
0169 C WRITE OUT ITERATION VALUES IF CONVERGENCE TO ERROR LIMITS HAS NOT
0170 C OCCURED IN 10 ITERATIONS OR IF PRINT MODE ON (IPRNT=1).
0171 C
0172 270 IF(NITR.LT.10 .AND. IPRNT.EQ.0) GO TO 300
0173 C WRITE(6,1) I,J,K,MTABLE(K,I,J-1),(<VALIT(N,L),N=1,4),L=1,NITR)
0174 300 MTABLE(K,I,J)=T
0175 C
0176 C *****
0177 C

```

```
0178 C                      END NEWTON RAPHSON ITERATION
0179 C
0180 C*****
0181 C
0182 400  CONTINUE
0183      RETURN
0184      END
0185      END*
```


ANNEX C-4

SUBROUTINE MCOMP
(Version 2.1)
LISTING


```

0058      IF(D.GT.80) M=29.59+1.035*(D+33)
0059      DO 90 I=1,9
0060  90      MTABLE(K,I,J)=M
0061 100      CONTINUE
0062      RETURN
0063      END
0064      END*

```

ANNEX C-5

MCOMP VERSION 1.0
ASCENT CRITERIA

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(CHVAL01- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	130.000	110.000	83.000	66.000	54.000	48.000	44.500	44.000	43.500
20 FSW	140.000	120.000	93.000	76.000	64.000	58.000	54.500	54.000	53.500
30 FSW	150.000	130.000	103.000	86.000	74.000	68.000	64.500	64.000	63.500
40 FSW	160.000	140.000	113.000	96.000	84.000	78.000	74.500	74.000	73.500
50 FSW	170.000	150.000	123.000	106.000	94.000	88.000	84.500	84.000	83.500
60 FSW	180.000	160.000	133.000	116.000	104.000	98.000	94.500	94.000	93.500
70 FSW	190.000	170.000	143.000	126.000	114.000	108.000	104.500	104.000	103.500
80 FSW	200.000	180.000	153.000	136.000	124.000	118.000	114.500	114.000	113.500
90 FSW	210.000	190.000	163.000	146.000	134.000	128.000	124.500	124.000	123.500
100 FSW	220.000	200.000	173.000	156.000	144.000	138.000	134.500	134.000	133.500
110 FSW	230.000	210.000	183.000	166.000	154.000	148.000	144.500	144.000	143.500
120 FSW	240.000	220.000	193.000	176.000	164.000	158.000	154.500	154.000	153.500
130 FSW	250.000	230.000	203.000	186.000	174.000	168.000	164.500	164.000	163.500
140 FSW	260.000	240.000	213.000	196.000	184.000	178.000	174.500	174.000	173.500
150 FSW	270.000	250.000	223.000	206.000	194.000	188.000	184.500	184.000	183.500
160 FSW	280.000	260.000	233.000	216.000	204.000	198.000	194.500	194.000	193.500
170 FSW	290.000	270.000	243.000	226.000	214.000	208.000	204.500	204.000	203.500
180 FSW	300.000	280.000	253.000	236.000	224.000	218.000	214.500	214.000	213.500
190 FSW	310.000	290.000	263.000	246.000	234.000	228.000	224.500	224.000	223.500
200 FSW	320.000	300.000	273.000	256.000	244.000	238.000	234.500	234.000	233.500
210 FSW	330.000	310.000	283.000	266.000	254.000	248.000	244.500	244.000	243.500
220 FSW	340.000	320.000	293.000	276.000	264.000	258.000	254.500	254.000	253.500
230 FSW	350.000	330.000	303.000	286.000	274.000	268.000	264.500	264.000	263.500
240 FSW	360.000	340.000	313.000	296.000	284.000	278.000	274.500	274.000	273.500
250 FSW	370.000	350.000	323.000	306.000	294.000	288.000	284.500	284.000	283.500
260 FSW	380.000	360.000	333.000	316.000	304.000	298.000	294.500	294.000	293.500
270 FSW	390.000	370.000	343.000	326.000	314.000	308.000	304.500	304.000	303.500
280 FSW	400.000	380.000	353.000	336.000	324.000	318.000	314.500	314.000	313.500
290 FSW	410.000	390.000	363.000	346.000	334.000	328.000	324.500	324.000	323.500
300 FSW	420.000	400.000	373.000	356.000	344.000	338.000	334.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

<HVAL02- HELIUM >

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	130.000	110.000	98.000	70.000	56.000	50.000	45.500	44.000	43.500
20 FSW	140.000	120.000	98.000	80.000	66.000	60.000	55.500	54.000	53.500
30 FSW	150.000	130.000	108.000	90.000	76.000	70.000	65.500	64.000	63.500
40 FSW	160.000	140.000	118.000	100.000	86.000	80.000	75.500	74.000	73.500
50 FSW	170.000	150.000	128.000	110.000	96.000	90.000	85.500	84.000	83.500
60 FSW	180.000	160.000	138.000	120.000	106.000	100.000	95.500	94.000	93.500
70 FSW	190.000	170.000	148.000	130.000	116.000	110.000	105.500	104.000	103.500
80 FSW	200.000	180.000	158.000	140.000	126.000	120.000	115.500	114.000	113.500
90 FSW	210.000	190.000	168.000	150.000	136.000	130.000	125.500	124.000	123.500
100 FSW	220.000	200.000	178.000	160.000	146.000	140.000	135.500	134.000	133.500
110 FSW	230.000	210.000	188.000	170.000	156.000	150.000	145.500	144.000	143.500
120 FSW	240.000	220.000	198.000	180.000	166.000	160.000	155.500	154.000	153.500
130 FSW	250.000	230.000	208.000	190.000	176.000	170.000	165.500	164.000	163.500
140 FSW	260.000	240.000	218.000	200.000	186.000	180.000	175.500	174.000	173.500
150 FSW	270.000	250.000	228.000	210.000	196.000	190.000	185.500	184.000	183.500
160 FSW	280.000	260.000	238.000	220.000	206.000	200.000	195.500	194.000	193.500
170 FSW	290.000	270.000	248.000	230.000	216.000	210.000	205.500	204.000	203.500
180 FSW	300.000	280.000	258.000	240.000	226.000	220.000	215.500	214.000	213.500
190 FSW	310.000	290.000	268.000	250.000	236.000	230.000	225.500	224.000	223.500
200 FSW	320.000	300.000	278.000	260.000	246.000	240.000	235.500	234.000	233.500
210 FSW	330.000	310.000	288.000	270.000	256.000	250.000	245.500	244.000	243.500
220 FSW	340.000	320.000	298.000	280.000	266.000	260.000	255.500	254.000	253.500
230 FSW	350.000	330.000	308.000	290.000	276.000	270.000	265.500	264.000	263.500
240 FSW	360.000	340.000	318.000	300.000	286.000	280.000	275.500	274.000	273.500
250 FSW	370.000	350.000	328.000	310.000	296.000	290.000	285.500	284.000	283.500
260 FSW	380.000	360.000	338.000	320.000	306.000	300.000	295.500	294.000	293.500
270 FSW	390.000	370.000	348.000	330.000	316.000	310.000	305.500	304.000	303.500
280 FSW	400.000	380.000	358.000	340.000	326.000	320.000	315.500	314.000	313.500
290 FSW	410.000	390.000	368.000	350.000	336.000	330.000	325.500	324.000	323.500
300 FSW	420.000	400.000	378.000	360.000	346.000	340.000	335.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL03- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	130.000	107.000	83.000	68.000	56.000	50.000	45.500	44.000	43.500
20 FSW	140.000	117.000	93.000	78.000	66.000	60.000	55.500	54.000	53.500
30 FSW	150.000	127.000	103.000	88.000	76.000	70.000	65.500	64.000	63.500
40 FSW	160.000	137.000	113.000	98.000	86.000	80.000	75.500	74.000	73.500
50 FSW	170.000	147.000	123.000	108.000	96.000	90.000	85.500	84.000	83.500
60 FSW	180.000	157.000	133.000	118.000	106.000	100.000	95.500	94.000	93.500
70 FSW	190.000	167.000	143.000	128.000	116.000	110.000	105.500	104.000	103.500
80 FSW	200.000	177.000	153.000	138.000	126.000	120.000	115.500	114.000	113.500
90 FSW	210.000	187.000	163.000	148.000	136.000	130.000	125.500	124.000	123.500
100 FSW	220.000	197.000	173.000	158.000	146.000	140.000	135.500	134.000	133.500
110 FSW	230.000	207.000	183.000	168.000	156.000	150.000	145.500	144.000	143.500
120 FSW	240.000	217.000	193.000	178.000	166.000	160.000	155.500	154.000	153.500
130 FSW	250.000	227.000	203.000	188.000	176.000	170.000	165.500	164.000	163.500
140 FSW	260.000	237.000	213.000	198.000	186.000	180.000	175.500	174.000	173.500
150 FSW	270.000	247.000	223.000	208.000	196.000	190.000	185.500	184.000	183.500
160 FSW	280.000	257.000	233.000	218.000	206.000	200.000	195.500	194.000	193.500
170 FSW	290.000	267.000	243.000	228.000	216.000	210.000	205.500	204.000	203.500
180 FSW	300.000	277.000	253.000	238.000	226.000	220.000	215.500	214.000	213.500
190 FSW	310.000	287.000	263.000	248.000	236.000	230.000	225.500	224.000	223.500
200 FSW	320.000	297.000	273.000	258.000	246.000	240.000	235.500	234.000	233.500
210 FSW	330.000	307.000	283.000	268.000	256.000	250.000	245.500	244.000	243.500
220 FSW	340.000	317.000	293.000	278.000	266.000	260.000	255.500	254.000	253.500
230 FSW	350.000	327.000	303.000	288.000	276.000	270.000	265.500	264.000	263.500
240 FSW	360.000	337.000	313.000	298.000	286.000	280.000	275.500	274.000	273.500
250 FSW	370.000	347.000	323.000	308.000	296.000	290.000	285.500	284.000	283.500
260 FSW	380.000	357.000	333.000	318.000	306.000	300.000	295.500	294.000	293.500
270 FSW	390.000	367.000	343.000	328.000	316.000	310.000	305.500	304.000	303.500
280 FSW	400.000	377.000	353.000	338.000	326.000	320.000	315.500	314.000	313.500
290 FSW	410.000	387.000	363.000	348.000	336.000	330.000	325.500	324.000	323.500
300 FSW	420.000	397.000	373.000	358.000	346.000	340.000	335.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL04- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	128.000	103.000	82.000	68.000	56.000	50.000	45.500	44.000	43.500
20 FSW	138.000	113.000	92.000	78.000	66.000	60.000	55.500	54.000	53.500
30 FSW	148.000	123.000	102.000	88.000	76.000	70.000	65.500	64.000	63.500
40 FSW	158.000	133.000	112.000	98.000	86.000	80.000	75.500	74.000	73.500
50 FSW	168.000	143.000	122.000	108.000	96.000	90.000	85.500	84.000	83.500
60 FSW	178.000	153.000	132.000	118.000	106.000	100.000	95.500	94.000	93.500
70 FSW	188.000	163.000	142.000	128.000	116.000	110.000	105.500	104.000	103.500
80 FSW	198.000	173.000	152.000	138.000	126.000	120.000	115.500	114.000	113.500
90 FSW	208.000	183.000	162.000	148.000	136.000	130.000	125.500	124.000	123.500
100 FSW	218.000	193.000	172.000	158.000	146.000	140.000	135.500	134.000	133.500
110 FSW	228.000	203.000	182.000	168.000	156.000	150.000	145.500	144.000	143.500
120 FSW	238.000	213.000	192.000	178.000	166.000	160.000	155.500	154.000	153.500
130 FSW	248.000	223.000	202.000	188.000	176.000	170.000	165.500	164.000	163.500
140 FSW	258.000	233.000	212.000	198.000	186.000	180.000	175.500	174.000	173.500
150 FSW	268.000	243.000	222.000	208.000	196.000	190.000	185.500	184.000	183.500
160 FSW	278.000	253.000	232.000	218.000	206.000	200.000	195.500	194.000	193.500
170 FSW	288.000	263.000	242.000	228.000	216.000	210.000	205.500	204.000	203.500
180 FSW	298.000	273.000	252.000	238.000	226.000	220.000	215.500	214.000	213.500
190 FSW	308.000	283.000	262.000	248.000	236.000	230.000	225.500	224.000	223.500
200 FSW	318.000	293.000	272.000	258.000	246.000	240.000	235.500	234.000	233.500
210 FSW	328.000	303.000	282.000	268.000	256.000	250.000	245.500	244.000	243.500
220 FSW	338.000	313.000	292.000	278.000	266.000	260.000	255.500	254.000	253.500
230 FSW	348.000	323.000	302.000	288.000	276.000	270.000	265.500	264.000	263.500
240 FSW	358.000	333.000	312.000	298.000	286.000	280.000	275.500	274.000	273.500
250 FSW	368.000	343.000	322.000	308.000	296.000	290.000	285.500	284.000	283.500
260 FSW	378.000	353.000	332.000	318.000	306.000	300.000	295.500	294.000	293.500
270 FSW	388.000	363.000	342.000	328.000	316.000	310.000	305.500	304.000	303.500
280 FSW	398.000	373.000	352.000	338.000	326.000	320.000	315.500	314.000	313.500
290 FSW	408.000	383.000	362.000	348.000	336.000	330.000	325.500	324.000	323.500
300 FSW	418.000	393.000	372.000	358.000	346.000	340.000	335.500	334.000	333.500

AD-A125 064

COMPUTER ALGORITHMS USED IN COMPUTING THE MK 15/16
CONSTANT 07 ATA OXYGEN..(U) NAVY EXPERIMENTAL DIVING
UNIT PANAMA CITY FL E D THALMANN JAN 83 NEDU-1-83


F/G 6/19

NL

UNCLASSIFIED

3/3

													END DATE FILMED F. 03 DTIC	



MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL 85- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	125.000	100.000	82.000	68.000	56.000	50.000	45.500	44.000	43.500
20 FSW	135.000	110.000	92.000	78.000	66.000	60.000	55.500	54.000	53.500
30 FSW	145.000	120.000	102.000	88.000	76.000	70.000	65.500	64.000	63.500
40 FSW	155.000	130.000	112.000	98.000	86.000	80.000	75.500	74.000	73.500
50 FSW	165.000	140.000	122.000	108.000	96.000	90.000	85.500	84.000	83.500
60 FSW	175.000	150.000	132.000	118.000	106.000	100.000	95.500	94.000	93.500
70 FSW	185.000	160.000	142.000	128.000	116.000	110.000	105.500	104.000	103.500
80 FSW	195.000	170.000	152.000	138.000	126.000	120.000	115.500	114.000	113.500
90 FSW	205.000	180.000	162.000	148.000	136.000	130.000	125.500	124.000	123.500
100 FSW	215.000	190.000	172.000	158.000	146.000	140.000	135.500	134.000	133.500
110 FSW	225.000	200.000	182.000	168.000	156.000	150.000	145.500	144.000	143.500
120 FSW	235.000	210.000	192.000	178.000	166.000	160.000	155.500	154.000	153.500
130 FSW	245.000	220.000	202.000	188.000	176.000	170.000	165.500	164.000	163.500
140 FSW	255.000	230.000	212.000	198.000	186.000	180.000	175.500	174.000	173.500
150 FSW	265.000	240.000	222.000	208.000	196.000	190.000	185.500	184.000	183.500
160 FSW	275.000	250.000	232.000	218.000	206.000	200.000	195.500	194.000	193.500
170 FSW	285.000	260.000	242.000	228.000	216.000	210.000	205.500	204.000	203.500
180 FSW	295.000	270.000	252.000	238.000	226.000	220.000	215.500	214.000	213.500
190 FSW	305.000	280.000	262.000	248.000	236.000	230.000	225.500	224.000	223.500
200 FSW	315.000	290.000	272.000	258.000	246.000	240.000	235.500	234.000	233.500
210 FSW	325.000	300.000	282.000	268.000	256.000	250.000	245.500	244.000	243.500
220 FSW	335.000	310.000	292.000	278.000	266.000	260.000	255.500	254.000	253.500
230 FSW	345.000	320.000	302.000	288.000	276.000	270.000	265.500	264.000	263.500
240 FSW	355.000	330.000	312.000	298.000	286.000	280.000	275.500	274.000	273.500
250 FSW	365.000	340.000	322.000	308.000	296.000	290.000	285.500	284.000	283.500
260 FSW	375.000	350.000	332.000	318.000	306.000	300.000	295.500	294.000	293.500
270 FSW	385.000	360.000	342.000	328.000	316.000	310.000	305.500	304.000	303.500
280 FSW	395.000	370.000	352.000	338.000	326.000	320.000	315.500	314.000	313.500
290 FSW	405.000	380.000	362.000	348.000	336.000	330.000	325.500	324.000	323.500
300 FSW	415.000	390.000	372.000	358.000	346.000	340.000	335.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL06- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	120.000	98.000	80.000	68.000	56.000	50.000	45.500	44.000	43.500
20 FSW	130.000	108.000	90.000	78.000	66.000	60.000	55.500	54.000	53.500
30 FSW	140.000	118.000	100.000	88.000	76.000	70.000	65.500	64.000	63.500
40 FSW	150.000	128.000	110.000	98.000	86.000	80.000	75.500	74.000	73.500
50 FSW	160.000	138.000	120.000	108.000	96.000	90.000	85.500	84.000	83.500
60 FSW	170.000	148.000	130.000	118.000	106.000	100.000	95.500	94.000	93.500
70 FSW	180.000	158.000	140.000	128.000	116.000	110.000	105.500	104.000	103.500
80 FSW	190.000	168.000	150.000	138.000	126.000	120.000	115.500	114.000	113.500
90 FSW	200.000	178.000	160.000	148.000	136.000	130.000	125.500	124.000	123.500
100 FSW	210.000	188.000	170.000	158.000	146.000	140.000	135.500	134.000	133.500
110 FSW	220.000	198.000	180.000	168.000	156.000	150.000	145.500	144.000	143.500
120 FSW	230.000	208.000	190.000	178.000	166.000	160.000	155.500	154.000	153.500
130 FSW	240.000	218.000	200.000	188.000	176.000	170.000	165.500	164.000	163.500
140 FSW	250.000	228.000	210.000	198.000	186.000	180.000	175.500	174.000	173.500
150 FSW	260.000	238.000	220.000	208.000	196.000	190.000	185.500	184.000	183.500
160 FSW	270.000	248.000	230.000	218.000	206.000	200.000	195.500	194.000	193.500
170 FSW	280.000	258.000	240.000	228.000	216.000	210.000	205.500	204.000	203.500
180 FSW	290.000	268.000	250.000	238.000	226.000	220.000	215.500	214.000	213.500
190 FSW	300.000	278.000	260.000	248.000	236.000	230.000	225.500	224.000	223.500
200 FSW	310.000	288.000	270.000	258.000	246.000	240.000	235.500	234.000	233.500
210 FSW	320.000	298.000	280.000	268.000	256.000	250.000	245.500	244.000	243.500
220 FSW	330.000	308.000	290.000	278.000	266.000	260.000	255.500	254.000	253.500
230 FSW	340.000	318.000	300.000	288.000	276.000	270.000	265.500	264.000	263.500
240 FSW	350.000	328.000	310.000	298.000	286.000	280.000	275.500	274.000	273.500
250 FSW	360.000	338.000	320.000	308.000	296.000	290.000	285.500	284.000	283.500
260 FSW	370.000	348.000	330.000	318.000	306.000	300.000	295.500	294.000	293.500
270 FSW	380.000	358.000	340.000	328.000	316.000	310.000	305.500	304.000	303.500
280 FSW	390.000	368.000	350.000	338.000	326.000	320.000	315.500	314.000	313.500
290 FSW	400.000	378.000	360.000	348.000	336.000	330.000	325.500	324.000	323.500
300 FSW	410.000	388.000	370.000	358.000	346.000	340.000	335.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL 07- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	120.000	98.000	88.000	68.000	56.000	50.000	49.000	48.000	47.000
20 FSW	132.000	110.000	92.000	80.000	68.000	62.000	61.000	60.000	59.000
30 FSW	144.000	122.000	104.000	92.000	80.000	74.000	73.000	72.000	71.000
40 FSW	156.000	134.000	116.000	104.000	92.000	86.000	85.000	84.000	83.000
50 FSW	168.000	146.000	128.000	116.000	104.000	98.000	97.000	96.000	95.000
60 FSW	180.000	158.000	140.000	128.000	116.000	110.000	109.000	108.000	107.000
70 FSW	192.000	170.000	152.000	140.000	128.000	122.000	121.000	120.000	119.000
80 FSW	204.000	182.000	164.000	152.000	140.000	134.000	133.000	132.000	131.000
90 FSW	216.000	194.000	176.000	164.000	152.000	146.000	145.000	144.000	143.000
100 FSW	228.000	206.000	188.000	176.000	164.000	158.000	157.000	156.000	155.000
110 FSW	240.000	218.000	200.000	188.000	176.000	170.000	169.000	168.000	167.000
120 FSW	252.000	230.000	212.000	200.000	188.000	182.000	181.000	180.000	179.000
130 FSW	264.000	242.000	224.000	212.000	200.000	194.000	193.000	192.000	191.000
140 FSW	276.000	254.000	236.000	224.000	212.000	206.000	205.000	204.000	203.000
150 FSW	288.000	266.000	248.000	236.000	224.000	218.000	217.000	216.000	215.000
160 FSW	300.000	278.000	260.000	248.000	236.000	230.000	229.000	228.000	227.000
170 FSW	312.000	290.000	272.000	260.000	248.000	242.000	241.000	240.000	239.000
180 FSW	324.000	302.000	284.000	272.000	260.000	254.000	253.000	252.000	251.000
190 FSW	336.000	314.000	296.000	284.000	272.000	266.000	265.000	264.000	263.000
200 FSW	348.000	326.000	308.000	296.000	284.000	278.000	277.000	276.000	275.000
210 FSW	360.000	338.000	320.000	308.000	296.000	290.000	289.000	288.000	287.000
220 FSW	372.000	350.000	332.000	320.000	308.000	302.000	301.000	300.000	299.000
230 FSW	384.000	362.000	344.000	332.000	320.000	314.000	313.000	312.000	311.000
240 FSW	396.000	374.000	356.000	344.000	332.000	326.000	325.000	324.000	323.000
250 FSW	408.000	386.000	368.000	356.000	344.000	338.000	337.000	336.000	335.000
260 FSW	420.000	398.000	380.000	368.000	356.000	350.000	349.000	348.000	347.000
270 FSW	432.000	410.000	392.000	380.000	368.000	362.000	361.000	360.000	359.000
280 FSW	444.000	422.000	404.000	392.000	380.000	374.000	373.000	372.000	371.000
290 FSW	456.000	434.000	416.000	404.000	392.000	386.000	385.000	384.000	383.000
300 FSW	468.000	446.000	428.000	416.000	404.000	398.000	397.000	396.000	395.000

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL09- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	120.000	90.000	80.000	60.000	56.000	48.000	47.500	47.000	46.000
20 FSW	132.000	110.000	92.000	80.000	60.000	60.000	59.500	59.000	58.000
30 FSW	144.000	122.000	104.000	92.000	80.000	72.000	71.500	71.000	70.000
40 FSW	156.000	134.000	116.000	104.000	92.000	84.000	83.500	83.000	82.000
50 FSW	168.000	146.000	128.000	116.000	104.000	96.000	95.500	95.000	94.000
60 FSW	180.000	158.000	140.000	128.000	116.000	108.000	107.500	107.000	106.000
70 FSW	192.000	170.000	152.000	140.000	128.000	120.000	119.500	119.000	118.000
80 FSW	204.000	182.000	164.000	152.000	140.000	132.000	131.500	131.000	130.000
90 FSW	216.000	194.000	176.000	164.000	152.000	144.000	143.500	143.000	142.000
100 FSW	228.000	206.000	188.000	176.000	164.000	156.000	155.500	155.000	154.000
110 FSW	240.000	218.000	200.000	188.000	176.000	168.000	167.500	167.000	166.000
120 FSW	252.000	230.000	212.000	200.000	188.000	180.000	179.500	179.000	178.000
130 FSW	264.000	242.000	224.000	212.000	200.000	192.000	191.500	191.000	190.000
140 FSW	276.000	254.000	236.000	224.000	212.000	204.000	203.500	203.000	202.000
150 FSW	288.000	266.000	248.000	236.000	224.000	216.000	215.500	215.000	214.000
160 FSW	300.000	278.000	260.000	248.000	236.000	228.000	227.500	227.000	226.000
170 FSW	312.000	290.000	272.000	260.000	248.000	240.000	239.500	239.000	238.000
180 FSW	324.000	302.000	284.000	272.000	260.000	252.000	251.500	251.000	250.000
190 FSW	336.000	314.000	296.000	284.000	272.000	264.000	263.500	263.000	262.000
200 FSW	348.000	326.000	308.000	296.000	284.000	276.000	275.500	275.000	274.000
210 FSW	360.000	338.000	320.000	308.000	296.000	288.000	287.500	287.000	286.000
220 FSW	372.000	350.000	332.000	320.000	308.000	300.000	299.500	299.000	298.000
230 FSW	384.000	362.000	344.000	332.000	320.000	312.000	311.500	311.000	310.000
240 FSW	396.000	374.000	356.000	344.000	332.000	324.000	323.500	323.000	322.000
250 FSW	408.000	386.000	368.000	356.000	344.000	336.000	335.500	335.000	334.000
260 FSW	420.000	398.000	380.000	368.000	356.000	348.000	347.500	347.000	346.000
270 FSW	432.000	410.000	392.000	380.000	368.000	360.000	359.500	359.000	358.000
280 FSW	444.000	422.000	404.000	392.000	380.000	372.000	371.500	371.000	370.000
290 FSW	456.000	434.000	416.000	404.000	392.000	384.000	383.500	383.000	382.000
300 FSW	468.000	446.000	428.000	416.000	404.000	396.000	395.500	395.000	394.000

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVAL11- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN .91 SDR	20 MIN .83 SDR	40 MIN .83 SDR	80 MIN .83 SDR	120 MIN .83 SDR			
10 FSW	120.000	90.000	82.000	68.000	56.000	50.000			
20 FSW	132.000	110.000	94.000	80.000	68.000	62.000			
30 FSW	144.000	122.000	106.000	92.000	80.000	74.000			
40 FSW	156.000	134.000	118.000	104.000	92.000	86.000			
50 FSW	168.000	146.000	130.000	116.000	104.000	98.000			
60 FSW	180.000	158.000	142.000	128.000	116.000	110.000			
70 FSW	192.000	170.000	154.000	140.000	128.000	122.000			
80 FSW	204.000	182.000	166.000	152.000	140.000	134.000			
90 FSW	216.000	194.000	178.000	164.000	152.000	146.000			
100 FSW	228.000	206.000	190.000	176.000	164.000	158.000			
110 FSW	240.000	218.000	202.000	188.000	176.000	170.000			
120 FSW	252.000	230.000	214.000	200.000	188.000	182.000			
130 FSW	264.000	242.000	226.000	212.000	200.000	194.000			
140 FSW	276.000	254.000	238.000	224.000	212.000	206.000			
150 FSW	288.000	266.000	250.000	236.000	224.000	218.000			
160 FSW	300.000	278.000	262.000	248.000	236.000	230.000			
170 FSW	312.000	290.000	274.000	260.000	248.000	242.000			
180 FSW	324.000	302.000	286.000	272.000	260.000	254.000			
190 FSW	336.000	314.000	298.000	284.000	272.000	266.000			
200 FSW	348.000	326.000	310.000	296.000	284.000	278.000			
210 FSW	360.000	338.000	322.000	308.000	296.000	290.000			
220 FSW	372.000	350.000	334.000	320.000	308.000	302.000			
230 FSW	384.000	362.000	346.000	332.000	320.000	314.000			
240 FSW	396.000	374.000	358.000	344.000	332.000	326.000			
250 FSW	408.000	386.000	370.000	356.000	344.000	338.000			
260 FSW	420.000	398.000	382.000	368.000	356.000	350.000			
270 FSW	432.000	410.000	394.000	380.000	368.000	362.000			
280 FSW	444.000	422.000	406.000	392.000	380.000	374.000			
290 FSW	456.000	434.000	418.000	404.000	392.000	386.000			
300 FSW	468.000	446.000	430.000	416.000	404.000	398.000			

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL12- HELIUM)

DEPTH	TISSUE HALF-TIMES					
	5 MIN .63 SDR	10 MIN .66 SDR	20 MIN .71 SDR	40 MIN .83 SDR	80 MIN .83 SDR	120 MIN .83 SDR
10 FSW	120.000	90.000	82.000	68.000	56.000	50.000
20 FSW	132.000	110.000	94.000	80.000	60.000	62.000
30 FSW	144.000	122.000	106.000	92.000	80.000	74.000
40 FSW	156.000	134.000	118.000	104.000	92.000	86.000
50 FSW	168.000	146.000	130.000	116.000	104.000	98.000
60 FSW	180.000	158.000	142.000	128.000	116.000	110.000
70 FSW	192.000	170.000	154.000	140.000	128.000	122.000
80 FSW	204.000	182.000	166.000	152.000	140.000	134.000
90 FSW	216.000	194.000	178.000	164.000	152.000	146.000
100 FSW	228.000	206.000	190.000	176.000	164.000	158.000
110 FSW	240.000	218.000	202.000	188.000	176.000	170.000
120 FSW	252.000	230.000	214.000	200.000	188.000	182.000
130 FSW	264.000	242.000	226.000	212.000	200.000	194.000
140 FSW	276.000	254.000	238.000	224.000	212.000	206.000
150 FSW	288.000	266.000	250.000	236.000	224.000	218.000
160 FSW	300.000	278.000	262.000	248.000	236.000	230.000
170 FSW	312.000	290.000	274.000	260.000	248.000	242.000
180 FSW	324.000	302.000	286.000	272.000	260.000	254.000
190 FSW	336.000	314.000	298.000	284.000	272.000	266.000
200 FSW	348.000	326.000	310.000	296.000	284.000	278.000
210 FSW	360.000	338.000	322.000	308.000	296.000	290.000
220 FSW	372.000	350.000	334.000	320.000	308.000	302.000
230 FSW	384.000	362.000	346.000	332.000	320.000	314.000
240 FSW	396.000	374.000	358.000	344.000	332.000	326.000
250 FSW	408.000	386.000	370.000	356.000	344.000	338.000
260 FSW	420.000	398.000	382.000	368.000	356.000	350.000
270 FSW	432.000	410.000	394.000	380.000	368.000	362.000
280 FSW	444.000	422.000	406.000	392.000	380.000	374.000
290 FSW	456.000	434.000	418.000	404.000	392.000	386.000
300 FSW	468.000	446.000	430.000	416.000	404.000	398.000

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL13- HELIUM)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN .63 SDR	20 MIN .41 SDR	40 MIN .26 SDR	80 MIN .16 SDR	120 MIN .13 SDR
10 FSW	120.000	90.000	82.000	68.000	56.000	50.000
20 FSW	132.000	110.000	94.000	80.000	68.000	62.000
30 FSW	144.000	122.000	106.000	92.000	80.000	74.000
40 FSW	156.000	134.000	118.000	104.000	92.000	86.000
50 FSW	168.000	146.000	130.000	116.000	104.000	98.000
60 FSW	180.000	158.000	142.000	128.000	116.000	110.000
70 FSW	192.000	170.000	154.000	140.000	128.000	122.000
80 FSW	204.000	182.000	166.000	152.000	140.000	134.000
90 FSW	216.000	194.000	178.000	164.000	152.000	146.000
100 FSW	228.000	206.000	190.000	176.000	164.000	158.000
110 FSW	240.000	218.000	202.000	188.000	176.000	170.000
120 FSW	252.000	230.000	214.000	200.000	188.000	182.000
130 FSW	264.000	242.000	226.000	212.000	200.000	194.000
140 FSW	276.000	254.000	238.000	224.000	212.000	206.000
150 FSW	288.000	266.000	250.000	236.000	224.000	218.000
160 FSW	300.000	278.000	262.000	248.000	236.000	230.000
170 FSW	312.000	290.000	274.000	260.000	248.000	242.000
180 FSW	324.000	302.000	286.000	272.000	260.000	254.000
190 FSW	336.000	314.000	298.000	284.000	272.000	266.000
200 FSW	348.000	326.000	310.000	296.000	284.000	278.000
210 FSW	360.000	338.000	322.000	308.000	296.000	290.000
220 FSW	372.000	350.000	334.000	320.000	308.000	302.000
230 FSW	384.000	362.000	346.000	332.000	320.000	314.000
240 FSW	396.000	374.000	358.000	344.000	332.000	326.000
250 FSW	408.000	386.000	370.000	356.000	344.000	338.000
260 FSW	420.000	398.000	382.000	368.000	356.000	350.000
270 FSW	432.000	410.000	394.000	380.000	368.000	362.000
280 FSW	444.000	422.000	406.000	392.000	380.000	374.000
290 FSW	456.000	434.000	418.000	404.000	392.000	386.000
300 FSW	468.000	446.000	430.000	416.000	404.000	398.000

ANNEX C-6

MCOMP VERSION 2.0
ASCENT CRITERIA

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL1 - NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	91.245	78.731	67.000	55.790	51.358	49.533	49.272	48.490	46.926
20 FSW	110.988	96.416	82.613	69.281	63.967	61.771	61.457	60.515	58.627
30 FSW	131.714	114.663	98.482	82.814	76.556	73.960	73.598	72.486	70.259
40 FSW	152.405	132.885	114.273	96.234	89.023	86.040	85.613	84.331	81.764
50 FSW	173.132	150.976	129.928	109.519	101.358	97.981	97.497	96.046	93.138
60 FSW	193.617	168.913	145.440	122.673	113.567	109.798	109.258	107.639	104.394
70 FSW	213.936	186.698	160.814	135.704	125.660	121.502	120.906	119.120	115.540
80 FSW	234.094	204.339	176.060	148.623	137.647	133.103	132.452	130.500	126.587
90 FSW	254.102	221.845	191.186	161.439	149.537	144.611	143.905	141.788	137.545
100 FSW	273.969	239.225	206.203	174.160	161.339	156.032	155.271	152.991	148.420
110 FSW	293.703	256.489	221.118	186.794	173.059	167.373	166.559	164.116	159.219
120 FSW	313.315	273.645	235.937	199.346	184.703	178.642	177.773	175.168	169.948
130 FSW	332.811	290.698	250.668	211.822	196.277	189.841	188.919	186.154	180.611
140 FSW	352.199	307.656	265.317	224.228	207.785	200.977	200.002	197.077	191.214
150 FSW	371.485	324.525	279.887	236.567	219.231	212.054	211.025	207.941	201.760
160 FSW	390.675	341.310	294.385	248.844	230.619	223.074	221.993	218.750	212.252
170 FSW	409.774	358.014	308.813	261.062	241.952	234.041	232.907	229.508	222.693
180 FSW	428.787	374.643	323.175	273.224	253.234	244.957	243.772	240.215	233.087
190 FSW	447.719	391.201	337.475	285.334	264.466	255.827	254.589	250.876	243.435
200 FSW	466.572	407.690	351.717	297.393	275.652	266.651	265.361	261.493	253.741
210 FSW	485.351	424.114	365.901	309.404	286.793	277.432	276.090	272.068	264.005
220 FSW	504.059	440.476	380.032	321.369	297.892	288.171	286.779	282.602	274.230
230 FSW	522.700	456.778	394.112	333.291	308.950	298.872	297.428	293.097	284.417
240 FSW	541.275	473.023	408.142	345.171	319.969	309.535	308.040	303.556	294.569
250 FSW	559.787	489.213	422.124	357.010	330.950	320.161	318.615	313.979	304.686
260 FSW	578.240	505.351	436.061	368.811	341.896	330.753	329.156	324.368	314.770
270 FSW	596.634	521.438	449.954	380.575	352.807	341.311	339.664	334.724	324.822
280 FSW	614.973	537.475	463.805	392.303	363.685	351.838	350.140	345.049	334.844
290 FSW	633.257	553.466	477.615	403.996	374.531	362.332	360.585	355.343	344.836
300 FSW	651.490	569.411	491.385	415.655	385.346	372.798	371.000	365.607	354.799

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVAL2 - NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	86.831	74.821	64.393	55.790	50.054	48.229	47.969	47.187	45.623
20 FSW	104.934	91.831	79.526	69.281	62.399	60.200	59.886	58.942	57.052
30 FSW	124.634	109.292	94.857	82.814	74.708	72.115	71.745	70.631	68.400
40 FSW	144.348	126.769	110.101	96.234	86.893	83.903	83.477	82.192	79.619
50 FSW	163.935	143.993	125.289	109.519	98.946	95.561	95.078	93.624	90.710
60 FSW	183.363	161.125	140.177	122.673	110.875	107.098	106.559	104.936	101.683
70 FSW	202.630	178.111	155.010	135.704	122.690	118.523	117.928	116.138	112.549
80 FSW	221.744	194.958	169.718	148.623	134.402	129.848	129.198	127.241	123.319
90 FSW	240.713	211.675	184.311	161.439	146.819	141.080	140.376	138.254	134.000
100 FSW	259.548	228.271	198.797	174.160	157.549	152.229	151.469	149.184	144.601
110 FSW	278.258	244.756	213.184	186.794	168.998	163.299	162.486	160.037	155.128
120 FSW	296.850	261.137	227.480	199.346	180.374	174.298	173.431	170.820	165.586
130 FSW	315.332	277.420	241.690	211.822	191.681	185.230	184.309	181.537	175.981
140 FSW	333.712	293.612	255.820	224.228	202.923	196.100	195.126	192.194	186.316
150 FSW	351.995	309.719	269.875	236.567	214.105	206.911	205.884	202.793	196.596
160 FSW	370.186	325.744	283.859	248.844	225.238	217.667	216.588	213.338	206.823
170 FSW	388.292	341.694	297.777	261.062	236.302	228.372	227.240	223.832	217.001
180 FSW	406.316	357.571	311.631	273.224	247.323	239.027	237.843	234.278	227.132
190 FSW	424.262	373.388	325.425	285.334	258.296	249.636	248.400	244.679	237.219
200 FSW	442.134	389.124	339.162	297.393	269.223	260.201	258.913	255.036	247.264
210 FSW	459.935	404.805	352.844	309.404	280.107	270.724	269.384	265.352	257.269
220 FSW	477.670	420.427	366.475	321.369	290.950	281.206	279.816	275.629	267.236
230 FSW	495.340	435.991	380.855	333.291	301.752	291.651	290.209	285.868	277.166
240 FSW	512.948	451.582	393.589	345.171	312.517	302.058	300.565	296.070	287.061
250 FSW	530.496	466.960	407.876	357.010	323.245	312.438	310.886	306.239	296.923
260 FSW	547.988	482.367	420.519	368.811	333.938	322.768	321.174	316.374	306.752
270 FSW	565.425	497.727	433.920	380.575	344.597	333.074	331.429	326.477	316.550
280 FSW	582.808	513.039	447.280	392.303	355.224	343.348	341.653	336.549	326.318
290 FSW	600.141	528.367	460.601	403.996	365.819	353.591	351.846	346.591	336.058
300 FSW	617.424	543.531	473.884	415.655	376.384	363.806	362.010	356.605	345.769

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(HVAL3 - NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	80.817	70.910	61.786	53.183	48.751	46.926	46.665	45.883	44.319
20 FSW	98.855	87.230	76.431	66.158	60.829	58.627	58.312	57.366	55.473
30 FSW	117.520	103.890	91.221	79.137	72.857	70.259	69.887	68.772	66.536
40 FSW	136.170	120.505	105.916	91.998	84.759	81.764	81.334	80.047	77.468
50 FSW	154.689	136.976	120.474	104.725	96.530	93.138	92.652	91.195	88.274
60 FSW	173.053	153.300	134.895	117.324	108.179	104.394	103.851	102.224	98.964
70 FSW	191.263	169.482	149.185	129.805	119.716	115.540	114.941	113.147	109.549
80 FSW	209.326	185.530	163.353	142.176	131.152	126.587	125.933	123.972	120.040
90 FSW	227.252	201.454	177.410	154.449	142.495	137.545	136.836	134.708	130.445
100 FSW	245.049	217.263	191.364	166.630	153.752	148.420	147.656	145.364	140.771
110 FSW	262.727	232.964	205.222	178.727	164.931	159.219	158.400	155.945	151.024
120 FSW	280.294	248.567	218.992	190.746	176.038	169.948	169.075	166.458	161.211
130 FSW	297.758	264.076	232.679	202.692	187.077	180.611	179.685	176.906	171.336
140 FSW	315.123	279.498	246.289	214.570	198.054	191.214	190.234	187.295	181.482
150 FSW	332.397	294.838	259.827	226.385	208.971	201.760	200.726	197.627	191.415
160 FSW	349.585	310.102	273.296	238.140	219.833	212.252	211.166	207.907	201.376
170 FSW	366.691	325.292	286.701	249.838	230.643	222.693	221.554	218.138	211.289
180 FSW	383.720	340.414	300.844	261.483	241.403	233.087	231.895	228.322	221.157
190 FSW	400.675	355.470	313.330	273.078	252.116	243.435	242.191	238.461	230.982
200 FSW	417.561	370.464	326.561	284.624	262.785	253.741	252.445	248.558	240.766
210 FSW	434.380	385.399	339.739	296.124	273.411	264.005	262.657	258.614	250.511
220 FSW	451.135	400.277	352.867	307.581	283.997	274.230	272.830	268.633	260.218
230 FSW	467.829	415.101	365.948	318.995	294.543	284.417	282.966	278.614	269.890
240 FSW	484.464	429.873	378.982	330.369	305.053	294.369	293.067	288.561	279.528
250 FSW	501.044	444.595	391.972	341.785	315.527	304.686	303.133	298.473	289.133
260 FSW	517.570	459.269	404.920	353.084	325.967	314.770	313.166	308.353	298.707
270 FSW	534.043	473.897	417.827	364.267	336.374	324.822	323.167	318.202	308.250
280 FSW	550.467	488.481	430.695	375.495	346.749	334.844	333.138	328.021	317.764
290 FSW	566.842	503.021	443.525	386.691	357.093	344.836	343.079	337.811	327.250
300 FSW	583.171	517.520	456.318	397.854	367.488	354.799	352.992	347.573	336.789

ANNEX C-7

MCOMP VERSION 2.1
ASCENT CRITERIA

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVALS - NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	50.000	50.000	50.000	50.000	50.000	50.000	50.000	50.000	50.000
20 FSW	62.463	62.463	62.463	62.463	62.463	62.463	62.463	62.463	62.463
30 FSW	74.988	74.988	74.988	74.988	74.988	74.988	74.988	74.988	74.988
40 FSW	87.543	87.543	87.543	87.543	87.543	87.543	87.543	87.543	87.543
50 FSW	100.105	100.105	100.105	100.105	100.105	100.105	100.105	100.105	100.105
60 FSW	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655
70 FSW	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180
80 FSW	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669
90 FSW	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117
100 FSW	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895
110 FSW	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245
120 FSW	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595
130 FSW	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945
140 FSW	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295
150 FSW	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645
160 FSW	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995
170 FSW	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345
180 FSW	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695
190 FSW	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045
200 FSW	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395
210 FSW	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745
220 FSW	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095
230 FSW	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445
240 FSW	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795
250 FSW	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145
260 FSW	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495
270 FSW	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845
280 FSW	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195
290 FSW	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545
300 FSW	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVAL83- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	103.000	85.000	71.000	57.000	46.740	46.740	46.740	46.740	46.740
20 FSW	104.933	85.850	73.000	61.480	61.480	61.480	61.480	61.480	61.480
30 FSW	106.860	86.700	74.988	74.988	74.988	74.988	74.988	74.988	74.988
40 FSW	108.790	87.543	87.543	87.543	87.543	87.543	87.543	87.543	87.543
50 FSW	110.720	100.105	100.105	100.105	100.105	100.105	100.105	100.105	100.105
60 FSW	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655
70 FSW	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180
80 FSW	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669
90 FSW	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117
100 FSW	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895
110 FSW	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245
120 FSW	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595
130 FSW	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945
140 FSW	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295
150 FSW	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645
160 FSW	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995
170 FSW	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345
180 FSW	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695
190 FSW	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045
200 FSW	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395
210 FSW	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745
220 FSW	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095
230 FSW	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445
240 FSW	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795
250 FSW	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145
260 FSW	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495
270 FSW	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845
280 FSW	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195
290 FSW	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545
300 FSW	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVAL92- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSU	103.000	85.000	71.000	56.000	46.740	43.000	40.500	40.500	40.500
20 FSU	104.933	85.858	73.000	61.480	55.000	51.000	51.000	51.000	51.000
30 FSU	106.860	86.700	74.900	74.900	74.900	74.900	74.900	74.900	74.900
40 FSU	108.790	87.543	87.543	87.543	87.543	87.543	87.543	87.543	87.543
50 FSU	110.720	100.105	100.105	100.105	100.105	100.105	100.105	100.105	100.105
60 FSU	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655
70 FSU	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180	125.180
80 FSU	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669
90 FSU	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117
100 FSU	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895
110 FSU	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245
120 FSU	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595
130 FSU	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945
140 FSU	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295
150 FSU	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645
160 FSU	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995
170 FSU	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345
180 FSU	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695
190 FSU	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045
200 FSU	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395
210 FSU	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745
220 FSU	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095
230 FSU	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445
240 FSU	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795
250 FSU	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145
260 FSU	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495
270 FSU	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845
280 FSU	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195
290 FSU	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545
300 FSU	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(MVAL97- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	103.000	85.000	71.000	56.000	46.000	46.000	46.000	45.800	45.000
20 FSW	104.933	85.850	73.000	62.500	61.500	57.000	55.000	52.500	51.000
30 FSW	106.860	86.700	74.900	74.900	74.900	74.900	74.900	74.900	74.900
40 FSW	108.790	87.543	87.543	87.543	87.543	87.543	87.543	87.543	87.543
50 FSW	110.720	100.105	100.105	100.105	100.105	100.105	100.105	100.105	100.105
60 FSW	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655	112.655
70 FSW	125.100	125.100	125.100	125.100	125.100	125.100	125.100	125.100	125.100
80 FSW	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669	137.669
90 FSW	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117	150.117
100 FSW	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895	156.895
110 FSW	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245	167.245
120 FSW	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595	177.595
130 FSW	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945	187.945
140 FSW	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295	198.295
150 FSW	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645	208.645
160 FSW	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995	218.995
170 FSW	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345	229.345
180 FSW	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695	239.695
190 FSW	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045	250.045
200 FSW	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395	260.395
210 FSW	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745	270.745
220 FSW	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095	281.095
230 FSW	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445	291.445
240 FSW	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795	301.795
250 FSW	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145	312.145
260 FSW	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495	322.495
270 FSW	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845	332.845
280 FSW	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195	343.195
290 FSW	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545	353.545
300 FSW	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895	363.895

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(VVAL09- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	103.000	87.000	72.000	56.000	45.500	43.000	44.500	44.000	43.500
20 FSW	113.000	97.000	82.000	66.000	55.500	53.000	54.500	54.000	53.500
30 FSW	123.000	107.000	92.000	76.000	65.500	63.000	64.500	64.000	63.500
40 FSW	133.000	117.000	102.000	86.000	75.500	73.000	74.500	74.000	73.500
50 FSW	143.000	127.000	112.000	96.000	85.500	83.000	84.500	84.000	83.500
60 FSW	153.000	137.000	122.000	106.000	95.500	93.000	94.500	94.000	93.500
70 FSW	163.000	147.000	132.000	116.000	105.500	103.000	104.500	104.000	103.500
80 FSW	173.000	157.000	142.000	126.000	115.500	113.000	114.500	114.000	113.500
90 FSW	183.000	167.000	152.000	136.000	125.500	123.000	124.500	124.000	123.500
100 FSW	193.000	177.000	162.000	146.000	135.500	133.000	134.500	134.000	133.500
110 FSW	203.000	187.000	172.000	156.000	145.500	143.000	144.500	144.000	143.500
120 FSW	213.000	197.000	182.000	166.000	155.500	153.000	154.500	154.000	153.500
130 FSW	223.000	207.000	192.000	176.000	165.500	163.000	164.500	164.000	163.500
140 FSW	233.000	217.000	202.000	186.000	175.500	173.000	174.500	174.000	173.500
150 FSW	243.000	227.000	212.000	196.000	185.500	183.000	184.500	184.000	183.500
160 FSW	253.000	237.000	222.000	206.000	195.500	193.000	194.500	194.000	193.500
170 FSW	263.000	247.000	232.000	216.000	205.500	203.000	204.500	204.000	203.500
180 FSW	273.000	257.000	242.000	226.000	215.500	213.000	214.500	214.000	213.500
190 FSW	283.000	267.000	252.000	236.000	225.500	223.000	224.500	224.000	223.500
200 FSW	293.000	277.000	262.000	246.000	235.500	233.000	234.500	234.000	233.500
210 FSW	303.000	287.000	272.000	256.000	245.500	243.000	244.500	244.000	243.500
220 FSW	313.000	297.000	282.000	266.000	255.500	253.000	254.500	254.000	253.500
230 FSW	323.000	307.000	292.000	276.000	265.500	263.000	264.500	264.000	263.500
240 FSW	333.000	317.000	302.000	286.000	275.500	273.000	274.500	274.000	273.500
250 FSW	343.000	327.000	312.000	296.000	285.500	283.000	284.500	284.000	283.500
260 FSW	353.000	337.000	322.000	306.000	295.500	293.000	294.500	294.000	293.500
270 FSW	363.000	347.000	332.000	316.000	305.500	303.000	304.500	304.000	303.500
280 FSW	373.000	357.000	342.000	326.000	315.500	313.000	314.500	314.000	313.500
290 FSW	383.000	367.000	352.000	336.000	325.500	323.000	324.500	324.000	323.500
300 FSW	393.000	377.000	362.000	346.000	335.500	333.000	334.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(VAL14- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	60 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSU	120.000	90.000	70.000	50.000	40.500	45.500	44.500	44.000	43.500
20 FSU	130.000	100.000	80.000	60.000	50.500	55.500	54.500	54.000	53.500
30 FSU	140.000	110.000	90.000	70.000	60.500	65.500	64.500	64.000	63.500
40 FSU	150.000	120.000	100.000	80.000	70.500	75.500	74.500	74.000	73.500
50 FSU	160.000	130.000	110.000	90.000	80.500	85.500	84.500	84.000	83.500
60 FSU	170.000	140.000	120.000	100.000	90.500	95.500	94.500	94.000	93.500
70 FSU	180.000	150.000	130.000	110.000	100.500	105.500	104.500	104.000	103.500
80 FSU	190.000	160.000	140.000	120.000	110.500	115.500	114.500	114.000	113.500
90 FSU	200.000	170.000	150.000	130.000	120.500	125.500	124.500	124.000	123.500
100 FSU	210.000	180.000	160.000	140.000	130.500	135.500	134.500	134.000	133.500
110 FSU	220.000	190.000	170.000	150.000	140.500	145.500	144.500	144.000	143.500
120 FSU	230.000	200.000	180.000	160.000	150.500	155.500	154.500	154.000	153.500
130 FSU	240.000	210.000	190.000	170.000	160.500	165.500	164.500	164.000	163.500
140 FSU	250.000	220.000	200.000	180.000	170.500	175.500	174.500	174.000	173.500
150 FSU	260.000	230.000	210.000	190.000	180.500	185.500	184.500	184.000	183.500
160 FSU	270.000	240.000	220.000	200.000	190.500	195.500	194.500	194.000	193.500
170 FSU	280.000	250.000	230.000	210.000	200.500	205.500	204.500	204.000	203.500
180 FSU	290.000	260.000	240.000	220.000	210.500	215.500	214.500	214.000	213.500
190 FSU	300.000	270.000	250.000	230.000	220.500	225.500	224.500	224.000	223.500
200 FSU	310.000	280.000	260.000	240.000	230.500	235.500	234.500	234.000	233.500
210 FSU	320.000	290.000	270.000	250.000	240.500	245.500	244.500	244.000	243.500
220 FSU	330.000	300.000	280.000	260.000	250.500	255.500	254.500	254.000	253.500
230 FSU	340.000	310.000	290.000	270.000	260.500	265.500	264.500	264.000	263.500
240 FSU	350.000	320.000	300.000	280.000	270.500	275.500	274.500	274.000	273.500
250 FSU	360.000	330.000	310.000	290.000	280.500	285.500	284.500	284.000	283.500
260 FSU	370.000	340.000	320.000	300.000	290.500	295.500	294.500	294.000	293.500
270 FSU	380.000	350.000	330.000	310.000	300.500	305.500	304.500	304.000	303.500
280 FSU	390.000	360.000	340.000	320.000	310.500	315.500	314.500	314.000	313.500
290 FSU	400.000	370.000	350.000	330.000	320.500	325.500	324.500	324.000	323.500
300 FSU	410.000	380.000	360.000	340.000	330.500	335.500	334.500	334.000	333.500

TABLE OF MAXIMUM PERMISSIBLE TISSUE TENSIONS

(VVAL18- NITROGEN)

TISSUE HALF-TIMES

DEPTH	5 MIN 1.00 SDR	10 MIN 1.00 SDR	20 MIN 1.00 SDR	40 MIN 1.00 SDR	80 MIN 1.00 SDR	120 MIN 1.00 SDR	160 MIN 1.00 SDR	200 MIN 1.00 SDR	240 MIN 1.00 SDR
10 FSW	120.000	98.000	78.000	56.000	48.500	45.500	44.500	44.000	43.500
20 FSW	130.000	108.000	88.000	66.000	58.500	55.500	54.500	54.000	53.500
30 FSW	140.000	118.000	98.000	76.000	68.500	65.500	64.500	64.000	63.500
40 FSW	150.000	128.000	108.000	86.000	78.500	75.500	74.500	74.000	73.500
50 FSW	160.000	138.000	118.000	96.000	88.500	85.500	84.500	84.000	83.500
60 FSW	170.000	148.000	128.000	106.000	98.500	95.500	94.500	94.000	93.500
70 FSW	180.000	158.000	138.000	116.000	108.500	105.500	104.500	104.000	103.500
80 FSW	190.000	168.000	148.000	126.000	118.500	115.500	114.500	114.000	113.500
90 FSW	200.000	178.000	158.000	136.000	128.500	125.500	124.500	124.000	123.500
100 FSW	210.000	188.000	168.000	146.000	138.500	135.500	134.500	134.000	133.500
110 FSW	220.000	198.000	178.000	156.000	148.500	145.500	144.500	144.000	143.500
120 FSW	230.000	208.000	188.000	166.000	158.500	155.500	154.500	154.000	153.500
130 FSW	240.000	218.000	198.000	176.000	168.500	165.500	164.500	164.000	163.500
140 FSW	250.000	228.000	208.000	186.000	178.500	175.500	174.500	174.000	173.500
150 FSW	260.000	238.000	218.000	196.000	188.500	185.500	184.500	184.000	183.500
160 FSW	270.000	248.000	228.000	206.000	198.500	195.500	194.500	194.000	193.500
170 FSW	280.000	258.000	238.000	216.000	208.500	205.500	204.500	204.000	203.500
180 FSW	290.000	268.000	248.000	226.000	218.500	215.500	214.500	214.000	213.500
190 FSW	300.000	278.000	258.000	236.000	228.500	225.500	224.500	224.000	223.500
200 FSW	310.000	288.000	268.000	246.000	238.500	235.500	234.500	234.000	233.500
210 FSW	320.000	298.000	278.000	256.000	248.500	245.500	244.500	244.000	243.500
220 FSW	330.000	308.000	288.000	266.000	258.500	255.500	254.500	254.000	253.500
230 FSW	340.000	318.000	298.000	276.000	268.500	265.500	264.500	264.000	263.500
240 FSW	350.000	328.000	308.000	286.000	278.500	275.500	274.500	274.000	273.500
250 FSW	360.000	338.000	318.000	296.000	288.500	285.500	284.500	284.000	283.500
260 FSW	370.000	348.000	328.000	306.000	298.500	295.500	294.500	294.000	293.500
270 FSW	380.000	358.000	338.000	316.000	308.500	305.500	304.500	304.000	303.500
280 FSW	390.000	368.000	348.000	326.000	318.500	315.500	314.500	314.000	313.500
290 FSW	400.000	378.000	358.000	336.000	328.500	325.500	324.500	324.000	323.500
300 FSW	410.000	388.000	368.000	346.000	338.500	335.500	334.500	334.000	333.500

ANNEX D

**SUBROUTINE FMFER
LISTING**

&FMPER Y=00004 IS ON CR00012 USING 00021 BLKS R=0000

```

0001 FTN4
0002 C
0003 C   Name:  FMPER
0004 C
0005 C   Date:  27 July 1970           Operating System: HP 21MX RTE IV-B
0006 C                                           Subroutine Size:  533 words
0007 C                                           Message buffer added
0008 C
0009 C   Author:  Mark Mobley
0010 C                               Navy Experimental Diving Unit
0011 C                               Panama City, Florida
0012 C
0013 C   Source
0014 C     File:  &FMPER
0015 C
0016 C   Calling
0017 C   Sequence:  (&IERR,&NAM,&LU,&MESS)
0018 C               IERR - FMP error code from calling program.
0019 C               NAM  - Name of calling program.
0020 C               LU   - Logical unit no. of terminal.
0021 C               MESS - Message buffer (any length)
0022 C
0023 C   Arguments:
0024 C
0025 C       IASCII      ASCII ERROR CODE
0026 C       IBUFF       MEMORY BUFFER FOR DISK FILE
0027 C       IDCB        DISK FILE DATA CONTROL BLOCK
0028 C       IEC         BINARY VALUE OF ERROR CODE
0029 C       IER         ERROR CODE FOR FMPER INPUT FILE
0030 C       IERR        ERROR CODE FROM CALLING PROGRAM
0031 C       IPERR       POSITIVE VALUE OF BINARY ERREO CODE
0032 C       ISIGN       SIGN VALUE OF BINARY NUMBER
0033 C       LDASH       BINARY VALUE FOR DASH AND A NULL
0034 C       LEFT        LEFT HALF OF AN ASCII WORD
0035 C       LEN         ACTUAL NUMBER OF WORDS READ
0036 C       LU          DEVICE NUMBER OF TERMINAL
0037 C       MESS        OPTIONAL MESSAGE BUFFER
0038 C       NAM         NAME OF CALLING PROGRAM OR SUBROUTINE
0039 C       NAME        NAME OF FILE CONTAINING ERROR DESCRIPTIONS
0040 C       PGERR       TERMINAL DISPLAY BUFFER
0041 C       RIGHT       RIGHT HALF OF ASCII WORD
0042 C       SUBER       DISPLAY LABEL BUFFER
0043 C
0044 C
0045 C   RTE IV-B Operating System Subroutines required:
0046 C
0047 C       CLOSE       CLOSSES DISK FILE
0048 C       CHMOD       CONVERTS BINARY NUMBER TO ASCII
0049 C       OPEN        OPENS DISK FILE
0050 C       READF       READS DATA FROM DISK FILE INTO MEMORY BUFFER
0051 C       REIO        WRITES DIRECTLY TO TERMINAL BYPASSING FORMATTER
0052 C
0053 C
0054 C   Method:  This subroutine compares the calling program's FMP error
0055 C            code with the error codes listed in file FNPLST and will
0056 C            display the associated error description on the terminal or
0057 C            log device.

```

```

0058 *
0059 C   References:  File FMPLST
0060 C
0061 C
0062 SUBROUTINE FMPE(IERR,NAM,LU,MESS)
0063 *Returns FMP error on FMP Call
0064 INTEGER IBUF(40),IDCB(144),NAM(3),NAME(3),SUBER(14),PGERR(19),
0065 *   IASCI(3),RIGHT,MESS(1)
0066 DATA NAME/2HFW,2HPL,2HST/, LDASH/0264000/,
0067 *PGERR/2HIE,2HRR,2H =,3*2H ,2H I,2HM ,2HPR,2HOG,2HRA,2HM ,3*2H /,
0068 *SUBER/2HSU,2HRR,2HOU,2HTI,2HNE,2H F,2HNP,2HER,2H ,2HIE,2HR ,2H= ,
0069 *   2H ,2H /
0070 C
0071 C RETURN IF NO ERROR (>0)
0072 C
0073 IF(IERR .GE. 0)GO TO 90
0074 IF(LU .LT. 1)LU = 1
0075 C
0076 C OPEN FMP ERROR DESCRIPTION FILE
0077 C
0078 CALL OPEN(IDCB,IER,NAM,3,0,12)
0079 IF(IER .LT. 0)GO TO 30
0080 C
0081 C GET ERROR DESCRIPTION RECORD
0082 C
0083 10 CALL READF(IDCB,IER,IBUF,40,LEN)
0084 IF(IER .LT. 0)GO TO 30
0085 C
0086 C CONVERT ASCII NUMBERS TO BINARY W/O USING FORMATTER
0087 C RIGHT HALF
0088 C
0089 IEC = IAND(IBUF(2),00377B) - 600
0090 C
0091 C LEFT HALF
0092 C
0093 ISIGN = IBUF(2) / 256 - 600
0094 IF(ISIGN .LT. 0)GO TO 20
0095 IEC = ISIGN = 10 + IEC
0096 C
0097 C RIGHT HALF
0098 C
0099 ISIGN = IAND(IBUF(1),00377B) - 600
0100 IF(ISIGN .LT. 0)GO TO 20
0101 IEC = ISIGN = 100 + IEC
0102 C
0103 C ERROR CODE IS REALLY NEGATIVE
0104 C
0105 20 ISIGN = -IEC
0106 C
0107 C LOOK AT NEXT RECORD IF FMP ERROR DOES NOT MATCH ERROR NO.
0108 C
0109 IF(IERR .NE. ISIGN)GO TO 10
0110 C
0111 C CONVERT FMP ERROR NUMBER TO ASCII
0112 C
0113 30 IPERR = -IERR
0114 CALL CHAND(IPERR,IASCI)
0115 C
0116 C INSERT MINUS SIGN
0117 C

```



```

0118      IASCI(2) = IOR(LDASH,IAND(000377B,IASCI(2)))
0119      C
0120      C LOAD DISPLAY BUFFER WITH ERROR NUMBER & PROGRAM NAME
0121      C
0122      DO 40 I=1,3
0123          PGERR(I+3) = IASCI(I)
0124      40      PGERR(I+12) = NAM (I)
0125      C
0126      C DISPLAY FILE ERROR NO. & PROGRAM NAME
0127      C
0128      CALL REIO(2,LU,PGERR ,15)
0129      C
0130      C DETERMINE LENGTH OF MESSAGE BUFFER
0131      C
0132          I = 1
0133          J = 0
0134      50      LEFT = MESS(I) / 256
0135          IF(LEFT .LT. 32 .OR. LEFT .GT. 126)GO TO 60
0136          J = J + 1
0137          RIGHT = IAND(377B,MESS(I))
0138          IF(RIGHT .LT. 32 .OR. RIGHT .GT. 126)GO TO 60
0139          J = J + 1
0140          I = I + 1
0141          GO TO 50
0142      60      IF(J .GT. 0)CALL REIO(2,LU,MESS,-J)
0143      C
0144      C BRANCH IF ERROR ON DESCRIPTION FILE ACCESS ALSO
0145      C
0146          IF(IER .LT. 0)GO TO 70
0147      C
0148      C DISPLAY ERROR DESCRIPTION
0149      C
0150          CALL REIO(2,LU,IBUF (4),LEN-3)
0151          GO TO 80
0152      C
0153      C DISPLAY ERROR IN ACCESS TO ERROR DESCRIPTION FILE
0154      C
0155      70      IPERR = -IER
0156          CALL CHUND(IPERR,IASCI)
0157          IASCI(2) = IOR(LDASH,IAND(000377B,IASCI(2)))
0158          SUBER(13) = IASCI(2)
0159          SUBER(14) = IASCI(3)
0160          CALL REIO(2,LU,SUBER,14)
0161      C
0162      C CLOSE ERROR DESCRIPTION FILE
0163      C
0164      80      CALL CLOSE(IOC9,IER)
0165      90      RETURN
0166      END
0167      ENDS

```

END

DATE
FILMED

3-83

DTIC